

正面：

尺寸:65x90mm

5折页

70g书写纸

黑白印刷

### Quick Installation Guide GPON ONT

### Safety Guidance

#### 1.1 Safety Check

Before installing the device, you must check the following items.

##### 1.1.1 Electric Safety

- Ensure that there are no inflammable, conductive or moist objects around. Check whether the cables are aged and whether other electrical appliances are placed stably.
- Check whether the alternating or direct input current is within the allowed range of the device, whether the polarity of the direct current is correct, and whether the earth line is properly connected.

##### 1.1.2 Device Position

- Because the running electric device easily generates heat, please ensure to place the device in a well-ventilated environment.
- Avoid direct sunlight, and do not place the device on a PC case.
- Keep the device away from heat and water.
- Check whether power supply is available. The input voltage fluctuation range must be smaller than 10%. The power plug should not share one socket with a hair drier, an iron or a refrigerator.

##### 1.2 Safety Caution

- Read the quick installation guide carefully before using the device.
- Note all Cautions in the quick installation guide.
- Do not use any accessory that does not belong to the device without prior consent of the manufacturer, as it may cause fire or product damage.
- Use the power adapter accompanied in the package.
- Do not place any object on the device.
- Keep the device dry, ventilated, rainproof, and clean.
- During lightning weather, unplug the power plug and all connection cables, to protect the device against lightning.
- Clean the device using a soft and dry cloth rather than liquid or atomizers. Power off the device before cleansing it.

#### 2 Overview

This chapter mainly describes functions and the structure of the HALNy HL-4GMV2.

### 2.1 Features and Function

- Fast rate, Support up to 1.25Gbps uplink and 2.5Gbps downlink data transmission rates.
- Strong maintainability. Provide various statuses of LED indicators, to help troubleshooting.
- Long transmission distance, up to 20 km.

### 2.2 Front, rear and side Panel

The description of the front, rear and side panel of the GPON ONU as follows.

#### 2.2.1 Front Panel

LED	Color	Status	Description
POWER	Green	On	The power works normally.
POWER	Green	Off	Powered off or the power supply is abnormal.
PON	Green	Refer to Table 2: "PON LED Status Instruction"	
LOS	Red	Refer to Table 2: "PON LED Status Instruction"	
NET	Green	Blink	Data is being transmitted
NET	Green	On	The connection of Ethernet interface is normal.
NET	Green	Blink	Data is being transmitted through the Ethernet interface.
NET	Green	Off	The connection of the Ethernet interface fails to establish.
LAN1-4	Green	On	The connection of the Ethernet interface is normal.
LAN1-4	Green	Blink	Data is being transmitted through the Ethernet interface.
LAN1-4	Green	Off	The connection of the Ethernet interface fails to establish.
2.4G	Green	Blink	Data is being transmitted through the Ethernet interface.
2.4G	Green	Off	The connection of the Ethernet interface fails to establish.
5G	Green	Blink	Data is being transmitted through the Ethernet interface.
5G	Green	Off	The connection of the Ethernet interface fails to establish.
TEL1-2	Green	On	Voice account is registered
TEL1-2	Green	Off	Port deactivated or VoIP account is unregistered

Table 1: ONU LED Indication Table

PON LED Status Instruction
PON LOS Description
Off Off The ONU is disabled by the OLT
Flash Off The ONU is registering to the OLT
On Off The ONU has already registered to OLT
Off Flash The fiber is not connected properly

Table 2: PON LED Status Instruction

#### 2.2.2 Rear Panel

Interface / Button	Function
LAN1-4	Ethernet interface, for connecting to a computer or an Ethernet interface of a switch.
Power	Connect power cable
ON/OFF	Turn on/off the power supply.
TEL1-2	RJ-11 Telephone Port

Table 3: Rear Panel port description

#### 2.2.3 Side Panel

Button	Function
WLAN	Press and hold for 5 seconds to disable/enable Wi-Fi
WPS	Press and hold for 5 seconds to activate WPS pairing
RST	Press and hold for 5 seconds to Reset configuration to the factory default settings.

Table 4: Side Panel

#### ONT Bottom Panel Description:

Button	Function
WLAN	Press and hold for 5 seconds to disable/enable Wi-Fi
WPS	Press and hold for 5 seconds to activate WPS pairing
RST	Press and hold for 5 seconds to Reset configuration to the factory default settings.

### 3 ONU Installation

The chapter describes the required installation operations before you use the device for the first time.

#### 3.1 Product Networking Application - FTTH

Fiber to the Home. This means to install the ONU in the residential enterprise building. The optical line terminal (OLT) is placed in the central equipment room. The ONU can be placed in the home of user, or it can provide connection to the user through the Ethernet interface, according to the user requirement. The OLT connects to the ONU with an optical distributor in the point-to-multipoint way. See the following figure.

**Note:**  
The ONU applies to installation at home or in the corridor. Because installation and cabling in the corridor are relatively complex, let the professional engineers deploy according to the actual situation. This manual describes the procedure for installing the device at home, and is for reference only.

#### 3.2 Installation Preparations

The Ethernet interface of your computer connects to the Ethernet interface of the ONU. Before installing it, ensure that an Ethernet adapter is already installed in your computer.

#### 3.3 Connecting ONU

#### 3.3.1 Connecting the Network Cable

Step 1 Use the one end of the network cable to connect the Ethernet interface of the computer.

Step 2 Use other end of a network cable to connect the Ethernet interface on the rear panel of the HALNy HL-4GMV2.

#### 3.3.2 Connecting the Fiber

##### Caution:

- When a fiber is not in use, ensure to cover the optical interface of the ONU and the dust cap of the optical fiber. Prevent grease, dust pollution or water immersion, which may lead to unavailable fiber and optical interface of the device.
- If fibers need to be fixed or bended during cabling, do not fasten the fibers too tight. Avoid fiber extrusion, which may lead to increase of fiber material or unavailable fiber.

#### 3.3.3 Connecting the Power Adapter and Power Cord

- Connect the output end of the power adapter included in the device package to the input end of the power supply of the ONU.
- Insert one end of the power cord attached with the device into the input end of the power adapter. Insert the other end of the power cord into the power socket.
- Check whether the Power indicator is on. If it is on, the power supply is normal. Otherwise, check whether the power cord and the power adapter are correctly connected.

#### 4 Troubleshooting

Symptom	Solution
The POWER indicator is not on	<ul style="list-style-type: none"><li>Check whether the power connection is correct.</li><li>Check whether the power adapter matches the device.</li></ul>
The PON indicator is not on	<ul style="list-style-type: none"><li>Check whether the SN of ONU matches OLT.</li><li>Check whether the optical attenuation is in the normal range.</li></ul>
The LOS indicator is not on	<ul style="list-style-type: none"><li>Check whether the optical fiber cable is properly inserted.</li><li>Check whether the optical fiber connector is clean.</li></ul>

#### 5 Technical Specification

Main Technical Specifications	
Standard	GPON Standard ITU-T G.984, TR156/TR255
Rate	Uplink 1.25Gbps Downlink 2.5Gbps
Optical Interface	SC/APC, Single Mode
Interface	4 LAN ports Rj-45 10/100/1000Mbps MDI/MDIX Self-adaption 2 POTS ports Rj-11 FXS

#### Physical Characteristics and Environment Requirements

Power adapter input	100V~240V AC, 50Hz~60Hz
Whole-device power supply	12V DC, 1.5A
Standard power consumption	<18W
Operating temperature	0°C~45°C
Operating humidity	10%~95% (non-condensing)
Dimension	L x W x H: 151mm x 185mm x 38mm
Weight	<500g

#### Appendix A Acronyms and Abbreviations

GPON	Gigabit Passive Optical Network
FTTB	Fiber to the Building
FTTH	Fiber to the Home
OLT	Optical Line Terminal
ONU	Optical Network Unit
PON	Passive Optical Network

**Warning:**  
Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:**  
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**FCC Statement:**  
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
—Reorient or relocate the receiving antenna.  
—Increase the separation between the equipment and receiver.  
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
—Consult the dealer or an experienced radio/TV technician for help.

The equipment complies with FCC Radiation exposure limit set forth for uncontrolled environment. This equipment should be installed and operated with a minimum distance 20cm between the radiator and your body.

#### Recycling

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled according to European directive 2012/19/EU in order to be recycled or dismantled. This will minimize the negative effects on the environment and human health resulting from the possibility of the presence in the equipment substances, mixtures and hazardous components. A user can give the product to a competent recycling organization, to WEEE collection points or to a distributor (in accordance with local regulations).