



1.General Information




01

2.Plug and play ,automatic connected




02

3.Install the Ethernet Air




1.Plug in the antenna




Drill the hole and screw the Ethernet Air on the wall

03

4.Install the Ethernet Air




3.Plug in the RJ45 Cable



Plug in the power supply

04

5.Before you begin Check out all



Ethernet Air X1



Self tapping screwX2



Colloidal particlesX2



Ethernet CableX1



12V1A power adapterX1




Omnidirectional antennaX1

Wireless Signal Wall-through Ethernet Connector -- ETHERNET AIR

First omnidirectional Antenna Network Bridge with 10000ft transmission distance

6.Detail Technical Specifications

- Connectivity: Wi-Fi Halow security protocol
- Transmission Distance: Max 10000ft with the 1080P video
- Penetration Ability: 3-4 concrete walls
- Power: 12V/1ADC
- Operation Temperature: -5°F-120°F(-20°C-48°C)
- Size: 114mmX84mmX30mm
- Antenna: length 19cm with 2dbi gain
- Warranty: 12 months Parts and Lifetime Purchase Protection
- FCC ID: 2AZIK-AH9066



Version 2.0.0

Wireless Signal Wall-through Ethernet Connector -- ETHERNET AIR

05

06

FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.