



Timely Hand SOS Button User manual

Timely Hand SOS Button is a personal emergency device which together with the Timely hand app on smartphones creates an emergency alarm system using bluetooth technology. Timely Hand SOS Button can only work with Timely hand app; it cannot be used as an independent device.



User manual

To power on the device press the button for 3s. The device will power on and will start sending iBeacon signals. The Timely Hand app should be used to connect to the device further steps will be provided on the app.

General features

Main Chip	Nordic nRF52840
Bluetooth	Bluetooth 5.3
Range	Up to 150 meters (in the open area and no obstacles)
Dimension	48.9mm x 41.7mm x 12mm (Main body)
Material	ABS+PC & TPU
Waterproof	IP67
Color	Black
Installation	Neck pendant, wristband
Button	Mechanical button
LED	RED and GREEN LED
Operating temperature	-20°C / + 60°C
Power supply	CR2032 Lithium Coin Cell Battery220mAh
Certification	USA FCC ID: 2BACY-THSB1

Mechanical drawings



FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could

void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirements. The device can be used

in portable exposure conditions without restriction.