

USB, PS/2 or RS232 RFID Series




Specification

Model	09A/09B/09C	04	05	06
Size	140 X 100 X 25(mm) 110 X 80 X 25(mm)	140 X 100 X 25(mm)	140 X 100 X 25(mm)	140 X 100 X 25(mm)
Color	Champagne	offwhite	offwhite	offwhite
Voltage	DC 5V (USB Power)	DC 5V (Keypad)	DC 5V (USB/Keypad)	DC 5V (USB/Keypad)
Current	≤100mA	≤100mA	≤100mA	≤100mA
Ambient Temperature	-10°C ~ 70°C	-10°C ~ 70°C	-10°C ~ 70°C	-10°C ~ 70°C
Reading Range	3 ~ 15CM	5 ~ 10CM	5 ~ 10CM	5 ~ 10CM
Output Format	USB	Keypad Interface	Reader&Writer,RS232 Interface	RS232 Interface
Card Type	EM/Mifare/Desfire/ISO15693/TYPE A B C	EM-ID/Mifare	TM-E5551/Mifare	EM-ID/Mifare
Communication Distance	≤10M	≥10M	≥10M	≥10M
01A	01B	01C		
104 X 70 X 13(mm)	110 X 80 X 25(mm)	120 X 76 X 14(mm)		
Black	Black	Black		
DC 5V (USB Power)	DC 5V (USB Power)	DC 5V (USB Power)		
≤100mA	≤100mA	≤100mA		
-10°C ~ 70°C	-10°C ~ 70°C	-10°C ~ 70°C		
3 ~ 15CM	3 ~ 15CM	3 ~ 15CM		
USB	USB	USB		
EM/Mifare	EM/Mifare	EM/Mifare		

Example of Use

Plug it to USB port of PC or Laptop, execute the following steps after several seconds operating system adaption: Start----Program----Microsoft Office---- Word. Card Number will be showed in Word automatically while card was presented to the reader.



Features

- Avoid manual input mistake,
- Save your time with more convenient and efficient
- Free of installing driver, compatible with Windows98/2000/XP
- Support proximity (EM-ID 125 KHz, 13.56Mhz Frequency) Card.
- 5~10cm Proximity Reading Range
- 10 to 70 C Ambient Temperature
- Less 100mA Working Current
- DC 5V working Voltage or Power on USB
- Available Version: 125 KHz: 09B-ID, 09A-ID Mifare: 09B-Mifare, 09A-Mifare
- Optional: PS2 or RS232 interface. Mifare Reader and Writer.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.