



1. PREPARE DOOR & INSTALL LATCHES

- Prepare door according to template.
- Install deadbolt latch in top hole with cross slot for tailpiece toward bottom.
- Install beveled latch on bottom with bevel toward door frame.
- Secure with (4) small combo screws.

2. INSTALL LOCK ASSEMBLY

- Install lock chassis into bottom hole making sure to properly engage lock body into latchbolt.
- Install inside mounting plate and secure with (2) screws.



3. INSTALL READER ASSEMBLY

Install reader assembly from outside of door – feeding reader wire through chassis hole in door and through square hole in mounting plate – wire routes above deadbolt latch.

Ensure deadbolt is retracted:

Left Hand Door – Rotate tailpiece clockwise until it stops in the vertical orientation.

Right Hand Door – Rotate tailpiece counter-clockwise until it stops in the vertical orientation.



CLS INSTALLATION INSTRUCTION

INTERCONNECTED LOCK






4. PREPARE INSIDE ESCUTCHEON

- Rotate lever driver tab to correct orientation as shown.
- Hold escutcheon up to door and connect reader wire to control board.



Rotate Driver Tab
For Proper Handing



5. INSTALL INSIDE ESCUTCHEON AND LEVER

- Rotate thumb turn away from leading edge of door
- Install inside escutcheon. Push excess wire into door cavity.
- Secure escutcheon using two screws.
- Install batteries and battery cover.

CLS INSTALLATION INSTRUCTION

INTERCONNECTED LOCK



Caution Statement:

FCC ID: 2BBNS-KLCP1

Contains FCC ID: 2AV6C-CRCM1101B1

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including, an interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This equipment should be installed and operated with a minimum distance of 15 cm between the radiator and your body.