

Silicone Wireless Mouse User Manual

- A 2-button Touchpad scrollwireless optical mouse, rugged and waterproof, made of silicone
- 2.4 GHz digital radio frequency technology
- Automatic synchronization between Mouse and receiver
- Working distance up to 10 meters (30 feet)
- Rubberized surface provides comfort to user
- Precise and smooth cursor movement, superior performance
- 1000 dpi optical sensor with 3,000 frames/second scan rat
- Compatibility: Microsoft® Windows® 10, 8, 7, Vista® & XP
- Interface: Nano USB receiver
- Power: 2 x AAA alkaline battery
- Protection level: IP65

Step 1: Find the mini receiver, which is at the bottom of the mouse.

Step 2: Install two AAA Alkaline battery (No. 7) into the battery compartment, close the battery cover,

and lock the battery cover with the accompanying screws,

Step 3: Insert the mini receiver into the USB port of the computer.

Step 3: Multiple clicks of the left and right mouse buttons.

Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter