



KUU SUPPORT

www.kuu-tech.com

USER GUIDE

Please read this instruction thoroughly before using this product
and keep it for future reference.

V1.05



GETTING STARTED

Power On/Off

Press and hold the power button for 2-3s to turn on your laptop. Select your language and set up your laptop following the start guide.

Press and hold the power button for 2s, then release it, it will show Power off, Restart and Screenshort on the screen. Tap Power off to turn off the laptop.

Press and hold the power button for 10s to do a forced reboot when it frozen.

Battery

A rechargeable Li-ion battery is installed in the laptop.

DO NOT attempt to replace the laptop battery by yourself because you may damage the battery, which might cause overheating, fire or injury.





EN

DO NOT dispose the laptop in fire.

DO NOT expose the laptop battery to any heat source,direct sunlight or high tempreature.

Only use the original power adapter provided by us to charge the laptop battery.

We suggest you drain the battery completely once a month if only use your laptop occasionally.

The Li-ion battery in your laptop should be serviced or recycled by an authorized service provider, and must be recycled or disposed of separately from household waste.

Dispose of battery according to your local environmental laws and regulations.

Sleep Mode


Simply press the power button once to switch the laptop to the Sleep Mode when the laptop is ON,press again to wake it up.

Tip:

Go to Settings>System>Power&Battery>Screen &Sleep to set the time of entering the Sleep Mode.

NETWORK CONNECTION


Wifi CONNECTION

To connect to a Wi-Fi network in Windows, select the Network icon ( or ) on the task bar.

Select the Wi-Fi network you want > Connect, then type the password and follow the instructions. That's it—you're connected! This icon  will appear in the task bar.

02





After you're connected, you're ready to set up email, browse the web, and do a whole lot more online.

If Wi-Fi isn't available, or you just want the assurance of a wired connection, the Ethernet cable is your friend—just connect your PC to your router or modem, and then do your thing.


Bluetooth Paring

① Turn on your Bluetooth audio device and make it discoverable.

The way you make it discoverable depends on the device. Check the device or visit the manufacturer's website to learn how.

② Turn on Bluetooth on your PC if it's not on already. To do this, on the task-bar, select **action center**  > **Bluetooth**.

③ In action center, select **Connect** > the device name.



④ Follow any more instructions that might appear. Otherwise, you're done and connected.





EN

Your Bluetooth device and PC will usually automatically connect anytime the two devices are in range of each other with Bluetooth turned on.

To connect a Bluetooth mouse, or other device


- ① Turn on your device and make it discoverable.
- ② Select the Start  button, then select **Settings**  > **Devices** > **Bluetooth**.
- ③ Turn on **Bluetooth** > select the device > **Pair**.
- ④ Follow any more instructions if they appear.

Sign in with a Microsoft account

Select the Start  button, then select **Settings**  > **Accounts** > **Email & app accounts**.

Under Accounts used by other apps, select Add a Microsoft account.

Follow the prompts to add your Microsoft account. You may need to verify your identity by entering a confirmation code.



04





5 Start menu

Apps, settings, files—they can all be found on the Start menu. Just select the **Start**  button on the task-bar. Next, make it yours by pinning apps and programs, or moving and regrouping tiles. If you need more space, resize the Start menu.

6 Organize your apps

Pin apps to the Start menu to see live updates on what's happening in your world—such as new email, your next appointment, or the weekend weather. When you pin an app, it's added to the Start menu as a new tile.

Pin apps to Start

- ① Select the **Start**  button, then press and hold (or right-click) the app you want to pin.
- ② Select **Pin to Start**.



Once you pin a new app, resize it. Press and hold (or right-click) the app tile, select **Resize**, and then choose the tile size you want.





EN


Tip

Drag and drop apps from the apps list to pin them to the Start menu as tiles.

7 Group your apps

After you've pinned an app, move it into a group.

To create a new group of tiles, move an app's tile up or down until a group divider appears, and then release the tile. Move apps in or out of the group to organize your tiles for perfect productivity.




To give your new group a name, select the open space above your new group and type a name.

8 Action Center

Click in the lower right corner of the task-bar  to open the "Action Center", you can quickly open or close the tablet mode, rotation mode, flight mode, VPN, power-saving mode, the networking, Bluetooth, location, project and adjust brightness.

06





You no longer need to open action center to see how many notifications you have—the number on the action center icon shows you how many notifications are waiting for you. Other apps pinned to the task-bar can also show the number of notifications you've missed.





EN

TROUBLESHOOTING

Q1. The laptop doesn't power on.

- * Reboot your laptop after charging for more than 30 minutes.
- * Press the power button to check if the laptop is in the Sleep Mode.
- * Press and hold the power button for 10s to reboot it.

Q2. The laptop doesn't charge.

- * Make sure the USB cable is properly plugged into the charging port.
- * Try another compatible USB cable and adapter.

Q3. Error message occurs during the operation.

- * Uninstall the App with error message, then download and install again.

Q4. The laptop cannot connect to the Wifi.

- * Make sure the Wifi in your laptop is ON.
- * Make sure you input the correct password when connecting the Wifi.
- * Restart the router.
- * Make sure there is no filter setting or device connection limitation in the setting of the router.
- * Forget the current Wifi, reset the router and connect to the Wifi again.

Q5. The storage space of the laptop is not enough.

- * Delete the Apps you don't use.
- * Clear the cache of the Apps regularly.

08





* Install a memory card to expand the storage.

Q6. The screen is unresponsive.

* Check if the screen is dusty or greasy. If yes, please gently wipe the screen with a cloth to clean it.

Q7. Can the laptop support OTG function?

* Yes, but an extra OTG cable is required. You can connect the mouse or a USB drive through the cable then.

Brand : KUU

Model : YEPBOOK

System : Windows 11 operating system

CPU Brand : Intel N5095

Screen size : 15.6"

Screen scale : 16:9

Resolution : 1920*1080

Net play style : WIFI (2.4G/5G)

5150-5250MHz for indoor use only

Hot function : BT4.2





FCC Compliance Statement:

EN

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Specific Absorptiion Rate(SAR) information:

The FCC Statement of Exposure to RF and the SAR limit for the United States(FCC) is 1.6W/kg average for each gram of tissue. This device was tested for typical operations of use on the body.

This device was tested for typical operations 0mm from the body, and the highest SAR value reported under this standard during product certification is 0.375W/kg.

10



EN

Warnings:

This device complies with Industry Canada's licence-exempt RSSs

Operation is subject to the following two conditions:

- (1) This device may not cause interference and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.



Specific Absorptiton Rate(SAR) information:



The SAR limit of Canada(ISED) is 1.6W/kg averaged over one gram of tissue.

The highest SAR value reported under this standard during product certification for use at the body is 0.367 W/kg@1g(0mm Separation distance).

Taux d'absentéisme spécifique (SAR) Information:

La limite de Das (ISDE) au Canada est de 1,6 W / kg en moyenne par gramme de tissu. Lors de la certification du produit, la valeur SAR la plus élevée rapportée conformément à cette norme pour une utilisation sur la carrosserie est 0.367 W / kg@1g (distance de séparation de 0mm).

11

