

AnablepSecurity Wi-Fi Sensors are for home and office. This document will provide you setup instructions.

Power up the AnablepSecurity base unit using built-in AC wall adaptor. Power light will turn on blue. Use a laptop or phone, Go to settings > Wi-Fi and look for "AnablepSecurity" Wi-Fi network. Click and connect to this Wi-Fi Network.

Open a Web Browser and enter 192.168.4.1 in the URL to open an AnablepSecurity Sensor Setup page.

Here you will select your local Wi-Fi and Enter the Wi-Fi password.

Enter email address where you will receive welcome emails and notifications.

Enter the Sensor Name and click Connect so that AnablepSecurity Sensor connects to Internet..

Check for Welcome email from AnablepSecurity Team in your email box. Please follow the instructions on creating a cloud account and then signing on to the cloud.

On Cloud, you can monitor your AnablepSecurity Sensors. You can also change AnablepSecurity Sensor Settings.

If your local Wi-Fi settings change or you move the AnablepSecurity Sensor to a new location, please press WPS button for 10 seconds on the AnablepSecurity Sensor to update Wi-Fi Settings. You can follow the above steps again to setup AnablepSecurity Sensor again.

Please contact us if you are not able to resolve any issues.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This modular complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

Steadfast Technology LLC /ADS-BLEnRF1-ANT2.412 GHz - 2.462GHz: -0.5dBi