


AGE 14+

FBRUSHLESS FOLDING DRONE OPERATING MANUAL

无刷折叠无人机 使用说明书



*Please read this manual carefully before operation and keep it properly for future reference.

*请在飞行前仔细阅读说明书并妥善保管以便日后参考。


KNOW YOUR DRONE

认识你的无人机

The drone uses the 2.4G frequency, multiple-player can operate at the same time without interference.

The drone can be controlled by remote to achieve flying, flipping, fine tuning, one-key take off, one-key landing, speed control, headless mode, calibration, camera adjustment, emergency stop, light switch and other functions.

无人机采用2.4G频段，可多人同时操作而互不干扰。通过遥控器可操控无人机实现飞行、翻滚、微调、一键起飞、一键降落、速度、无头模式、校正，摄像头调节，急停，灯光开关等功能。



① Upper Casing
机壳上盖

② Lower Casing
机壳下盖

③ Propeller
风叶

④ Arm
机臂

⑤ Battery
电池

⑥ Motor
电机

⑦ Camera
摄像头

⑧ Bottom camera
底部摄像头

ACCESSORIES 配件表




DRONE x1
(Battery Included)
无人机 x1 (内含电池)




Remote Control x1
遥控器 x1



Mobile phone
holder x1
手机夹 x1




Backup Propellers A/Bx4
备用风叶 A/Bx4



Protective Guard x4 x1
防护架 x4



Screwdriver x1
十字螺丝刀 x1



USB Charger x1
USB充电器 x1



User Manual x1
说明书 x1



WIFI manual x1
WIFI说明书 x1


Notes 注意:

Please check the number of accessories carefully (as shown above). Please provide proof of purchase and contact the store for replacement if any missing parts.


请仔细清点各配件及数量（如配件表），如果发现不齐全，请提供购买凭证，及时联系销售商家补换货。

OPTIONAL ACCESSORIES LIST

可另购配件表




Propellers
风叶




Launch board
发射板




Upper Casing
机身上盖



Lower Casing
机身下盖



Battery
电池



Receiving board
接收板

Notes 注意:

If any of the above accessories are damaged during operation, you can contact the seller to purchase.

操作过程中，如有以上配件损坏，可自行联系卖家购买。

PRE-FLIGHT PREPARATION

飞行前准备

1. FLIGHT ENVIRONMENT 选择飞行环境



Indoor: Spacious spaces away from barriers, crowds or pets are preferred.

在室内飞行：请选择附近无障碍物、人群和宠物的开阔空间飞行。



Outdoor: Sunny, windless and breezy weathers are preferred.

在室外飞行：请选择晴朗无风的天气或微风的天气飞行。



Please keep the drone in sight during the flight and keep it away from barriers, high-tension cables, trees and people.

飞行时请保持飞行器在视线范围之内，并远离障碍物、高压线、树木、人群等。



Do not fly in extreme environment, such as hotness, coldness, strong wind or heavy rain.

切勿在极端恶劣的环境下飞行，如过冷、过热、强风、暴雨等。

2. OPEN THE WINGS 打开机翼

OPENING STEPS 打开机翼顺序:



① Open the front arm(close to camera)

先打开前机臂。(靠摄像头一侧)


② Open the back arm

Fold the back arm firstly and then the front arm when folding.


再打开后机臂,折叠时顺序相反。



3. ASSEMBLING PROTECTIVE GUARD 防护架安装




① Align the protective guard under the motor and install it.
将保护架对准电机下方安装上去。




② Press firmly on the arrow position.
安装后按箭头位置用力按到位。

4. ASSEMBLING PROPELLERS 风叶安装





① Correspond the Propellers with the hex nuts of the crankshaft.
(The arm identification is consistent with the Propellers identification)
将风叶对准电机轴安装上去。(机臂标识与风叶标识要一致)
② Tighten the screws clockwise.
顺时针拧紧螺丝。




5. BATTERY CHARGING FOR DRONE

机身充电方法



A. Remove the lithium battery from the bottom of the drone.

按下箭头指示的位置，把电池箱往外拉出，取出电池。



B. The USB charging cable connects the battery to the USB power port.

USB充电线连接电池与USB充电接口

Notes 注意：

When charging, you should choose input: 100–240V–50~60hz, output 5V–2A. Or use a charging adapter below 5V–2A to avoid damage to the battery. LED lights on when charging and red light turn off when full charging completes. Charging time is about 150 minutes.

充电时应选择输入:100–240V–50~60hz,输出为5V–2A。或者5V–2A以下充电适配器进行电线，避免对电池造成损坏。充电时LED灯亮，充电结束时LED灯灭，充电时间约为2.5小时左右。

⚠ BATTERY INSTRUCTIONS 电池使用注意

- There is a certain risk when using lithium battery. It may cause fire, body injury or property loss. Users must be aware of the risks and take full responsibility of using battery improperly.

使用锂电池有一定风险，可能对人和财产造成重大损失，请谨慎使用，自行承担所有相关责任。

- If battery leakage occurs, please avoid contacting your eyes or skin with electrolyte. Once it happens, please wash your eyes with clean water and seek medical care immediately.

如果电池发生泄漏，请避免液体与皮肤和眼睛接触。若接触到皮肤，请立即以香皂和清水清洗。若接触到眼睛，请立即以大量冷水冲洗并立即就医。

- Please remove the plug immediately if you sense any peculiar smell, noise or smog.

如果充电器发出可疑异味、噪音或者烟雾，请立即拔除电源。

Battery Charging 充电

- Please use the charger from original factory to ensure your safe usage.

请使用原厂配送的专用充电器充电，严禁使用破损或其他品牌充电器。

- Do not charge dilatant or outworn battery.

请勿对膨胀、泄漏或破损的电池充电。

- Do not over charge battery. Please unplug the charger once fully charged.

请勿对电池过度充电。当电池完全充满后，请拔出充电器。

- Do not charge the battery next to inflammables, such as carpet, timber floor or wood furniture or on the surface of electro-conductive objects.

Please always keep an eye on the battery when charging.

请勿在靠近易燃物（地毯、木地板、实木家具等）或导电的物体表面上充电。充电时请保持电池在视线范围内。

- Do not charge battery which not cool down yet.

切勿在使用产品后电池尚热时立即充电。

- The charging temperature should be between 0°C to 40°C.

电池充电的温度应该介于0°C到40°C之间。


Battery Recycling 回收

- Do not dispose the battery as daily rubbish. Please familiarize yourself with the local garbage disposal method and dispose it according to the special requirement.


此设备由电子元件和电池构成。关于电子电器垃圾，请按照当地垃圾处理要求，进行特殊处理。

KNOW YOUR REMOTE CONTROL 认识你的遥控器

1. Parts of remote control 遥控器各部位名称



2. Remote control handle mobile phone holder instructions: 遥控器手把/手机架使用说明:



Mobile phone holder: Put the mobile phone holder into the remote control and stretch it upwards to place the mobile phone


Remote control handle: Pull the bottom handle of the remote control downward from the middle position and rotate it until it is in place.

手机架:将手机架装入遥控器, 向上拉伸可放置手机

遥控器手把:将遥控器底部手把从中间位置向下拉, 旋转至到位。

LITHIUM BATTERY INSTRUCTION 电池安装及充电方法

Remote control battery installation 遥控器电池的安装



Open the battery cover and insert the 2 AA batteries correctly according to the electrode instructions.(Batteries not included)
打开电池盖，依照电极指示正确放入2粒AA电池。（电池需另购）

Notes 注意：


1. Make sure the battery are loaded correctly according to the polarity indications on the battery compartment.
2. Please do not mix old and new batteries together.
3. Please do not mix different types of batteries together.

1. 装入电池时必须认准电池正负极，且不能装反。
2. 请勿混合使用新旧电池。
3. 请勿混合使用不同类型的电池。

SIGNAL CONNECTION OF TRANSMITTER AND RECEIVER 遥控器与无人机对频

- ① Switch on the drone power, place the drone on a horizontal plane, then open the remote control, both of their lights flash quickly at this time.
开启机身电源后，将无人机放置在水平面，再打开遥控器，此时遥控器指示灯和无人机的LED灯闪烁。
- ② Push the throttle joystick to the top, hear a "drip", and the remote light is fast flashing.then pull the joystick to the lowest point, another "drip" will be heard, the lights of the remote and drone change to steady on, that means the calibration is finished.

将油门杆推到顶部，听到“滴”一声，遥控器指示灯快闪，再将油门杆推到最低点，再次听到“滴”一声，遥控器指示灯常亮，飞行器指示灯常亮，则完成对频。



TRANSMITTER CALIBRATION 遥控器校准


Apply transmitter calibration when the drone fails to take off vertically.

Standard version/Obstacle avoidance version

Press the "One button calibration" button, When the lights of drone are on and then start flashing and keep on again, the calibration is complete. the drone must be placed on a horizontal surface in a steady state when the calibration is conducted.

若无人机起飞不能垂直上升，可对无人机校正。

按下“一键校正”键，此时无人机指示灯快速闪烁，待指示灯常亮，校正完成。在执行校正命令时，必须在与水平线平行的平稳状态下执行，否则会影响校正效果。



TRANSMITTER CALIBRATION 灯光控制

When the drone calibration is completed, the light will stay on. Press the light control button to switch to different lighting effects.

无人机校准完成时灯光长亮，按下灯控按键可切换不同的灯光效果。

START YOUR FLIGHT

开始飞行

1. One-key Ascend

一键起飞

Press the "One-key Ascend" button, the drone blades rotate and automatically fly to a height of 1.5 meters.

按下“一键起飞”按键，无人机风叶转动，自动飞到1.5米的高度。

2. Basic Flight


基本飞行

Use the left joystick to control the flight altitude and turn left/right, and the right joystick to control the forward, backward, left and right side flight directions.

左操纵杆控制飞行高度与左右转方向，右操纵杆控制前进、后退以及左右侧飞方向。


Left joystick

左操纵杆



Right joystick

右操纵杆





Flips & Rolls

翻滚

When the drone go to 1 meter above, press flipping button and move the right-joystick to the left or right side, it will flip to the corresponding direction.

无人机飞到1米以上高度后，点击翻滚键并将右操纵杆（方向舵）向左或右移动，可实现往此方向的翻滚动作。

Right joystick 右操纵杆



Headless Mode

无头模式

The flight direction of drone is subjected to the direction of remote control.

1. When drone adjust the frequency, the drone is default as common mode. Then the indication light of drone is normally on. When you press the headless function key of remote control, the remote control beeps once and enters headless state. When you press the headless function key again, you listen to a long beep sound and the drone exits the headless mode.
2. In the headless state, operator doesn't need to identify the direction of nose, but control the drone according to the operating lever of remote control.

当无人机对完频后，无人机默认为普通模式，此时无人机的指示灯为长亮状态，当按下遥控器上无头功能键后，遥控器发出“滴”一声表示进入无头状态，再按下无头功能键后听到“滴”长声响为退出无头状态。

在无头状态下，操控者无需去辨认无人机的机头方向，只需根据遥控器的操作杆方向来控制飞行器。

Hover



悬停

When you release the left joystick (throttle) after the ascent/descent action, the drone will hover at a certain height.

用左操纵杆让无人机上升后，松开左操纵杆，无人机仍会悬停在松开操纵杆时的高度。

Left joystick

左操纵杆





Camera angle adjustment

摄像头角度调节

During the flight of the drone, the camera angle can be adjusted through the camera adjustment button.

(This function is only available in the camera ESC version)

无人机飞行过程中可通过摄像头调节按键来调节摄像头的角度。（摄像头电调版本才有此功能）



FAQ

遇到问题不用慌

PROBLEMS 问题	CAUSES 原因	SOLUTIONS 处理方法
Control failure 遥控器失灵	Not connect with the quadcopter battery. 无人机电池没连接	Connect the quadcopter battery in right way. 把无人机电池按正确方向连接
	Too strong wind force. 风力太大	Do not fly in windy days. The performance and the control of the quadcopter will be affected by the strong winds. 切勿在有风的情况下飞行，有风会对无人机造成局限，或会妨碍你的控制飞行
Fail to ascend 无人机不能升高	The rotation speed of main blades is too slow. 旋翼转动速度太慢	Push up the throttle joystick. 动力操纵杆向上推
	The battery of the quadrocopter is not fully charged. 无人机未完成充电	Please full charge the quadcopter. 为无人机完全充电
Landing too soon 无人机很快跌落	The throttle stick is pulled down too fast. 过快将动力操纵杆回拉	Pull down the throttle stick slowly to perform a smooth landing. 慢慢的回拉动力操纵杆让无人机慢慢着陆
Out of control 失控	Beyond the effective controlling distance. 超出有效遥控距离	Ensure operation within the controllable distance: remote control of 100 meters and WiFi control of 40–50 meters. 确保遥控距离在100m内，WiFi操控在40–50m内

Federal Communications Commission Notice

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.