

WIFI CAMERA

User Manual

Before using this product, please read this manual carefully and keep it for future reference.

Quick Start Guide

①Download the App

You can connect to notebook or personal computer via USB port available in windows PC for camera surveillance. Or, Search App in the App Store, download to install, then register to login.

②Power on the device

Power on the device and the device will give out sound in around 30s. If the sound can not be heard, please insert the thimble into the "reset" hole and long press it until the device emits the voice tone.

In order to ensure that the pictures and records are stable, please use the bracket and fix it on a desktop or other stable surface and keep the USB cable connected.

③Add the device

1. Connect the device to WiFi (If the device does not support 5GHz WiFi, please make sure the connected WiFi is 2.4GHz)
2. Go to 'Device' in the app, click '+', Then add the camera according to the prompt

The App interface may be upgraded occasionally to improve user experience.

Device sharing

1. Invite your friends to download and install the App, and register to log in.
2. The device owner can click the 'share' icon to choose either way to share.
3. You can follow the App instruction to complete the share

monitoring

On the monitoring interface of the app, you can check the camera monitoring images in real time and control camera monitoring, interception and recording functions.

playback

After you install a TF card (support fat32/exFat), the camera will automatically record videos when the camera is in working condition. You can check the recorded videos in the "local playback" function of the app.

Trouble Shooting

Q:The camera can not connect with WiFi?

A:Please double check whether the WiFi password is correct.

Please confirm whether the device supports 5GHz WiFi, otherwise, please make sure the connected WiFi is 2.4GHz;

The router can not have WiFi restrictions such as enabling AP isolation, preventing Wi-Fi squatting etc. Some phones need to get mobile phone GPS permission and turn on GPS to get a WiFi list.

Q:Device is offline in device list?

A:Check whether the device network is good or not.

If there is TF card inserted, please unplug the TF card, reset the device and router. Check whether the device is online or not.

If the problem still exists, please reset the device (Insert the thimble into the "reset" hole and long press for 5s to 10s). Please re-add the device.

After that, check the device firmware and App version and upgrade them to the latest version.

Q:How to do if the device is offline after changing a router or WiFi

password?

A:The device keeps the original password. If password is changed and can not match with the original password, the device is not able to be online then. Under this situation, please reset the device (Insert the thimble into the "reset" hole and long press for 5s to 10s) and re-add according to the App tips.

Q:The playback video can not be watched?

A:Unplug the TF card and re-insert. Please check whether the record mode is open.

If the record mode is open but no video is made, please go to "Settings", enter "Record settings", disable "Record switch", and format the TF card. If the video can not be watched still after formatting TF card, please replace a new TF card to try.

For more questions, please refer to "Help and feedback" in App.

Note

- Please confirm whether the device supports 5GHz WiFi, otherwise, make sure that the WiFi connected to the mobile phone is 2.4GHz;
- The device supports 128G card storage at maximum and the TF card should be formatted with FAT32/exFat format.
- The device uses loop record technique, when TF card is full, the camera will cover the earliest files automatically to save new videos.
- Please do not install the product in a harsh environment. The product may be damaged if exposed to high temperatures, high humidity, dust and smoke etc.
- The App and the device firmware will be updated occasionally. Please update when the software notifies you that an update is available.
- The device will be automatically bound with the account after connecting to network. Before binding a new account, please unbind the device with the first account.
- Yoosee CMS

Customer Service

For users who need technical support, please contact:

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

NOTE: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.