

— Operation:

1. As shown in Figure 1, open the back cover of the remote control and install two 1.5 V "AAA" un rechargeable batteries.

Schematic diagram of battery installation

(Figure 1)

When in use, the counterbalance hammer at the bottom of the kayak must be opened (Figure 2) before the kayak is put into the water. The lights on the boat flickered. Turn on the remote control power switch, the lights on the boat by flickering into a gradual light, this time the remote control and kayak frequency successfully. At this time, power remote control kayak, hand do not put near the propeller, and make sure that there are no obstacles around the propeller, to prevent high-speed rotation of the propeller injury.

(Figure 2)

If stop operation, please take the remote control kayak out of the water, dry it with a cloth and put it away. As shown in Figure 3, when the two contact points of the bottom of the remote control kayak leave the water, the remote control kayak is in a power-off state, and the propeller of the remote control kayak stops spinning.


(Figure 3)

2. Remote control button function:

When the remote control switch button is pressed, the remote control switch is turned on. When the remote control rod is pushed forward/backward, the remote control kayak can go forward/backward. Push the remote to turn left/right. Remote control kayak can turn left/right, front button for paddle switch.

(Figure 4)

3. Paddle mode
When the paddle switch is pressed, the kayak's rower will automatically paddle forward. At this time, the remote control can be used to turn left/right to achieve the kayak's turn. (figure 4)



Warning Sign:
When the remote control switch button is pressed, the remote control switch is turned on. When the remote control rod is pushed forward/backward, the remote control kayak can go forward/backward. Push the remote to turn left/right. Remote control kayak can turn left/right, front button for paddle switch.

FCC Warning Statement
Changers or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.