


# Quick Start Guide


## 5G CPE C150

### Product overview



1. LED indicator:
2. DC Power Port
3. LAN port
4. TypeC Port
5. Sim slot
6. Reset button
7. WPS button
8. Power button

## Setup



1. Make sure you use the correct SIM card: Nano- SIM (4FF).
2. Insert the SIM card gently into the SIM card slot until it clicks.  
Remark:
  - If you want to remove the SIM card, please gently press the SIM card in until it clicks, then the card will pop out automatically.
  - Please do not insert or remove SIM card when the CPE is working. It may affect performance and damage the SIM card.
3. Connect the power adapter to the CPE.
4. Press the Power button more than 3 seconds, the indicator light and flashing, the CPE starts to initialize.
5. When the indicator stop flashing, the CPE complete the initialization and start to work.

## Indicator Description

|  |                              |                      |
|--|------------------------------|----------------------|
| Signal strength indicator                    | Strong                       | Green                |
|  | Weak                         | Blue                 |
|  | No Signal                    | Red                  |
| 5G network status                            | 5G Network is connected.     | Green                |
|  | 5G Network is not connected. | Off                  |
| Wi-Fi Status                                 | Wi-Fi is working.            | Green                |
|  | Wi-Fi is off.                | Off                  |
|  | WPS Function is working.     | Green light flashing |
| LAN Port status                              | LAN port is working.         | Green                |
|  | LAN port is not connected.   | Off                  |
| Mode to indicate Power status or FOTA status | The device is working.       | Green                |
|  | The device is off.           | Off                  |
|  | Battery is working           | Blue                 |
|  | Battery is charging          | Blue light flashing  |
|  | Battery capacity is low      | Red                  |

|  |                           |                      |
|--|---------------------------|----------------------|
|  | FOTA function is working. | Green light flashing |
|--|---------------------------|----------------------|

## Button Introduce

|              |                                 |                              |
|--------------|---------------------------------|------------------------------|
| Power Button | Press the button for 3 seconds  | Turn on/off the device       |
| Reset Button | Press the button for 3 seconds. | The device starts to reset.  |
| WPS Button   | Press the button for 3 seconds. | The WPS function is working. |

## Connecting to CPE

### ● Connect by Wi-Fi

Search the CPE's SSID and connect your mobile phone or computer to CPE's Wi-Fi (Please look at the label on the bottom of the CPE for Wi-Fi's SSID and Password).

### ● Connect by Ethernet

Connecting your computer to CPE by ethernet cable and then your computer can access the Internet .

## WebUI Configuration

1. Connect your mobile phone or computer to CPE.
2. Enter "192.168.8.1" in your browser and login WebUI by the default username / password "admin / admin".
3. Then you can change the settings on WebUI.

## FAQS

### How do I restore factory settings?

When the device is working, press the reset button for 3 seconds until the indicator starts to blink. About 60 seconds later the indicator stops blink that means device complete the reset.

### What should I do if I forgot the Wi-Fi password or the login password?

Restore the device and use the default Wi-Fi password and login password to try again.

### What should I do if the device cannot connect to the Internet ?

- Please check if the SIM card is inserted.
- Please check if your SIM card is out of service.
- Please check there is any wrong about network connection steps.

What should I do if the device cannot connect to the 5G Network?

- Please check if the SIM card has got 5G service.
- Please check there is covered by 5G signal.

#### **How can I know the device has connected to 5G Network or not?**

If the 5G signal indicator is green that means 5G Network is connected.

#### **What should I do if I cannot access the device's WebUI?**

- Ensure your computer is connected to the device through an ethernet cable or Wi-Fi.
- Ensure your computer is set to obtain an IP address and DNS server address automatically.
- Restart your browser, or try another browser.
- If the problem persists, restore the device to its factory settings.

## **Safety Information**

### Operating environment

- Ideal operating temperatures are 0 °C to 40°C. Ideal storage temperatures are -20°C to + 60°C.
- Keep the device away from heat and fire.

### **FCC Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

### **FCC Warning**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with

the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.