

H A T C H



## User Manual - Touchpoint

**UM-803-34-000**

---

Version	Date	Description
A	4 <sup>th</sup> March 2024	Initial Release

## User Manual Outline

The following instructions contain important safety information to prevent damage and misuse of the product. Read thoroughly before use.

---

# H A T C H

## Table of Contents

User Manual Outline.....	1
1. Introduction .....	3
1.1 Welcome .....	3
1.2 Model Details .....	3
1.3 Installation .....	3
2. Product Features, Controls, Instructions for use, and Maintenance .....	4
2.1 Product Specifications.....	4
2.2 Controls and Features.....	4
2.3 Instructions for Use .....	5
2.4 Software Updates.....	6
2.5 Maintenance.....	6
2.6 Troubleshooting .....	6
3. Regulatory Compliance and Product Warnings .....	6

# H A T C H

## 1. Introduction

### 1.1 Welcome

The Fox Touchpoint controls key elements of a vehicle's metrics such as suspension. The Touchpoint is a sophisticated controller that can be used to control vehicle suspension on the fly. The Touchpoint forms the interface between the vehicle and the human. The Touchpoint physical interface communicates with the Fox ECU which is fitted to a vehicle. The Touchpoint does not communicate directly to the vehicle, only to the ECU.

### 1.2 Model Details

This user manual covers the following models:

Model	Description
803-34-000	Fox Touchpoint, Wired Installation

### 1.3 Installation

The 803-34-000 Touchpoint product will be pre-installed by Fox or its network of installers and distributors in a user's cockpit similar to the image below. Device connection is via the cradle mounted inside the vehicle and device communication is via a connection over USB-c (Through CAN).



# H A T C H


## 2. Product Features, Controls, Instructions for use, and Maintenance

### 2.1 Product Specifications

Input Power: 12VDC

Weight: ~150g

Ingress Protection: IP65 (Water & Dust Resistant)



### 2.2 Controls and Features

- Paddle levers (A.)
- AUX button (B.)
- Trail Modes (C.)
- Suspension Feel Modes (D.)



## 2.3 Instructions for Use

- When the device is powered suspension modes can be changed.

Powered device.



- Using the left paddle moving either up or down will change the trail condition mode.
- Using the right paddle moving either up or down will change the suspension feel modes.

Left paddle (A.) and right paddle (B.) used for mode switching.



- To turn LEDs off hold AUX button for 2 seconds.
- To turn LEDs back on either press the AUX button or use either paddle.

AUX button (C.) used to turn LEDs off.

C.



## 2.4 Software Updates

OTA automatic updates.

## 2.5 Maintenance

Clean the Touchpoint regularly with a wipe or microfiber cloth.

## 2.6 Troubleshooting

Please contact RIDE FOX Truck and Off-Road service at [orservice@ridefox.com](mailto:orservice@ridefox.com) for any issues that arise during operation.

# 3. Regulatory Compliance and Product Warnings

This product is ROHS and REACH compliant.

### FCC Compliance Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm

# H A T C H

between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

#### ISED Compliance Statement:

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

#### IC Radiation Exposure Statement:

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Cet équipement est conforme aux limites d'exposition aux radiations IC CNR-102 établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps. Cet émetteur ne doit pas être colocalisé ou fonctionner en conjonction avec une autre antenne ou un autre émetteur.