

FCC Warning Statement


Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines. This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.



3. Set up work mode

Log in Web manage page
Use a browser and visit <http://192.168.188.253> and input password admin

4. Wireless testing

Set up work mode
Enter setup page, click Network-WAN, click apply after choose work mode.
DHCP: Your router IP will be automatically configured
Static IP: Your router IP will be fixed as your setup IP.
PPPoE: ADSL to connect internet

Wi-Fi setup
Enter setup page to set up Wi-Fi. Please note that Wi-Fi password length at least 8 digits. After set up, please click apply to save settings

Check the status of the wireless network connection: signal quality, speed, Bytes sent and received. Click on Details, check if the IP address and DNS server address etc. obtained correctly, confirm that the device is working properly.

5. FAQs

| Solutions | Questions |
|---|--|
| Forget the login username and password | 1. Check whether the IP address and the AP are on the same segment. Check whether the IP address is manually configured to other segment. 2. Restore the wireless AP to the factory settings, and try to connect again. 3. Make sure that the IP 192.168.188.253 is not occupied by other devices. 4. Check the computer of the network cable. We recommend using unshielded twisted pair as the network cable. |
| Cannot log in to the wireless management page through web | 1. Connect device with cables, enter the web management page. Click wireless setting and basic setting. Enter the password again in the secret key. 2. Restore to the factory settings, there is no password by default. |
| Forget the password of the wireless network. | 1. Check whether the DHCP server is enabled on the device. 2. In AP mode, check whether the upper-layer network connection is normal or whether the DHCP service on the LAN is enabled. |
| Cannot acquire IP address. | 1. Check whether the DHCP server is enabled on the device. 2. In AP mode, check whether the upper-layer network connection is normal or whether the DHCP service on the LAN is enabled. |
| Once the setup is complete, the connection is also successful but the wireless display is 150M instead of 300M. | It is necessary to transmit on 40MHz channel bandwidth to reach 300M speed, and the router and terminal network card must support 40MHz. The 2.4G band of the wireless audit route works at 20MHz channel bandwidth by default. You can adjust the device configuration on the wireless service platform and change the channel bandwidth to 20/40MHz or 40MHz to achieve 300M wireless transmission rate. |