



ENGLISH DESCRIPTION ON THE BACK

iCam365

Quick Operation Manual

WIFI Camera


20210709




Scan the QR code to
download "iCam365" APP



A Connect the device




Download the app
Use the "Scan" function of your mobile phone to scan the QR code,
download and install the "iCam365" APP



Connect power
Connect the device to the power supply and wait for about 1 minute


B Add device




01.Log in




02.Add device




03.Scan the QR code
of the fuselage




04.Waiting for a
utomatic recognition




05.Select the WiFi to connect to
and enter the password




06.Waiting to configure
the network




09.The addition is complete,
the device is named




The device will appear
on your homepage




The device will appear
on your homepage




The device will appear
on your homepage




The device will appear
on your homepage




The device will appear
on your homepage




The device will appear
on your homepage




The device will appear
on your homepage




The device will appear
on your homepage




The device will appear
on your homepage




The device will appear
on your homepage




The device will appear
on your homepage



The device will appear
on your homepage



The device will appear
on your homepage



C Function Description

Alarm message

Add device

Live and playback







Settings

Share the device

More features

Intelligent Recognition

Cloud recording



D Common problem

Problems	Solution
What should I do if the device is unsuccessfully added?	Check whether the WIFI password is correct, and the network can be connected correctly, then RESET the camera, and add it again after completion.
How to download video?	Click the "Record Screen" button during playback, and click the red button after recording, and the video file will be saved to the phone;
What if the display device is offline?	First confirm whether the power supply and network are normal, and there is no problem before powering off the camera and restarting it. If the connection is still disconnected
The memory card is full, what should I do?	No manual processing is required. When the remaining memory card capacity is less than or equal to 500M, the camera will automatically overwrite the oldest video file.
The memory card shows no memory card or abnormal	1. The camera does not support hot swapping. When inserting a memory card, it needs to be powered off. Please restart the camera.2. The memory card is still not recognized after restarting the camera, please replace with a new card and test again.3. If the new card is still not recognized, the card slot may be damaged or the cable is faulty. Contact the supplier to replace the device.
What should I do if I cannot receive the warning message?	Confirm whether the system has turned off the message push permission of iCam365. If it is turned off, please turn on the "message notification" permission in the phone settings and check whether the message push is turned off in the device settings. Alarm messages are stored for up to 7 days

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one

or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.