


GEARWRENCH

Programmable Universal Tire-Pressure Sensor (With Adjustable Valve Stem)



GWTPMSM Universal Tire-Pressure Sensor User Manual (Metal Valve / Clamp-in Style)

Disclaimer

Please read this manual carefully before installing GWTPMSM universal tire sensor (hereinafter referred to as GWTPMSM). For safety reasons, all the installation and maintenance operations should be carried out by trained professionals, with the guidance of vehicle manufacturer. Tire valves are vehicle-safety related component and incorrect installations may cause malfunctions for tire valves or TPMS1 sensors. Shenzhen Xtooltech Intelligent Co., Ltd. (hereinafter referred to as "Xtooltech") does not assume any liability in case of incorrect installation of the product. Pictures illustrated here are for reference only and this user manual is subject to change without prior notice.


Warranty

GWTPMSM sensor is guaranteed to be free from material or manufacturing defects for a period of 24 months or 40,000km (25,000 miles), whichever comes first. In case of defections caused by material or workmanship, Xtooltech will repair or replace (according to the situations) the product or parts for free by inspecting the proof of purchase.

Xtooltech are not responsible for defects caused in the following circumstances:

- Incorrect installation;
- Irregular usage;
- Damage caused by collision or tire damage;
- Exceeding specific using limits of the product.

Exploded View



Specifications

Sensor Weight (valve not included)	approx. 13 g
Dimensions (valve not included)	46.1 x 25 x 16.2mm (1.81" x 0.98" x 0.64")
Max. Pressure	900 kPa (9.0 bar or 130.5 psi)
Max. Speed	240 km/h (150mph)

Installation Guide

⚠ Warning


Every time the tire been repaired, dismantled, or uninstalling & replacing GWTPMSM sensors, make sure that the original rubber washer, screws, nuts and valve stems from GWTPMSM are used in order to keep good air tightness. If the tire or wheel is damaged externally, the GWTPMSM sensor must be replaced.

- The torque of the valve tightening screw should be 4Nm (2.95 lb· ft).

1. Deflate & Uninstall Tire

Take off the valve cap and the valve core to deflate the tire. Then, use tools (or machines) to uninstall the tire from the rim.

*In case of replacing the sensor only, deflate the tires, pry up the tire near valve stem until the sensor is exposed. Do not break the tire bead near the valve stem, or the original sensor may get damaged.




2. Uninstall Sensor

Take off the valve nut, washer and screw from the valve stem.


Then, take the sensor assembly out from the rim.

* Here shows the process of uninstalling GWTPMSM sensor. If you have problems when uninstalling other sensors, please check the repair manual or installation guide for uninstalling steps.



3. Install GWTPMSM Sensor

1. Use the screw to assembly the valve core and the GWTPMSM sensor tightly.
2. Uninstall the valve nut, washer and valve cap.
3. Adjust the angle of the sensor, then insert the valve core inside the valve hole, and make sure that the GWTPMSM sensor is inside the rim.
4. Install the valve nut and washer back to the valve core.
5. Lock the nut with 4Nm (2.95 lb· ft) of torque.
6. Install the tire back, inflate the tire to standard tire pressure (see vehicle nameplate) and install the valve cap.



FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

The use distance is not more than 5mm.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

The use distance is not more than 5mm.

IC Warning

This device complies with Innovation, Science and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- This device may not cause interference, and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil est conforme aux normes RSS sans licence d'innovation, sciences et développement économique Canada. Les opérations sont soumises aux deux conditions suivantes:

- (1) Cet appareil ne peut pas causer d'interférences, et
- (2) Cet appareil doit accepter toute interférence, y compris celles qui pourraient entraîner un fonctionnement accidentel de l'appareil.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Tout changement ou modification non expressément approuvé par la partie responsable de la réglementation de l'OCDE peut faire perdre à l'utilisateur le droit d'utiliser l'appareil.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Remarque: cet appareil a été testé pour répondre aux limites des appareils numériques de classe B conformément à la partie 15 des règles de la Federal Communications Commission des États - Unis. Ces limites sont conçues pour fournir une protection raisonnable contre les interférences nuisibles dans les installations résidentielles. L'appareil génère de l'énergie RF utilisée et rayonne, ce qui peut causer des interférences nocives pour les communications radio s'il n'est pas installé et utilisé conformément aux instructions. Cependant, aucun

Garantie contre les interférences dans une installation spécifique. Si l'appareil cause des interférences nuisibles à la réception de la radio ou de la télévision, qui peuvent être déterminées en éteignant et en allumant l'appareil, l'utilisateur est encouragé à tenter de corriger les interférences par une ou plusieurs des mesures suivantes:

- redirection ou repositionnement de l'antenne de réception.
- augmenter l'espacement entre l'appareil et le récepteur.
- Connecter l'appareil à une prise sur un circuit différent de celui auquel le récepteur est connecté.
- consultez votre revendeur ou un technicien radio / tv expérimenté pour obtenir de l'aide.

RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Avertissement RF pour les appareils portables:

L'appareil a été évalué pour répondre aux exigences générales d'exposition aux radiofréquences. Équipement Peut être utilisé sans restriction dans des conditions d'exposition portables.