

Languages



ICE TAG 1.0

MANUEL D'UTILISATION


USER MANUAL

NOTES

- The company reserves the right to modify the contents of this manual without any further notification. It is normal that some functions may vary in certain versions of software.
- This product has an IP65 waterproof rating, but it is not suitable for deep sea diving. Hot water, tea and corrosive liquids could destroy the ICE tag, so damage by these liquids will not be covered by the product warranty and free maintenance services.
- Before you use the product, you need to connect to the APP to set your personal information.
- Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.
- Apple, Apple Find My, Apple Watch, Find My, iPad, iPad, iPadOS, Mac, MacOS and WatchOS are trademarks of Apple Inc. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

IMPORTANT TIPS

When pairing a device with the «Find My» APP, the phone will link to Apple server. Pairing may fail because of network problems. The following action is recommended: Change the phone's network, disconnect Bluetooth connection and reconnect.



1. GETTING STARTED

a. Power ON

Pull the plastic tab to enable battery contact, it should beep once indicating it is powered on.

b. Check for upgrade

To better use «Apple Find My» APP to locate your item(s), please upgrade your iOS or iPad OS to the latest version.



This device can only be used on iOS 14.5 or later version iPhone, or iPad OS 14.5 or later version iPad.

2. ADD YOUR ITEM DEVICE

a. APP

- Download the Find My APP on your supported iPhone or iPad.
- Start the APP, Open Find My APP on your supported iPhone or iPad.

b. Pairing mode

Press the device's function button once, you will hear the beeping sound indicating device entering pairing mode. The duration of pairing mode is 1 minute. Press again the function button to re-enter pairing mode.



c. Items



Select the "Items" tab then tap the "Add Item" tab.

d. Add new items



Tap "Other Supported Item".


e. Connect



- Make sure the ICE tag is close to your iPhone.
- Find My APP enter searching mode, and when you see the "ICE tag 1.0" pop up, click "Connect".
- Follow the guidance on screen and input device name and select the emoji, then click "Continue".
- Then the item is linked to your Apple ID, then click "Agree".
- Click "Finish", your device will beep twice indicating setting finished.

3. HOW TO REPLACE THE BATTERY

- Use the provided pick to insert into the hole with «OPEN» indicated at the back. Push slightly inward and the back cover will be opened accordingly. No need to twist left and right to open.
- Replace the battery with a new CR2032 battery. (Positive pole upward).
- Carefully close the item device.



4. UNWANTED TRACKING DETECTION

If the item separated from its owner is seen moving with you over time, you'll be notified in one of two ways. These features were created specifically to discourage people from trying to track you without your knowledge.

1. If you have an iPhone, iPad, or iPod touch, Find My will send a notification to your Apple device. This feature is available on iOS or iPadOS 14.5 or later. To receive alerts, make sure that you:
 - Go to Settings > Privacy & Security > Location Services, and turn Location Services on.
 - Go to Settings > Privacy & Security > Location Services > System Services. Turn Find My iPhone on.
 - Go to Settings > Privacy & Security > Location Services > System Services. Turn Significant Locations on to be notified when you arrive at a significant location, such as your home.
 - Go to Settings > Bluetooth, and turn Bluetooth on.
 - Go to the Find My app, tap the Me tab, and turn Tracking Notifications on.
 - Turn off airplane mode. If your device is in airplane mode, you won't receive tracking notifications.
2. The item that isn't with its owner for a period of time will emit a sound when it's moved.

5. LOCATE YOUR ITEM


- Open the Find My APP and select "Items" and tap your item to enter Find My App interface.
- Tap "Play Sound" to make your device beep when it is nearby and tap "Stop Sound" to stop the beeps once you find your item.
- Last known location will appear on the map as emoji you choose during setup and tap "Directions" to navigate to the last known location.



6. FIND ITEM WHEN OUT OF RANGE

- Enable the "Notify When Left Behind" toggle, you will receive a notification when you leave your item device behind and it is no longer in range of your device.
- Enable the "Notify When Found" toggle, when your item location is seen by another Find My enabled device, you will receive a notification of its updated location.

 "Notify When Found" can only be active when your item device is out of range.



7. WHEN YOUR ITEM IS LOST

When you lost the item, go to Lost Mode in Find My APP and tap «Enable». Tab «Continue» then you can enter your phone number or email address and tap "Next". You may enter a message that will be shared with the person that finds your items. Tap "Activate" to enable "Lost Mode".

 When "Lost Mode" is enabled, "Notifications When Found" is automatically enabled and your device is locked and cannot be paired to a new device.

8. REMOVE ICE TAG IN FIND MY APP

- Ensure "Lost Mode" is disabled, tap the corresponding emoji to choose the item and tap "Remove Item", a reminder will pop up, tap "Remove" to confirm.

9. HOW TO PAIR ICE TAG TO A NEW PHONE FROM CURRENT PHONE

- When the device is connected to your iPhone, you need to «Remove Item» (pt 8 above) at first. Put the ICE tag close to the phone, choose «Remove Item» (follow pt 8 above). You will hear a beep sound. Then your device is ready to pair with a new phone.

- If the ICE tag is not close to your current phone during «Remove Item», reset the tag by long press the function button till hearing a «beep beep»sound, rapidly press 2 times and long press the function button till you hear «beep beep» sound. Reset is done and the tag is ready to pair to a new phone.

 One tag can only be connected to one Apple ID.

10. WARRANTY

Each ICE tag comes with a **2 YEARS LOCAL WARRANTY** against defects in materials and workmanship. This warranty covers all parts except the battery and the silicone band.

The following causes of defects are not covered by the free warranty service:

- Personal assembly or disassembly.
- Damage caused by the ICE tag being dropped during use.
- Any man-made damage or damage through the fault of a third party, improper use (such as: water in the ICE tag, shattering due to external forces, scratching during use etc.)

Please provide the warranty card with all details filled in when you request aftersales services.

Please contact dealers directly for warranty services.

This limited warranty is void if the defect is discovered to be caused by abuse or tampering with the ICE tag.

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



Scan QR code to know more
about Find My



Scannez le code QR pour en
savoir plus sur Find My

WWW.ICE-WATCH.COM