


Manual

1. Getting Started

To prevent accidental shutdowns that could result in the device being unable to locate, we have re-upgraded the startup and shutdown methods.

1.1. Power On/Off

1.1 Power On: Hold the circular dot on the device's power button for 3 seconds, and when you hear a ring-ring chime, it indicates that the device has been powered on. (Refer to the diagram)



1.1.2 Power Off: Press the device button twice, and you will hear a confirmation sound. Then press and hold the power button for 3 seconds (if you press it for less than 3 seconds or more than 3 seconds, the device will not power off), then release it..., you will



6. Battery and Lanyard replacement

6.1 Insert the shell opening with a shell opening tool.

6.2 Rotate the shell opening tool 90 degrees to open the shell.

6.3 Use your fingernails at the small gap on the side of your item Locator to carefully open the case.

6.4 Replace the battery with a new CR2032 battery 3V. (Positive pole with the text upward).



hear two beeps indicating it is powered off.

Remark:d setting a shutdown timer are designed to prevent accidental shutdowns, ensuring the device can continue to locate effectively.

1.2. Check For Updates

To use the Apple® Find My® app to locate item Locator, the latest version of iOS®, iPadOS®, or macOS® is recommended. The Find My app on Apple Watch requires the latest version of watchOS®.

2. Add Your Locator

2.1 Start the App

2.1.1 Open Find My app on your supported iPhone® or iPad®.

2.1.2 Allow notifications from the app.

2.2 Connect your Locator

2.2.1 Power on your Locator, select the "Items" tab then tap the "Add Item" tab, tap "Other Supported Items".

2.2.2 Make sure your item Locator is close to your phone. Wait... until you see the pop-up "Wireless tag" then tap "Connect".

2.2.3 Choose a recognizable name and emoji for your item Locator and tap "Continue".



① Open the shell as diagrammatic sketch.(No need to fully open the entire shell)

② Put the lanyard into column, then close the cover.

FAQ

1. Why find my device's location not updating.

There are two principles for product positioning reporting. If there are many Apple devices nearby, each new user in the vicinity of this device will report their location, typically within 2-5 minutes. If the device has not moved, the built-in sensors will detect this, and the device will enter a sleep mode, with the reported location ranging from 30 minutes to several hours. Don't worry, the location you see might be from 30 minutes or several hours ago, but it's very likely that the item hasn't moved, and the location you see is the last known location.

2. When pairing a device with Find My app, the phone will link to the Apple server. Pairing may fail because of network problems. The following action is recommended: 1. Change the phone's network, such as switching between WiFi and mobile. The first pairing may take a long time, please wait patiently. 2. Reset your item. 3. Repair with Find my APP.

2.2.4 Find My will ask for confirmation to add your Locator for your Apple ID - tap "Continue".

2.2.5 Tap "Finish" and your Locator will be set up and ready to be connected to whatever item you wish to locate, e.g., your keys.

3. Function introduction

3.1 Locate Your Item

When your item is nearby, tap "Play Sound" to make your Locator beep, then you can find it. When it is out of range, you can find Locator's Last Known Location.

3.2 Notifications

You will receive a notification when you leave your Locator behind when it's no longer in range of your device.

Note: "Notify When Found" can only be activated when your Locator is out of range.

3.3 Share items

The people you've shared it with will be able to locate it, and they won't receive unidentified-tracking notifications.

To use Share Items, make sure you and your friends have installed the iOS 17, iPadOS 17, or macOS 14 Sonoma public betas or newer.

3.4 Lost mode

When your item is lost, enable lost mode, you will receive a notification when location becomes available. You can leave a phone number or email address for the finder of your item to contact you.

Note: When "Lost Mode" is enabled, your Locator is locked and no one else can pair with it. And DO NOT REMOVE ITEM in the APP. Your item Locator will be locked and cannot be used by any person.

3.4 Remove item

Make sure your item is nearby, you can remove item in the app, it should make a ring-ring chime indicating it is removed successfully, then the item can be used by other people.

Note: When "Lost Mode" is enable, DO NOT REMOVE ITEM in the APP, otherwise your item Locator will be locked and no one else can pair with it.

3.5 Factory Reset Your Locator

When your item is out of the range of your phone, and your Locator is removed from Find My app, the device can't be used by other people, you need reset your locator, then it can be used by other people. How to restore factory settings: Press the function button two times, you can hear one beep. Then Press the function button four times rapidly and then hold it a fifth time until you hear a ring-ring chime,

now the device is reset. The device can be repaired to a new Apple ID account as a new device.

3.6 Unwanted Tracking Detection

If any Find My network accessory separated from its owner is seen moving with you over time, you'll be notified in one of two ways: (1) if you have a iPhone, iPad, Find My will send a notification to your Apple device. This feature is available on iOS or iPadOS 14.5 or later. 2) if you don't have an iOS device or smartphone, a Find My network accessory that isn't with its owner for a period of time will emit a sound when it's moved. These features were created specifically to discourage people from trying to track you without your knowledge.

4. Specifications

Battery: CR2032 3V (Replaceable)

Working voltage: 2.8V-3.3V

Capacity: 220mAh

Wireless range: 10-30 meters

Buzzer: Max 100 DB

Product size:Φ32X7.9mm

may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1)This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.



WARNING:This product contains a button cell or coin battery.



WARNING

- INGESTION HAZARD: This product contains a button cell or coin battery.
- DEATH or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause in as internal Chemical Burns little as 2 hours

