


MASSAGE CHAIR

Kyota M880 Joubu



MASSAGE CHAIR

Contents

Warm Prompt:

Thank you for purchasing this massage chair.
please read all the safety and operational instructions
before using the chair .

CONTENTS

Cautions and Warnings.....2-5

Product Specifications.....6

Product Components.....7-8

Positioning The Chair.....9

Before Use.....10

Moving The Chair.....11

Operation Instruction.....12-15

Product Care and Storage.....16

After Use.....17

Trouble Shooting.....18

The product is subject to upgrade and change without prior notice.
Please refer to the actual product

Cautions and Warnings

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be followed. Read all instructions before using this massage chair.

1. Always unplug this massage chair from the electrical outlet immediately after using and before cleaning.
2. If liquid is accidentally spilled onto the chair, remove the power plug from the electrical outlet immediately. Do not use wet hands to connect or disconnect the power plug from the electrical outlet.
3. Do not operate it during storm and lightning.
4. Although operation will be stopped automatically by the Auto-Timer function, always remember to turn off the main power switch after use.
5. Do not place the power cord under the chair or under any other heavy objects.
6. Do not wind the power cord around the chair as this may damage the cord and result in a fire or electric shock.
7. Do not operate the chair with a damaged cord or with an extension cord.
8. Do not use the chair if the electrical outlet is loose.
9. Check that the Alternating Current (AC) voltage corresponds with the specification indicated for the chair.

WARNING- To reduce the risk of burns, fire, electric shock or injury to persons:

1. This massage chair should never be left unattended when plugged in. When not in use, please unplug from the power outlet, and before putting on or taking off parts.
2. Do not operate under blanket or pillow. Excessive heating can occur and cause fire, electric shock or injury to persons.
3. Close supervision is necessary when this chair is used by, on or near children, invalids or disabled persons. Keep children away from extended foot support.
4. Use this massage chair only for its intended use as described in this manual.
5. Never operate this massage chair if it has a damaged cord or plug, if it is not working properly, if it is damaged, or dropped into water. Do not move or carry this massage chair by the power cord or controller, or use the cord as a handle.
6. Keep the cord away from heated surfaces.
7. Never operate the massage chair with the air openings blocked. Keep the air openings free of lint, hair and the like.
8. Never drop or insert any object into any opening.
9. Do not use outdoors.
10. Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
11. To disconnect, turn all controls to the OFF position, then remove the plug from the outlet.
12. Use heated surfaces carefully. May cause serious burns. Do not use over insensitive skin areas or in the presence of poor circulation. The unattended use of heat by children or disabled persons may be dangerous.
13. Never remove the cover from this chair. Do not use the chair when the upholstery is ripped, torn, or removed. This may cause injury or malfunction. Carefully examine the covering before each use. Call for service if the covering shows any sign of deterioration, such as blistering, peeling, cracking, or ripping.

Trouble Shooting

If you encounter problems while operating the massage chair, try the suggestions below.

If the massage chair still is not operating properly, click the main power switch on the back of the chair to the OFF Position and remove the power plug from the electrical outlet.

Do not dismantle or attempt to repair the massage chair by yourself, Doing so will influence the warranty and will not bear any responsibility for any subsequent consequences.

Problem Possible cause/action

Problem	Possible cause/action
· The massage chair is connected to the power source but it is not functioning	<ul style="list-style-type: none"> · Check that the main power switch on the back of the chair is in the ON Position. · Check that the power plug is inserted properly and the power outlet is functioning properly. · Press the power button on the controller. · Check the fuse next to the main switch in the back of the chair.
· The controller is responding, but the massage chair is not functioning	<ul style="list-style-type: none"> · The massage chair may have automatically shut down due to overheating protection devices. please turn off the power and allow the chair to cool for 30 to 50 minutes. · Check that the main power switch on the back of the chair is in the ON Position.
· My massage has stopped	<ul style="list-style-type: none"> · Automatic and manual programs last for 15 minutes (6 minutes for the Quick program). when the program completes, the massage chair will turn off. · The massage chair may have automatically shut down due to overheating protection devices. please turn off the power and allow the chair to cool for 30 to 50 minutes.
· There is noise during the massage.	<ul style="list-style-type: none"> · Some sound is generated by the massage mechanism. This is unavoidable.


Cautions and Warnings

14. Keep dry - do not wet. Do not operate in a wet or moist condition. Do not use the chair when your body is wet. Do not operate this chair with wet hands.
15. Connect this chair to a properly grounded outlet only.
16. Do not insert your hand or foot along the paths of the massage rollers during use as this may cause injury.
17. This massage chair is not intended for use by children or persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of this chair by a person responsible for their safety.
18. Children should be supervised to ensure that they do not play with this massage chair.
19. Any individual who may be pregnant, or recently gave birth, has a heart condition, or a pacemaker, suffers from diabetes or other sensory impairment, phlebitis and/or thrombosis, joint dysfunction, inflammation or injuries, weak bones, osteoporosis, a high fever, an abnormal or curved spine, is at an increased risk of developing blood clots, has pins/screws/artificial joints or other medical devices implanted in his/her body, is being treated for a medical condition or physical injury or is under a doctor's care should consult with a medical professional before using this massage chair.
20. This massage chair is not intended for self-treatment of conditions that should be managed by a qualified healthcare provider.
21. Consult your physician before using this massage chair.
22. This massage chair is designed as a non-professional massager to help soothe tired and aching muscles. It is not intended to be a substitute for medical attention. If your ailments and symptoms persist or worsen after use, contact your physician immediately.
23. Do not use this chair if you are not feeling well.
24. Stop operation immediately if you experience any discomfort.
25. Do not fall asleep during the massage session.
26. Do not operate after taking pain killers, sedatives or alcohol.
27. Do not use this chair in combination with other therapeutic equipment or electric blanket, etc. as this may result in ineffectiveness or injury.
28. Do not stand on or in this massage chair. Use only while seated.
29. Do not disassemble any part of the chair. Touching the internal components may result in malfunction or electric shock.
30. The chair must only be professionally serviced or repaired. Do not attempt to disassemble or repair the chair yourself.
31. Always position the massage chair on a flat, level surface.
32. Do not operate for more than 30 continuous minutes. Turn off the chair and allow it to rest (cool) for 30 minutes before re-using. This will prolong the life of the chair.
33. Do not perform continuous massage on the same spot of your body for more than 5 minutes at a time as this may result in excessive stimulation and may have adverse effects.
34. Never use the chair on open skin eruptions, swollen or inflamed areas.
35. Do not apply massage rollers directly on the head, elbow or knee joints, torso or abdomen.
36. If the power goes off during use, be sure to turn the power switch to the OFF position and pull the power plug out from the socket to prevent damage from occurring when the power is restored.
37. Do not use massager in close proximity to lose clothing or jewelry.
38. Keep long hair away from massage chair while in use.



1. The appliance has a heated surface. Persons insensitive to heat must be careful when using the appliance.
2. If the supply cord is damaged, it must be replaced by a special cord or assembly available from the manufacturer or its service agent.
3. The instructions shall indicate whether the appliance is intended for household or commercial use, or both.
4. If the international symbols "I" and "O" are used, the significance of these symbols shall be explained in the instruction manual provided with the product.
5. Use heated surfaces carefully. May cause serious burns. Do not use over insensitive skin areas or in the presence of poor circulation.
6. Never use pins or other metallic fasteners with this appliance. Carefully examine the covering before each use. Discard the appliance if the covering shows any sign of deterioration, such as checking, blistering, or cracking. Keep Dry Do not operate in a wet or moist condition.
7. Temperatures sufficiently high to cause burns may occur regardless of the control setting. Do not use on an infant or invalid or on a sleeping or unconscious person. Do not use on insensitive skin or on a person with poor blood circulation. Check the skin in contact with the heated area of the appliance frequently to reduce the risk of blistering.
8. Do Not Crush-Avoid sharp folds.
9. Connect this appliance to a properly grounded outlet only. See Grounding Instructions.
10. For all grounded, cord-connected products: GROUNDING INSTRUCTIONS This product must be grounded. If it should malfunction or breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This product is equipped with a cord having an equipment-grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.
11. DANGER-Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or serviceman if you are in doubt as to whether the product is properly grounded.
12. Do not modify the plug provided with the product-if it will not fit the outlet, have a proper outlet installed by a qualified electrician.
13. This product is for use on a nominal 110-120V circuit. Make sure that the product is connected to an outlet having the same configuration as the plug. No adapter should be used with this product.

1. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
2. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
3. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
4. If this equipment does cause harmful interference to radio or television reception,

After Use




1. After the massage finished, press the power button of remote control, then it will adjust the backrest and footrest to the original position.
*Please check if there is any article around the backrest and footrest.
2. Please put the remote control into the Hand Controller Slot after finished using.



3. Please switch the power button to "OFF" if it is not used.
4. Please unplug the power cord.
*Please do not twist and pull the power cord, in case it fractures.
5. If it won't be used in a long time, please cover it with a cloth, in case the dust will influence the use or cause malfunction.

Product Care and Storage


To clean the massage chair:



- Remove the main plug from the electrical socket.
- Clean the controller and cords with a dry cloth.
- Do not use a moist cloth or a cleaning agent on the controller or cords. You may clean the chair with a cloth dampened with water, but do not use any solvents or abrasive cleaning agents.
- If a damp cloth is used, allow the chair to air dry.
- Do not use an electrical dryer.
- Be sure that the chair is completely dry before plugging the power back into the electrical outlet.

Caution

- Do not use abrasive cleaning agents like benzene, alcohol, or thinner to clean the massage chair.
- Do not pour any liquids directly onto the chair.
- Any additional service should be performed by an authorized service representative. Do not clean and wipe the inside of the chair privately.



- Disconnect the massage chair from the power source after use.
- Keep the massage chair away from direct sunlight, high temperature or high humidity.



- Do not put heavy objects on the massage chair.
- Do not store the massage chair under direct sunlight or in places of high temperature. This may cause the upholstery to fade.

Cleaning the Massage Chair.

Never use scouring pads, abrasive cleaning agents or aggressive liquids such as petroleum or acetone to clean the chair.
Do not immerse the chair in water.



which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

Product Specifications

Model No.: Kyota M880 Joubu

Rated frequency : 60Hz

Rated voltage :110-120V

Rated power :180W

Safety design : Class1

Body outer box

N.W.: 86.5 / 190.7 KG/LBS

G.W.: 112 / 246.9 KG/LBS

M/T: 1.257 CBM

Carton size:155*76.5*106CM/61" *30.1" *41.7"

Outer armrest box

N.W.: 26.6 / 58.6 KG/LBS

G.W.: 35 / 77.2 KG/LBS

M/T: 0.61 CBM

Carton size: 166*48*76CM/65.4" *18.9" *29.9"


Operation Instruction



After entering the Settings page, you can select "Language" to choose the language, Select "Screen Time-Out" to adjust the time to dormancy, Select "Backlight" to adjust the brightness of screen Turn on/off "Voice" , "Key Tone" , "Bluetooth" , "Sleep mode"



FAVORITES page: You can add the programs you like into it and when you feel uncomfortable you can delete it by press



Select Nature Sound "WhiteNoise" , "Ocean" , "Cricets" , "Rain" , "Fireplace" , "Airplane" , "CarRide" , "ThunderStorm" , "WindyNight" , "Nature" Volume Level "Off" , "1" , "2" , "3" , "4" , "5" , "6" , "7" , "8" , "9"

Operation Instruction



After entering controlsinterface, you can adjust "4D" , "time of massage" , "Massage Speed" , "Air Intensity"




"Air setting" for turning on/off of airbag massage control in "all body, shoulder, arms and hands" , "hips and waist" , "foot and feet"



After entering the position adjustment interface, you can press and hold "Backrest Down" , "BackrestUp" , "Calf Up" , "Calf Down" , "Foot in" , "Foot Out" , "Footrest Up" , "Footrest Down" .
Button for manual adjustment of sitting posture. You can also select three preset sitting positions. "Incline" , "Leisure" , "Zero Gravity"




Click "Auto" and slide the interface left and right to enter Lifestyle
There are 8 automatic programs to choose from: "Stress Relief" , "Meditate" , "Aging" , "Gamer" , "Driver" , "Athletic" , "On the go" , "Sedentary"



Click "Auto" and slide the interface left and right to enter Focus
There are 8 automatic programs to choose from: "Neck" , "Shoulder" , "Back" , "Lumbar" , "Waist & Hip" , "Leg & Feet" , "Upper Body" , "Lower Body"


Product Components

Main Body Diagram (Rear)




Product Components


Main Body Diagram (Rear)



Power switch



Operation Instruction



1. Massage technique

"Kneading" , "Kneading&Tapping" , "Knock" , "Tapping" , "Shiatsu" , "Combination" 6 massage methods can be selected. Click the corresponding icon to turn it on or off.

2. Area selection

After the massage method is selected, you can select three massage areas of "full range/interval/fixed point" according to your personal preference, and press the "up/down" arrow to adjust the movement position.

3. Roller width

Select "Wide" , "Narrow" and "Medium" to control the width of the movement massage.
(It is effective when non-manipulation is turned on)

This body scanning function will start automatically after selection of first program or demo program. Keep your head resting on the headrest and lean against the chair fully and comfortably in an upright position.

After the body detection is completed, the shoulder position can be adjusted manually,

Press the "up/down" arrow to adjust, and press the "OK" to confirm.

Enter the "Manual" interface, you can choose "Area selection" , "Roller width" , "Massage technique" to perform a custom massage.

Operation Instruction



Turn on LCD SCREEN to start massaging.



There are seven options on the home page :
"Auto" , "Manual" , "Sound" , "Air Setting" , "My Favorite" , "Position Adjustment" , "Setting"



Click "Auto" and slide the interface left and right to enter Therapy


There are 8 automatic programs to choose from: "Relax" , "Stretch" , "Recovery" , "Demo" , "Morning" , "Gentle" , "Nap" , "Night"

Positioning The Chair

When positioning your Massage Chair, allow sufficient space between the chair and walls or other obstacles, and place in an appropriate location.

- Allow 15cm between the back of the chair and any walls or obstacles.
- Allow 30cm between the footrest and any walls or other obstacles.
- Place on a dry, level surface.
- Do not place in direct sunlight or in places of high temperature.
- Keep a distance of more than 1 meter from audio-visual equipment such as TVs and radios to prevent signal interference.

Warning: Do not put the power cord under the chair.



Before Use


Machine adjustment

*Use the controller to place the backrest frame to the extreme position, raise the calf to the highest position and raise it to the longest position. Make sure there is sufficient space around the massage chair before operation.

Before sitting

*Do not sit while the calf massage stand is raised

*Do not suddenly subject the calf frame to excessive pressure, otherwise the mechanical structure may be damaged.



Moving The Chair

1. To move the massage chair, lift up by the head part until the chair inclines on its casters at about a 45° angle.
2. Slowly push and maneuver the massage chair to the desired location. Lower the chair slowly and smoothly until it is fully flat on the ground.
3. Do not move the massage chair when someone is sitting in it. This will cause the chair to tip over, resulting in accident and injuries.
4. Moving the massage chair may cause damage to floors. Floor protection, such as rugs or carpet, is recommended.
5. Do not drop or suddenly let go of the chair when moving, as it may damage the chair.
6. To avoid injury and minimize the chance of dropping the chair, it is recommended that two people move the chair.
7. Do not move by pulling on the cord or on the controller.

