




6 Installing CPU




To remove thermal module before installing CPU




7 Installing Memory



8 Installing Wi-Fi Card




9 Installing CPU Thermal Module



Tip1: To remove the air ven before installing CPU thermal module.

Tip2: Apply an even and thin layer of thermal grease on the surface of the installed CPU.

10 Installing CPU Fan




11


Connecting the cables on the motherboard

Configurations vary by different motherboard model.
Enclosed Wibtek motherboard I/O picture is an example for reference only.

Example




Back I/O Ports




Connection Identification for AIO PC

Label	Connection
1	SPEAKER Chassis Speaker Connector
2	FP_AUDIO/_F_AUDIO Front Audio Header
3	SPEAKER Chassis Speaker Connector
4	SYS_PANEL Intel Front Panel Header
5	AUTO_PWR Automatic Power
6	CLR_CMOS Clear CMOS Header
7	CPU_FAN Cpu Fan Header USB2.0 (Double) Header
8	SYS_FAN System Fan Header
9	USB20_1 USB2.0 (Double) Header
10	USB20_2 USB2.0 (Double) Header
11	USB20_3 USB2.0 (Double) Header
12	SATA SATA Connector
13	SATA_PWR Standard SATA 15-pin male(Optional)
14	SATA SATA Connector
15	SATA_PWR Standard SATA 15-pin male(Optional)
16	LCD_VOT_SEL Panel Voltage Selection
17	LVDS LVDS
18	INV_VOT_SEL Backlight Inverter Voltage Selection
19	MON_SW Monitor Switch
20	DISPLAY—BRT Display Brightness Header


12 Installing Antennas




13 Installing the Hard Disk Drive



Install shockproof foot pads




Plug in HDD cable




Lock HDD screws


14 Installing the Optical Disk Drive




Remove the ODD mounting bracket



Install the ODD mounting bracket on the back of the Optical Disk Drive




Mount the ODD in the chassis with screws




Connect the ODD Connect


15 Installing the back cover



Install shield





Install back cover





Install shaft bracket


16 Multiple combinations



Install decorative cover




Install shaft cover



Install base

17 Multiple combinations



It can be matched with different bases and different cameras

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, Human proximity to the antenna shall not be less than 20cm (8 inches) during normal operation.

This equipment has been tested and meets applicable limits for radio frequency (RF) SAR limits when used on body and limb.