

FUNCTIONAL DEMONSTRATION

1.TURN ON THE POWER, FREQUENCY THE CAR AND THE REMOTE CONTROL

First turn on the remote control car switch and then turn on the remote control switch.

After the successful frequency, the light on the remote control goes out.

2.REMOTE CONTROL DISTANCE

The remote control operation distance is about 30M.

3.TIME OF USE

On a full charge, the car lasts about 25 minutes.

4.LIGHT BAR

When the car is turned on, the light circle flashes blue. After turning on the remote control switch, the car's light circle will change.

LITHIUM BATTERY CHARGING DIAGRAM


Remove the lithium battery from the remote control car and charge it with the complimentary charging cable. The red LED light of the charging cable is on during charging and will be turned off when the charging is complete.

RF exposure statement
This equipment complies with the FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

FCC Warning
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



USB charging cable charging time: about 120 minutes (depending on the charger current)

Unscrew the screw to open the battery cover




Press the battery port before connecting or removing it

Use 14500/500mAh 3.7V lithium battery


After 5 minutes without control, the car will enter hibernation, restart the power supply of the car, and use it normally after the frequency.

BODY




REMOTE CONTROL


Unscrew the screw to open the battery cover





USE 2 X 1.5V "AA" ALKALINE BATTERY




OPERATING INSTRUCTION




IN SITU 360 ° ROTATING TO THE RIGHT





IN SITU 360 ° ROTATING TO THE LEFT





FORWARD




BACKWARD




RIGHT ROTATION





LEFT ROTATION



WHEN THERE ARE OBSTACLES IN FRONT OF THE REMOTE CONTROL CAR:



THE LEFT WHEEL ROLL



THE RIGHT WHEEL ROLLS