

MC-612

PLEASE READ AND SAVE THESE INSTRUCTIONS

MASSAGE CHAIR USER MANUAL

Welcome to

Make Your Home an Extremely Relaxing Environment

Thank you for purchasing our Massage Chair!

Our company is dedicated to crafting massage chairs that can transform the home into a real place for physical and mental relaxation and providing every user with high-quality and low-cost chair. Your support means the world to us. Our customer service team can be reached via email: imassager71@outlook.com

All the instructions necessary to set up and safely relish your chair are contained within this manual. We strongly recommend you to review the entire manual thoroughly before assembling or using your chair for your utmost safety and optimal enjoyment.

For the sake of convenience, we've created a Quick Start Guide designed to acquaint you with all the features of your new chair.

Contact Us

If you have any questions, please do not hesitate to reach out to us via following method

imassager71@outlook.com


We're excited for you to experience your new massage chair!

Table of Contents

| | | |
|--|---|-------|
| Massage Chair Overview | Overall Structure | 01 |
| | Main Features | 02 |
| Before You Begin | Installation Site | 03 |
| | Surrounding Environment | 04 |
| | Move Methods | 04 |
| | Grounding Instructions | 05 |
| Chair Setup | Main Power Switch | 05 |
| | Pillow Adjustment | 06 |
| | Footrest Extension | 06-07 |
| Component Functions | Key Functions of LCD Touch Screen | 08-09 |
| | Foot Rollers | 10 |
| | Bluetooth Speaker | 10 |
| Massage Programs | Auto Programs | 10-12 |
| | Custom Massage Mode | 12 |
| | Airbag Programs | 13 |
| | Zero Gravity/Rocking Chair | 13 |
| | Back Heating | 13 |
| | Massage Time Adjustment | 13 |
| Safety Precautions | Not Suitable for Below Persons | 14 |
| | Best Practices for Safe Use | 14-15 |
| | Unplug the Massage Chair | 15 |
| Fixing Issues | Troubleshooting | 16-17 |
| | Specifications | 17 |
| | Contact Us | 17 |
| Compliance & Certifications | FCC Compliance Statement | 18 |

Massage Chair MC-612

Overall Structure



Main Features



3D Robot Hand



Full-body Air Bags



12 Auto Modes



4 Massage Techniques



3 Massage Intensity



3 Airbag Pressure



Zero Gravity Rocking Chair



Back Heating



Calf Heating



LCD Touch Screen



Bluetooth Speaker



Foot Roller



Footrest Extension




Timer Function

Before You Begin

Installation Site

Please guarantee the proper clearance space for the massage chair

- Place a massage chair in a place where there is enough space for the back of the chair to recline and the footrest to extend.
- Make sure that there is a clearance of at least 16cm in the back of the massage chair and a clearance of at least 30cm in front of the massage chair.
- Please keep it at least 1m away from the TV, radio and other video and audio devices to avoid signal interference.



CAUTION


- Please tidy up the cables well to avoid tangle or damage.
- When the massage chair sliding forward or backward, please check first to make sure there are no kids, pets or other objects around to avoid accidents.
- We recommend to place a piece of carpet or other pad under the massage chair to avoid damaging the floor.

Surrounding Environment

- Keep the massage chair away from damp places (such as bathroom) to prevent electric shock accident.
- Keep the massage chair away from high temperature sources (such as stove) to avoid fire hazard or damage to leather material.

Move Methods

- Apply pressure to the back of the massage chair from behind to pivot on the casters.
- One person should raise the chair via moving holder while another person pushes the chair from the top to facilitate the movement of the casters. Ensure there is a second person at the front to assist in guiding the footrest to its correct position. Keep the specified clearances in mind and gently lower it into place. Do not pull on the armrests.



- Do not move the chair when there are people inside the chair.
- To move the chair, do not lift by the footrest or armrest, and only hold the moving holder in the back and front.


Grounding Instructions

- Insert the plug into a 110V grounded outlet.
- This product must be grounded. In case of malfunction or breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This product is equipped with a cord having an equipment-grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.
- Danger - Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or serviceman if you are in doubt as to whether the product is properly grounded. Do not replace the plug provided with the product - it may not fit the outlet; have a proper outlet installed by a qualified electrician.

Chair Setup

Main Power Switch

- Plug the power cord into well-grounded three-hole socket.
- Activate the chair by switching the main power button, located on the back of the chair's base, to the **ON** position.






CAUTION

- Please turn off the massage chair and unplug it from power the electrical outlet immediately after using.
- Please turn off the massage chair and unplug it from the electrical outlet when the chair is not in use, to avoid children to power on the chair accidentally.
- It is advised to cover the chair with dust-proof cloth, coil the power cord and store the massage chair in a dust-free and dry environment to maintain its condition when it is not in use for a long time.

Pillow Adjustment

● How to use pillow

Sit in the chair and observe the position of the neck pillow on your neck. Ensure it comfortably fits in the arch of your neck by adjusting it - remove it from the Velcro, align it as needed, and reattach it to the Velcro for the desired positioning.




● Increase or reduce the massage intensity manually

Flip up the pillow or both the pillow and pillow pad so that you lie directly on the seat back pad to obtain a more intense massage in the neck area.

For a milder massage experience, fold down the pillow to increase cushioning.

Footrest Extension

- Take a comfortable seat in the massage chair and press the power button to turn it on. As the massage begins, the back of the chair will recline to a certain degree. To adjust the footrest, simply step onto it with proper strength to extend it until you reach the desired length, then hold the position.



CAUTION

- Do not stand directly on the footrest to get in or out of the massage chair, as it will cause damage to the foot rollers!

TIPS:

● How to sit correctly on the chair

How to sit on the massage chair correctly will directly affect your massage experience. It is recommended that you sit in the massage chair deeply, adjust the length of the legs after massage starts, ensuring your body fits snugly against massage chair cushion. After body scanning ends, get ready to start your relaxation journey!


● How to get out of the chair

Simply press the ON/OFF power button to return the chair to its upright position at any time to get out of the chair.

Component Functions

Key Functions of LCD Touch Screen


- The LCD touch screen on the massage chair is designed with a user-friendly interface, facilitating you to use the massage chair easier.



| | |
|--|---|
| | Short press to turn the massage chair on; press again to pause/resume the massage; press and hold for 3 seconds to turn it off |
| | Short press to adjust the massage time, with 5 minutes added by each press (10min/15min/20min/25min/30min). |
| | Zero Gravity: Turn on and off the zero gravity mode (switch among 2 levels). Rocking: Long press for 3 seconds to turn on/off the rocking chair. |
| | Adjust massage position of back rollers up and down |
| | Manually adjust the backrest up and down |
| | Adjust the airbag intensity from level 1 to level 3 |
| | Choose airbag massage modes among upper body airbags, lower body airbags, whole body airbags and deactivate whole body airbags |
| | Manually adjust the massage speed from level 1 to level 3 |
| | Short press to turn the buttock rollers on or off |
| | Turn the back and calf heating function on/off |
| | Short press to turn the foot rollers on or off |

Foot Rollers

- Press the foot rollers button to turn the rollers on or off and adjust the intensity of the foot rollers



Bluetooth Speaker

- Our product is designed with Bluetooth audio connection function. It can play music through connection with smartphone, tablet or other electronic devices.
- Open mobile phone/ipad/computer BLUETOOTH function, and enter search state to automatically search neighboring BLUETOOTH devices.
- In a few seconds, our massage chair name will show up under the device list, select the massage chair name "MC-612" to complete the Bluetooth connection.
- Long press "Foot Roller" button for 5 seconds to clear the Bluetooth connection on the remote control.

Massage Programs

Auto Programs

| | |
|---|---|
| Automatic program Family care Relaxing Classic massage | Special program Neck & shoulder yoga Relax trapezius muscle Refreshing |
|---|---|

- The massage chair features 12 auto modes, including nine automatic programs, i.e. Family care*3, Relaxing *3, Classic massage*3, and three special programs, i.e. Neck & shoulder yoga, Relax trapezius muscle and Refreshing.

| Auto Programs | | |
|------------------------|---|--|
| Family care *3 | Women Massage | Tailored program for women: enjoy a personalized spa massage experience in the comfort of your home. |
| | Men Massage | A specialized program designed for men, offering a massage with distinctive techniques to promote relaxation. |
| | Senior Joy | A special massage program designed for seniors, incorporating gentle and slow massage techniques to relax meridians. |
| Relaxing *3 | Game Mode | Suitable for leisure time massage to relieve tension. |
| | Movie Mode | Ideal for massage during gatherings, movie watching, or chatting with friends. |
| | Nap Mode | Perfect for a mid-day break, soothing tension, improving digestion, and refreshing the body. |
| Classic massage *3 | Chinese Massage | Reduce mental stress and relax the entire body. |
| | Thai Stretch | Enhance relaxation, provide stretching effects with rocking chair functionality. |
| | Healthy Breath | Focus on breathing, eliminate distractions, and clear the mind through even and slow breathing. |
| Special Programs | | |
| Neck & shoulder yoga | Imitate yoga stretches, boost blood circulation in shoulders and neck, ease soreness and headaches due to poor blood flow. | |
| Relax trapezius muscle | Target trapezius muscle for better relief from soreness and tension caused by prolonged sitting, with secondary focus on other areas. | |
| Refreshing | Ease back muscle tension and improve the soreness and pain caused by tense back muscles. | |

- Turn on the power: When the power is turned on, press up and down to lower or raise backrest.
- Press the power button: When press power button, it will automatically start Auto program one.
- You can switch auto program by press auto program buttons. We have 12 automatic modes:



- You can switch to next auto program anytime, don't have to wait until the current program is finished.
- Zero: In any auto programs, press "  " into zero gravity position.
- Up and Down: In any auto programs, press "  " and "  " to lower or raise the backrest.
- Time setting: short press  to adjust the massage time, with 5 minutes added by each press (10min/15min/20min/25min/30min). After reaching 30min, press again to change it to 10min.
- Short press  to turn the massage chair on; press again to pause/resume the massage; press and hold for 3 seconds to turn it off.

Custom Massage Mode

- Press  and  to adjust massage position of back rollers up and down.
- The foot rollers and the buttock rollers can be turned on/off separately.
- Press  to turn the back and calf heating function on/off.

In auto modes, you can press any of the following four techniques to select your desired one. Press again to deactivate the function and the chair will perform the initially selected auto mode.

| | |
|--|--|
|  Spa | Mainly utilize SPA massage and perform cyclic kneading to alleviate muscle tension |
|  Twist & Shake Neck | Mainly utilize neck twisting and shaking method to stretch the shoulder and neck muscles, eliminating fatigue in those areas |
|  Kneading | Mainly utilize the kneading method to stretch the muscles of lower back and promote the circulation of lower back |
|  Shiatsu | Mainly utilize Shiatsu massage, focus on scraping and deliver deep massage |

Airbag Programs


- The massage chair boasts full body airbags massage including shoulder airbags, arm airbags, hip airbags, calf airbags, and foot airbags.
- Dedicated airbag massage programs are designed for each automatic program in order to provide a comprehensive full-body massage experience.
- In the manual mode, you can select the upper body airbags, lower body airbags, whole body airbags and deactivate whole body airbags and adjust airbag intensity according to your preference.
- During airbag massage process, the airbag inflates to envelop the body. Due to limited power of air pump, our airbags won't over-inflate, ensuring a comfortable experience without applying excessive pressure on the body.

Zero Gravity/Rocking Chair

- Press Zero Gravity button to turn on and off the zero gravity mode (switch among 2 levels).
- Long press the button for 3 seconds to turn on/off the rocking chair.
- Note: in any mode, the Rocking Chair function can be activated.
 - (1) When turning on the Rocking Chair function first, you can also activate other modes;
 - (2) Activate any mode first, then long press the Zero Gravity button for 3 seconds to activate the Rocking Chair function; press the button again for 3 seconds to deactivate it, with other functions operating normally.

Back Heating

- Press the Heat Function button to apply the hot compress to entire Back to expel the moisture from the body, thus promoting blood circulation and relieving muscle pain.



Massage Time Adjustment

- Short press the Power button to turn the massage chair on and adjust the massage session duration (5 minutes will be added with each press).
- Recommended massage time: 1 hour or less each time.

Safety Precautions

Not Suitable for Below Persons



Warning

- We recommend those with any of the following conditions consult your physician first before using the massage chair.
- Patients with serious hyperostosis.
- Patients with swollen lump and thrombosis.
- Patients with serious heart conditions.
- Women who are pregnant.
- People that consume large amounts of alcohol.
- People with diabetes.
- People suffering from high fever.
- Patients with malignant tumors or malignant abscesses.
- People with distorted joints.
- People with serious skin conditions.
- People with spinal injuries.
- Minors under 16 years or people unable to control their behavior, such as mental patients and people with paralysis.
- Children shall not play with the device.

Best Practices for Safe Use



Warning

- Use this product only for its intended use as described in this manual.
- Do not use attachments not recommended by the manufacturer.
- Never operate this chair if it has a damaged cord or plug.
- Keep the cord away from heated surfaces.
- Empty pockets and remove all your arm jewelry and watches before using this chair.
- Do not operate where aerosol (spray) products are being used.
- To disconnect, turn all controls to the off position, then remove plug from outlet.
- Connect this device to a properly grounded outlet only. See Grounding Instructions.
- Do not remove the back cushion to modify roller mechanism.
- Do not remove the bottom seat to modify actuators.
- Keep the cord away from a heavy traffic area.
- Please unplug the power cord from the electrical outlet immediately after use.
- Only for users who weigh below 120kg.
- Do not operate any equipment with damaged parts.
- Any other use not recommended by the manufacturer may cause electrical shock or injury.
- Do not touch or re-wire the wires connected to the master-box.
- Do not attempt to repair or modify any electrical or mechanical functions on this unit, it will void the warranty.

Best Practices for Safe Use



Warning

- Do not put your hands or head under the chair.
- When using the massage chair, make sure that the footrest is in the lowest position.
- Do not allow children to play near the chair, especially when the chair is in use.
- Do not leave mobility impaired or speech impaired people alone in chair.
- Do not place or stock this chair near damp places such as swimming pools or bathrooms.
- Do not press massage rollers by force.
- Do not stand on the chair or put heavy items on the chair.
- Do not use in a humid, dusty, greasy or oxygen-deficient environment.
- Do not spill water or other liquids onto the control buttons to avoid fault.
- Do not place the product near steam oven, open fire, or heat.
- Wear suitable clothing, do not massage with bare skin.
- Do not place it directly in the sun.
- Do not use electric blanket while using the massage chair.
- Do not use it outdoors.
- Do not massage while smoking.
- Do not massage immediately after meals.
- Do not sit on the back cushions, armrest, or footrest.
- Don't use it when your body is wet or moist as it can result in electrical shock.
- Do not massage with more than one person.
- Don't massage when using headwear as it can result in injury.
- Do not stumble over electrical wires or connections.
- Do not squeeze, over bend, pull hard or twist the cord.
- Do not use the massage chair when you are not feeling well.
- Do not massage the head, elbow joints, knees, chest, abdomen directly on the massage ball.
- Do not damage the power cord, which may result in electric shock or mechanical failure.
- Do not stand on or stack heavy objects on the footrest.
- Do not fall asleep when using the product.
- Do not disassemble, fix or modify the product yourself to avoid failure.
- Please be seated properly while using the product.

Unplug the Massage Chair



Caution

- Pull out the power plug before maintenance.
- Do not plug in or unplug the massage chair with damp hands to avoid electric shock.
- Turn off power and unplug the massage chair from the electrical outlet when the massage chair is not in use to prevent power surges or other emergencies that may damage the massage chair or to avoid children powering on the massage chair accidentally.
- Power off the chair and unplug the massage chair after using.
- Disconnect the controller and store the chair carefully.

Fixing Issues

Troubleshooting

| Problems/Issues | Possible Causes | Possible Solution |
|---|--|--|
| ● Sounds like tapping or hum are heard while in use | ● These sounds are normal and arise from air pump, motor or other mechanical parts | ● Normal, no need to take any measure |
| ● Massage chair stops working suddenly | ● Power connection is bad ● Auto program time is up | ● Unplug and reinsert the power cord to the chair ● Normal circumstance |
| ● Massage chair doesn't work after power on | ● Power switch is not turned on ● Connection between plug and socket is bad ● Massage remote is not turned on ● Power wire plug is broken ● Fuse is blown ● Control unit fails to work properly | ● Turn on switch ● Insert power cord again ● Press power button on remote ● Contact customer service or professional technician ● Replace with a fuse of same type and rating ● Contact our customer service or professional technician |
| ● Roller height changes | ● Rollers work alternately | ● Normal, no need to take any measure |
| ● Abnormal sounds are heard suddenly while in use | ● May be caused by over-working of the massage chair | ● Reduce usage ● Contact our customer service or professional technician |
| ● Backrest or footrest can not recline | ● Be obstructed, make sure that there is enough space for the chair to fully recline | ● Stop operation, move the obstacles and provide sufficient clearance |
| ● Fail to restore position after reclined | ● Electric motion pole fails ● Plug connection is bad | ● Contact our customer service or professional technician ● Insert the power plug properly into the socket |
| ● No music comes from the speaker | ● The volume is adjusted to its minimum setting | ● Adjust the speaker volume and ensure that both the chair's and phone's Bluetooth settings are activated |

In case of any problems beyond above reasons, turn off the power supply and contact the distributor or manufacturer for assistance.

TIP:

Do not attempt to dismantle or repair the product by yourself, and our company shall not be liable for the damage or injury caused by improper use or servicing without authorizations. Thank you for your cooperation!

Specifications

Model: MC-612 Massage Chair

Rated Voltage: 110V ~220V

Rated Frequency: 50/60HZ

Rated Power: 90W

Safety Design: Class I

Net Weight: 140 LB

Gross Weight: 167 LB

MEAS: 55.1" * 29.9" * 34"

Manufacturer reserves the right to make changes to information published in this document, including without limitation specifications and product descriptions at any time and without prior notice.

Compliance and Certifications

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Statement

To maintain compliance with FCC'S RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm between the radiator and your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.