

Thank you for choosing our product. If you have any questions, concerns of need any help, please contact us at support@ecozy.com or call us via hotline (443)991-8777 (UTC 14:00-22:00, Monday to Friday)

CONTENT

CONTENT	
SAFETY INSTRUCTIONS	01
MAINTENANCE AND CARE	01
WHAT'S INCLUDED	02
PRODUCT OVERVIEW	02
GET STARTED	03
OPERATE VIA THE DEVICE	
Time ·····	
Alarms ·····	
FM Radio	
Bluetooth	07
Sleep Music	80
Sleep Timer	08
Sunrise Light	09
Single-Color Light	09
RGB Ambient Light	09
Display Brightness	09
OPERATE VIA THE APP	10
App Downloading and Installation	10
App Registration and Login	10


SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, please read these instructions before use. 1. This product is only intended for household use, including similar use in hotels. 2. Please place this product on a stable, level, and non-slippery surface. 3. Do not use this product in wet surroundings, such as in the bathroom, near a shower or a swimming

4. Do not let the water run into the product or spill any water onto the product. 5. Make sure the power adapter does not get wet when in use. 6. Only use the ORIGINAL USB cable provided. 7. Do not use this product as a means of reducing your sleeping time. This product aims to help you wake up more easily instead of diminishing your need for sleep.

MAINTENANCE AND CARE


1. Please clean the product with a dry and soft cloth. 2. Do not use abrasive cleaning agents, pads, or cleaning solvents like alcohol, acetone, etc., as this might damage the surface of the product. 3. If the product will not be used for an extended period of time, please unplug the power adapter f rom the socket, then store the product in a safe and dry place where it will not be crushed, banged, or subject to damage.






10 Sleep Timer/Time Setting (11) Alarm 1 on/off & Setting (12) Snooze (13) Alarm 2 on/off & Setting 14 Time Display Brightness/Bluetooth on/off (15) Volume Adjustment (6) Alarm 1 Repeating Cycle Setting 16 FM Radio (17) Sleep Music

PRODUCT OVERVIEW






GET STARTED

Connect the wake-up light to a 100-240V power with the provided charging cable and power adapter. 漢: Tip:

This product has no power on/off button, and it will be on once you connect it to power. To disconnect power, please unplug the product.



(18) Alarm 2 Repeating Cycle Setting

OPERATE VIA THE DEVICE

Link the Light with the App

TROUBLESHOOTING SPECIFICATIONS

CONTROL THE LIGHT WITH AMAZON ALEXA CONTROL THE LIGHT WITH GOOGLE ASSISTANT

The wake-up light will automatically save the current setting and exit from setting mode if the operation is not resumed within 15s.

Before the first use, please set the time.

1 Press and hold (Sleep Timer time setting. You will see the flashing digits. 2 Rotate to select between 12-hour format or 24 hour format, and then press to proceed. ③ Set the hour, minute and day of week by rotating ⑥ . Press ⑥ to navigate through settings and complete the setup.

Alarms

Set up the Alarm You could set Alarm 1 and Alarm 2 with the wake-up light and via the EcozyHome app, while Alarm 3 and Alarm 4 could be only set via the app EcozyHome. We will take setting Alarm 1 as an example to

4 Select the alarm sound by rotating (a) (options: OFF, S01-S08), and then press (b) to proceed.

guide you how to set an alarm. 1 Press and hold $\binom{ON/OFF}{ALI SET}$ to enter alarm setting. ② Set the hour by rotating ⑤ , and then press ⑥ to proceed. ③ Set the minute by rotating ⑤ , and then press ⑥ to proceed.

* S08: The last FM station you were tuned to before turning off the radio. If you prefer another station, please turn on the FM radio to search and select the one you like, then set the alarm again. 5 Set the volume of the alarm sound by rotating (options: V01-V16, V16 = loudest), and then

press 🔵 to proceed. 6 Set the brightness level of the wake-up light by rotating (options: OFF, L01-L20, L20 = brightest), and then press 🔵 to proceed.

7 Set the time to turn on the wake-up light before the alarm rings by rotating (options: 0, 10, 20, 30, 40, 50, and 60 min), and then press 🖨 to confirm and complete. Alarm 1 is on after setup. 8 To change the alarm repeating cycle, make sure the alarm is on (on display), and then press (ALL OPTION) to choose from Monday to Sunday, Monday to Friday, and Saturday to Sunday. The setting will be saved automatically.

💓: Tips: * Please note you cannot set both the wake-up light and alarm music to OFF. * To turn on or turn off alarm 1/alarm 2, press $\binom{ON/OFF}{ALI SET}$ / $\binom{ON/OFF}{AL2 SET}$ once.

Respond to the Alarm

If you set the wake-up light for the alarm, it will gradually simulate a sunrise by increasing the light intensity at the preset time. When it's time for the alarm to ring, the light will reach the preset brightness, and the alarm sound will activate to wake you up. During the light-up or alarm ringing, you can perform the following operations:

When the wake-up light illuminates but the alarm still hasn't rung, press 📵 to turn off the wake-up light. It will light up again when the alarm rings.

Alarm snooze: When the alarm is ringing, press to activate snooze mode. Once the snooze duration ends, the alarm will ring again. You can repeat this process multiple times as there is no limit. 🄃 Tip:

For setting the snooze mode, please use the **EcozyHome** app.


When the alarm is ringing or in snooze mode, press ON/OFF / ON/OFF or press and hold for 3 seconds to stop the current alarm. This will not affect the next alarm.

No operation: If there is no operation for 30 minutes while the alarm is ringing, it will automatically stop.

FM Radio

FM Radio.





1 Press (to turn on the FM radio.

5 To turn off FM radio, simply press

2 Press and hold 👩 to enter station searching mode (range: 76.0MHz-108.0MHz). After the search is complete, the radio will automatically play the last searched station. 3 To switch between stations, press and hold for 2 seconds to enter station switching mode,

and then rotate 📵 to select your desired station. Repeat the same operation to manually adjust the station by 0.1. 4 Rotate to adjust the volume.

Bluetooth You can use the wake-up light as a Bluetooth speaker.

1 Press and hold (DMMER) for 2 seconds to activate Bluetooth mode, indicating by a voice prompt "Bluetooth mode" and a flashing BT icon on the display. ② Go to the Bluetooth settings on your device and search for "E80S" to connect. ③ Wait for successful pairing, indicating by the voice prompt "Paired successfully" and a solid BT icon on the display. Then you can start playing music.

💓: Tips: * The warm-up light's time will be automatically calibrated after Bluetooth connection. * To switch to the previous or next song, simply rotate (a). Each notch skips to another song. * Press to play or pause the music; rotate to adjust the volume.

4 To disconnect Bluetooth connection, simultaneously press and hold (DIMMER) for 2 seconds.

Sleep Music

1 Press to turn on the sleep music. 2 Rotate to switch among different music (options: S01-S22).

3 Rotate to adjust the volume. 4 To turn off the sleep music, press and hold for 3 seconds.

Sleep Timer 1 Press (Steep Timer) to enable the sleep timer. You will see the flashing digits. 2 Rotate to set the timer duration (options: 10-120, 180, 240, 300, 360, 420, and 480 MIN).

The setting will be saved automatically.

💓: Tips: * While the timer is running, you can freely turn on FM radio, sleep music, sunrise light or RGB ambient light, and they will automatically turn off when the timer ends.

* While the timer is running, you can press (SloopTime) to check the remaining time. 3 To cancel the timer, press and hold (SleepTimer) for 3 seconds.

Sunrise Light

1 Press to turn on the sunrise light. 2 Rotate to adjust its brightness.

3 To turn off the sunrise light, press again.

Single-Color Light

1) Press and hold (for 2 seconds to turn on the single-color light. 2) Press (to cycle through different colors, including pink, green, blue, cyan, purple, white,

red, and yellow. 3 Rotate to adjust its brightness.

4 To turn off the single-color light, press and hold if for 2 seconds.

RGB Ambient Light 1 Press (RGB) to turn on the RGB ambient light.

2 Press (RGB) to cycle through different light modes. C08 and C09 can sync with Bluetooth music. 3 Rotate to adjust its brightness.

4 To turn off the RGB ambient light, press and hold RGB for 2 seconds.

Display Brightness Press (DIMMER) to adjust the brightness of the display (options: high, medium, low, very low and off).

OPERATE VIA THE APP

App Downloading and Installation Option 1:

Search for EcozyHome from App Store™/Google Play™, then download and install it on your mobile device.

Google Play™ is a trademark of Google Inc., and App Store™ is a trademark of Apple Inc.

Option 2: Scan the QR codes below to download and install.





App Registration and Login Launch the App, register an account with a valid email address at your first use, then log in. For a successful connection, please allow the App to use your WLAN & Cellular Data when running it.

Link the Light with the App IMPORTANT:

For the wake-up light: • Make sure the wake-up light has been connected to power.

• Before connecting, please turn on location service/GPS on your phone and grant all the permissions required by the App.

• Make sure your mobile device is connected to a 2.4GHz WiFi. • Make sure you've entered the correct WiFi name and password when connecting. • Make sure the wake-up light, your phone and your router are close enough when connecting.

WiFi Indicator on the LED Display Flashing Ready for WiFi Connection

Solid WiFi Connected

(5) Connecting.

1. Auto Search ① Press and hold ② on the wake-up light for about 10 seconds until the WiFi Indicator on the LED display keeps flashing. Turning on the Bluetooth function of your mobile device is a must. ③ Tap Connect after ② Launch the App, and tap Add Device. your device is displayed on the page. Connect

(1)


Robot Vacuum Air Fryer

6 Connected. The WiFi

display will turn solid on.

Indicator on the LED










Step 2:

Step 1:

2. Add Manually







Step 2:

CONTROL THE LIGHT WITH AMAZON ALEXA Tap Connect, then tap the WiFi of ECOZY-SL-**** on the pop-up window. (For Android Device) Important:

1 Make sure the wake-up light has been connected to power. 2 You have connected the wake-up light to the **EcozyHome** App. 3 Make sure you've installed the **Alexa** App on your mobile device. (4) Make sure the WiFi connection is stable.

Log in to the Alexa App with your Amazon account, tap = and then select Skills & Games.

Step 2: Search and select EcozyHome, then enable it by tapping ENABLE TO USE.

Agree and link your **EcozyHome** account with Alexa.

Q4. The radio produces a crackling sound.

Step 4: Tap CLOSE to close the page, then tap DISCOVER DEVICES to discover the wake-up light which has been connected in the **EcozyHome** App.

Step 5: After the wake-up light is discovered, please tap CHOOSE DEVICE to set up your device.

Tap O and allow the Alexa App to access the microphone of your mobile device. Then you can say the following voice commands to your mobile device, the wake-up light will respond accordingly.

Alexa, turn on the light(or the name of your wake-up light if you have changed the device name). Alexa, turn off the light.

Alexa, turn on the alarm one/two/three/four. Alexa, turn off the alarm one/two/three/four. Alexa, turn on the radio.

Alexa, turn off the radio.

Note: If you have an **Echo** device at hand, please follow the steps below to make it available for voice commands.

Step 1: Log in to your **Echo** device with the same Amazon account for logging into the **Alexa** App.

Step 2: Tap Devices at the bottom, then tap Echo & Alexa to show your Echo device. Then you can speak the voice commands mentioned above to your **Echo** device, and the wake-up light will respond

accordingly as well. CONTROL THE LIGHT WITH GOOGLE ASSISTANT

1 Make sure the wake-up light has been connected to power. (2) You have connected the wake-up light to the **EcozyHome** App.

4 Make sure the WiFi connection is stable. Step 1: Launch the Google Home App, then follow the in-app instructions to set up your Google account. Tap \mathbb{Q} on the upper right corner, then search and select **EcozyHome**. Agree and link your **EcozyHome** account with Google Home.

Tap Settings on the main page, then scroll down to the bottom to tap Works with Google.

Step 6: Tap **4** and allow **Google Home** to access the microphone on your mobile device. Then you can say the following voice commands to your mobile device, and the wake-up light will

respond accordingly. OK Google, turn on the light(or the name of your wake-up light if you have changed the device name). OK Google, turn off the light.

Follow the instructions to set up the device to finish the settings.

OK Google, turn on the alarm one/two/three/four. OK Google, turn off the alarm one/two/three/four. OK Google, turn on the radio. OK Google, turn off the radio.

If you have a Google Home Speaker at hand, please follow the steps below to make it available for voice commands.

Plug your Google Home Speaker into the socket.

Tap New device, then tap Next to look for devices. Step 4:

Follow the instructions of the Google Home App to connect your Google Home Speaker to WiFi. Then you can speak the voice commands mentioned above to the speaker, and the wake-up light will respond accordingly as well.

Tap + on the upper left corner of the main page, then select **Set up device**.

TROUBLESHOOTING This part summarizes the most common problems you could encounter with the wake-up Light. If you are unable to solve the problem with the information below, please feel free to contact

* Make sure the wake-up light is ready for WiFi connection.

support@ecozy.com for assistance. Q1. The appliance does not work at all. * Make sure the appliace is properly connected to power.

* Perhaps there is a power failure. Check if the power supply works by connecting another appliance. Q2. What should I do when I cannot link the wake-up light with the App?

* Check if the wake-up light is powered on. * Make sure your mobile device is connected to the 2.4GHz WiFi Network. Make sure the password of your WiFi network entered in the **EcozyHome App** is correct when Q3. Why did I fail to set the alarm clock to ring only on weekdays? * Please turn on the **Network auto-time** in the setting interface of the **EcozyHome App**, then you can set the alarm clock according to your needs.

* Perhaps the broadcast signal is weak, please fully unwind antenna and move it around until you receive the best reception. Q5. How can I set the alarm 3 and alarm 4?

Q6. Could I completely turn off the time display? * Yes, you could turn it off in the setting interface on the **EcozyHome App** or by pressing the button $\left(\frac{\text{DIMMER}}{\text{BT}}\right)$ on the wake-up light. Q7. The light wakes up me too early.

* Perhaps the light intensity level you set is not appropriate for you. You can try a lower light level.

* Move the wake-up light further away from the bed. * The sunrise time duration you set is too long. Please select a shorter one. Q8. The light wakes up me too late.

* The sunrise time duration you set is too short. Please select a longer one. * Please make sure your power adapter's output voltage is 5V and current is greater than or equal to

Frequency Range Transmit Power(EIRP)

operation.

FCC CAUTION Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(2) this device must accept any interference received, including interference that may cause undesired

radiate radio frequency energy and, if not installed and used in accordance with the instructions, may

cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or

television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can

(1) This device may not cause harmful interference, and

— Reorient or relocate the receiving antenna.

— Increase the separation between the equipment and receiver.

— Connect the equipment into an outlet on a circuit different from that to which the receiver is — Consult the dealer or an experienced radio/TV technician for help.

ISEDC WARNING

other antenna or transmitter.

utiliser l'appareil est de 20 cm.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired

operation of the device. Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts

(1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device is compliance with RF exposure guidelines, users can obtain Canadian information on RF

informations canadiennes sur l'exposition aux RF et la conformité.La distance minimale du corps pour

L'appareil est conforme aux directives d'exposition aux RF, les utilisateurs peuvent obtenir des

exposure and compliance. The minimum distance from body to use the device is 20cm.

* Alarm 3 & Alarm 4 can be only set on the EcozyHome App.

* You can try to set a higher light intensity level. * Make sure the wake-up light is located at a height where the light is not blocked by your bed, comforter, pillow or any other things.

SPECIFICATIONS

2412-2462MHz 10-16dbm

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator& your body. This transmitter must not be co-located or operating in conjunction with any

L'exploitation est autorisée aux deux conditions suivantes: