

English

Product Hardware Overview

1. 4-Microphone Array

2. AI Search Button

3. Power Button


4.USB Type-C

5. Charging Indicator

6. Quick-Bar

7. Anti-Slip Pads

8. POGO PIN




-2-

1. Eraser


Use the end of the stylus to erase handwritten notes.

2. Customizable Button

For erasing: Hold the side button when the tip is over 1cm away, then tap the screen.




For custom functions: Keep the tip within 1cm of the screen while holding the side button, then tap the screen.



Supports customizable functions including Smart Pen Mode [Ballpoint], Circle-to-Erase, Erase, Disable, and more. Functions can be customized in Settings (see details on P12).


3. Replaceable Stylus Tip

Replace the tip when worn to maintain optimal writing performance. Simply pull out the old tip and insert a new one.




-3-


Accessories



USB Type-C x1




Quick Start Guide x1



EMR Stylus x1


-4-

Power On & Initialization






Step 1: Press and hold the Power Button for more than 3 seconds to start AINOTE.
*Note: During initial setup, pre-installed apps will load to enhance your experience. While waiting, you can:

① Download our companion app for multi-device note management



AINOTE mobile
android/iOS/windows/MAC OS

② Follow us on social media for tutorial videos and tips



@FLYTEKAINOTE

-5-

Step 2: Country and Region Selection

Language

Country and Region

*Select your region. Your account and data will be stored on corresponding servers. Changing regions may migrate your data to another server.

Step 3: Network Connection

Connected

*Connect to a network that does not require secondary verification.

Step 4: Time & Time Zone Setup

*If multiple time zones are available in your region, select the correct one manually.

-6-

Step 5: Account Registration

Account Login

Sign Up

*Register an AINOTE account with a valid email. Create a 6~16 character password containing at least two of the following: numbers, letters, symbols.

Step 6: Set the lock screen password & home signature

Set the lock screen password

Please remember your lock screen password. You cannot retrieve it if you forget it.

*Remember your lock screen password. You can also set up fingerprint unlock; the power button functions as a fingerprint sensor.
*The home screen signature can be updated anytime in Settings.

Congratulations! Your AINOTE is now ready to use!

-7-

AINOTE Gesture Controls


Quick Access Control Panel

Swipe down from the top right corner to open the Quick Settings menu for Wi-Fi, screen casting, volume, and more. Swipe down from the top left corner to open the Notification Center.

Multitasking

Swipe up from the bottom of the screen to open the multitasking interface. Quickly switch between apps or close background apps.

-8-



How to Use the Quick Bar

①Access free ChatGPT Q&A.
②Quickly flip through pages when reading multi-page content.
③Open Quick Notes for instant handwriting input.

-9-

Notes Feature Overview

Select note templates

Enable Text-Audio Sync

OCR language settings

Freely write in Handwriting Mode
Enter text in Text Mode

Modify text formatting

Set text alignment

Use AI Writing (supports creation, rewriting, and polishing)

How to Add Custom Note Templates

①Import template images (PNG, JPG, etc.) into the [template] folder via USB.
②Open the template menu at the top and select Custom.
③Tap the imported template to add it.

-10-

Audio-to-Text / Translation

Enable Speaker Recognition

Adjust transcription area size

Transcription Mode Settings

*Choose transcription language. Audio will be transcribed based on the selected language.
*Pre-set translation mode if needed.


Tip: When Text-Audio Sync is enabled, you can take handwritten notes while recording. Afterward, tap on any handwritten content to instantly locate the corresponding audio segment.

-11-


Smart Pen Overview

How to Use the Smart Pen


Step 1: Press the side button during writing to quickly activate Smart Pen mode.



Step 2: Circle handwritten content to move it, perform AI search, and more.




Step 3: Press the side button and draw shapes like O, e, Δ in front of handwritten content. The system will automatically convert them into standard shapes and add the associated content to To-Do, Follow-Up, or Subheading categories.



-12-

Calendar Overview

Link third-party calendar accounts for two-way sync of calendar events and to-do items



Calendar View all calendar events, tasks, and notes for the day, with options to switch between different calendar views.

Task Create new tasks and automatically collect tasks generated during meetings, with options to set deadlines and manage basic task details.

Focus-star Starred items: Automatically collect meeting content marked with a ☆ for follow-up.

-13-

Reading Overview

Bookshelf

Office Center

Bookstore

All imported and downloaded eBooks are displayed on the Bookshelf. Supported formats include MOBI, EPUB, PDF, TXT, AZW, and more.
Supports viewing, editing, and annotating Office documents, including Word, PowerPoint, and Excel.
A selection of free public domain books is available for download and reading.

-14-

How to Import Books and Documents

① Connect AINOTE to your PC via USB.
② Copy eBooks (PDF, EPUB, MOBI, TXT, AZW) to the [Bookshelf] folder. Copy Office documents (DOCX, PPTX, XLSX) to the [Office] folder.
③ View imported books and documents directly on AINOTE.

Method 2: Wi-Fi Import


①Go to the AINOTE Bookshelf interface and tap the Import button.
②Enter the Wi-Fi Import interface and check the provided address (http://).
③ Connect both AINOTE and your PC or mobile device to the same Wi-Fi network.
④ Open a browser on your PC or mobile device and enter the AINOTE-provided address (http://).
⑤ Access the transfer interface and select local files to import.
⑥ View the imported books and documents directly on AINOTE.

Method 3: Cloud Drive Import

① Enter the AINOTE App Center - Cloud Drive interface.
② Add your cloud drive account and login.
③ Browse and download documents from the cloud drive.
④ View the imported books and documents directly on AINOTE.

-15-

Tap the center of the screen to open Reading Settings



Supports handwritten annotations, highlights, excerpts, and other reading tools


Text-to-Speech is available with multiple language voice options

How to Import Custom Fonts

① Download font files on your PC and connect AINOTE via USB.
② Copy the font files to the [Fonts] folder.
③ Open a book, tap the center of the screen, and select Font Settings.
④ Tap Change Font to select your newly imported fonts.

-16-

How to Perform a System Update



Keeping AINOTE up to date ensures the best user experience. We release system updates periodically. When an update is available, you will receive a pop-up notification. You can also check for updates manually.

Step 1: Tap your user account icon on the left sidebar to open [Settings].
Step 2: Tap [Check for Updates] in the bottom left corner.
Step 3: If you see "Your device is up to date," no action is needed.
If a new version is available, follow the prompts to download and install it.

-17-

How to Provide Feedback


We highly value your feedback—it helps us improve our product. If you encounter any issues during use, you can contact us through the following channels:

1. Support Email


Choose the appropriate contact based on your region:
Europe: service@danutecheu.com
Japan: c-support@flytek.co.jp
Korea: service@flytekskorea.co.kr
Singapore: service@flyteklntech.com
USA & Others: support@flytekglobal.ai
Our team is ready to assist you with product-related inquiries.

2. In-Device Feedback on AINOTE

Step 1: Swipe down from the top of the screen to open the Quick Menu.
Step 2: Tap [Feedback] to enter the feedback interface.
Step 3: If the FAQ does not resolve your issue, describe the problem in detail on the [Feedback Page]. You can attach screenshots or other files.
Step 4: Tap [Submit]. Our support team will respond, and you can view the reply in [Feedback History].



FLYTEK Official Website



AINOTE Official Website

-18-

Note:

- 1.The built-in battery is non-removable. Do not attempt to disassemble or replace it yourself. Replacement must be done by authorized technicians.
- 2.Battery operating temperature range is 0 – 45°C. Please charge the battery strictly according to the instructions.
- 3.Dispose of used batteries in accordance with local laws and regulations.

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user’ s authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1)This device may not cause harmful interference, and
(2)This device must accept any interference received,including interference that may cause undesired operation.

This equipment has been tested and meets applicable limits for radiofrequency(RF)exposure. SAR limits depend on whether this equipment isused against the head or on the wrist. The FCC SAR limit for extremity SARis 4.0W/kg (10g) and Body SAR is 1.6W/kg (1g). The highest SAR value reported under this this standard during product certification when properly Limb worn (0mm) on the extremity SAR is 1.57 w/kg.

This product does not support fast charging.



To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your phonenear your ear while the loudspeaker is in use.

EU Conformity Statement

 Hereby, DanuTech Europe Kft. declares that the radio equipment type iFLYTEK AINOTE 2is in compliance with Directive 2014/53/EU.


RF Exposure Information


This device has been tested and meets applicable limits for Radio Frequency (RF) exposure.

Power

Bluetooth	2402 – 2480 MHz	8dBm
Bluetooth LE	2402 – 2480 MHz	10dBm
WLAN	2412 – 2472MHz	18.5dBm
WLAN	5180-5240MHz	14.5dBm
WLAN	5260-5320MHz	14.5dBm
WLAN	5500-5700MHz	15.5dBm
WLAN	5745-5825MHz	15.5dBm

The device is restricted to indoor use only when operating in the 5150 to 5350 MHz frequency range.

	AT	BE	BG	CH	CY	CZ	DE
	DK	EE	EL	ES	FI	FR	HR
	HU	IE	IS	IT	LT	LI	LU
	LV	MT	NL	NO	PL	PT	RO
	SE	SK	TR	SI	UK(NI)		



The power delivered by the charger must be between min [5] Watts required by the radio equipment, and max [10] Watts in order to achieve the maximum charging speed.