

USER MANUAL



Category: String Lights

Model Number: SMA-SL-01

Domination Principle: Ble

APP: Surplife

Power Supply: Our Plug Makes Input AC 120V Reduced To DC 5V for Safety


Supported Driver IC: SM16703P, WS2812E, UC1903B, ASL140140, IC2811F, TM1814, WS2815B, WS2812B, SM16703 , SM16704, WS2811, UCS1903, SK6812, INK1003, UCS2904B

Working Temperature : -20~+55°C

Control Distance: Visible distance 30M


Dimension: 20.3cm/7.99in Diameter, 34.5cm/13.58in Diameter, 50cm/19.68in Diameter

Installation



Way 1:

- ① Roll the flexible star page until the two plastic laminates are in one plane;
- ② Open the buckle of the plastic plate, align the plastic plat;
- ③ Close the buckle;
- ④ Find the base and insert the top rod deeply into the bottom of the star.




Way 2:

- ① Roll the elastic star page until the two plastic laminates are on a flat surface;
- ② Open the buckle of the plastic plate, align the plastic plat;
- ③ Close the buckle;
- ④ Using some auxiliary tools (not included), hang the stars in the appropriate positions using the grooves in the plastic board.


Download Surplife APP

Download "Surplife" in App Store, register and make sure Bluetooth of mobile phone is turned on.




How to Connect to Surplife APP


Register/Login your Surplife account.




Enter "Surplife" app, tap "add device" or click "+" to add the device.



Rename the device and select a room for it.



Remote Control



FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.

Frequently Asked Questions

How to set up your Bluetooth LED string light?

- Enable your Bluetooth on your phone.
- Then power on the LED string light.
- Open "Surplife" App, the App can directly connect to the device. It can automatically match the light without other steps, and you can experience the smart light simply and quickly.

How can i do if connecting the Bluetooth device or adding new device failed?

Please power off the led string light, then turn it on again, if the problem can't solve, please restart the phone.

