



Install our lock on top

If you have a desktop lock on top, please move the desktop lock on top to avoid installation issues.

Install our lock on top (only if needed)

4

Connect wire connector and install back panel

A

Inside

B

Inside

C

Inside

D

Inside

Note: This wire connector can only be connected in one way.

EXPLOSIVE VIEW

Handle

Front panel

Mounting plate

Back panel

Screws

Latch

Handle

Battery cover

APP Guide

Version 1.0

ENGLISH

APP UNLOCK/LOCK

To unlock the lock, tap this icon once.

To lock the lock, press and hold on this icon.

Note: This will only work while you are within bluetooth range of the lock. Refer to Gateway Setup page for remote unlock/lock from phone.

FINGERPRINTS

To add a fingerprint follow these instructions:

Step1

Tap on "Fingerprints"

Step2

Tap on "Add Fingerprint"

Step3

Tap on Fingerprints

Step4

Follow instructions on app. Your finger will be asked to place your finger on the sensor 4 times.

Note: If you are having trouble adding a fingerprint, try the following:

- Ensure the sensor surface is clean.
- Try a different finger.
- Make sure you are not moving your finger too fast.
- Use one battery for a minute and then lock it.

LOCK SETTINGS

Here are some settings you should familiarize yourself with.

Under **Basics**, you can View and Change information such as Lock Name.

Gateway allows signal strength if Gateway is connected.

With **Remote Unlock** on and a Gateway connected, you can remotely unlock/lock your lock.

Import from another lock allows for the transfer of passcodes and fobs from one lock to another. Data will remove the lock from your account and clear any settings one the lock. You must be near the lock to do this.

7

Insert the key and test the installation

A

Outside

B

Outside

C

Outside

D

Outside

3

Install front panel and interior mounting plate

A

Outside

B

Outside

Note: Choose the screws that will fit the thickness of your door. Check labels on the screw bags.

PRODUCT OVERVIEW

FRONT PANEL

BACK PANEL

Keyhole cover

Fingerprint reader

Keypad & Fob Reader

Battery cover

Battery pack

Reset button

HOW TO REGISTER

Download the Smart Lock app from Google Play or App Store. Search "TT Lock."

Register

Step 1

Tap on register to get started 1

STEP 2

Fill out this and then tap "Get Code". You will be sent a verify your account! Once, you receive it, tap on "Register".

Note: The Smart Lock app is needed to use this lock. If this lock was professionally installed (or installed by someone other than the homeowner), make sure this step is performed by the homeowner.

PASSCODES

STEP 1

Tap on "Generate Passcode".

STEP 2

Enter a name for this lock. This will be used to the passcode page.

Here is a breakdown of the 6 different code types for different durations.

	Permanent	Timed	One-time
Erases all codes on lock	Permanent	Timed	One-time
Choose your own digits such as 4321 (permanent or timed)	Permanent	Timed	One-time
Lasts during scheduled hours weekly	Permanent	Timed	One-time

eKEYS

STEP 1

Tap on "Wireless Key Fob"

STEP 2

Tap on "Add Key Fob"

Note: A Wireless Key Fob can only connect to one lock.

WIRELESS KEY FOB

1. Tap on "Wireless Key Fob"

2. Tap on "Add Key Fob"

3. Choose validity period.

4. Follow instructions to pair the wireless key fob.

5. Use unlock and lock to interact with lock.

Note: A Wireless Key Fob can only connect to one lock.

6

Install the door handles

A

Inside

B

Inside

C

Inside

2

Install latch

A

Inside

B

Inside

Note: Latch hole must be horizontal

WHAT'S INCLUDED

Latch and strike

Exterior Assembly

Interior Assembly

Screws

PAIRING YOUR LOCK

STEP 1

Tap on the Home icon on the app.

STEP 2

Tap on "Add Lock"

STEP 3

Tap on "Next"

STEP 4

Tap on the blue plus sign.

Note: You may need to tap on lock keypad.

PASSCODES

Pay attention to the text when generating a code. You may experience issues if these instructions are not followed.

Note: To generate custom codes, you will need to be within bluetooth range of the lock unless a Gateway is connected.

Note: The above can only be used if the lock is connected to a Gateway. If the lock is not connected to a Gateway, the lock will not work.

AUTHORIZED ADMIN

Step1

Authorized Admins are similar to eKeys; however, an authorized admin can do the following:

1. Unlock/lock via the app.
2. Generate passcodes, IC cards, & fingerprints.
3. Adjust lock settings, auto-lock timer, & turn on/off the lock sound.

Step2

Enter recipient's username. It will be the phone number or email address used during registration.

INTEGRATIONS

Our locks work with the following software:

- Works with Google Assistant
- Works with Amazon Alexa

The Gateway bridges any nearby locks to your lock with allowing for remote control.

With the Gateway connected.

- Receive unlock notifications whenever you are.
- Check access logs whenever you need them.
- Generate, edit, or delete custom codes for your app for real time.
- Access the features of the webportal version of our app for real time.
- Check battery level remotely.

5

Install 4 AA batteries and battery cover

A

Inside

B

Inside

C

Inside

1

Adjust the backset of latch (if needed)

A

Hold the latch in front of the door hole, with the latch face flush against the door edge.

B

If the latch holes are centered in the door hole, no adjustment is required. Proceed to step 2. If the latch holes are NOT centered, adjust latch, see "Latch Adjustment."

C

Latch adjustment (only if needed)

ENGLISH

Installation Guide

Version 1.0

LOCK PAGE OVERVIEW

Unlock/Lock

Unlock/Lock using phone's bluetooth

Generate Passcode Page

Generate 6 different types of passcodes

eKey Page

View and modify current ekeys

Records Page

View entry times, attempts and methods

Settings Page

View and modify passcode

Send ekey

Set up and send ekeys

Cards/Fobs Page

Set up your fobs

Fingerprints Page

Set up fingerprints

Unlock/Lock Status

Lock status lock

Note: Some of these icons may not appear if the Gateway is not connected to the lock.

IC CARD / FOBs

1. Tap on "Cards".

2. Tap on "Add Card"

3. Choose the validity period of the lock.

4. Place the lock against the "your card".

5. If you hear "input successful", the fob can be used to unlock your lock.

To add a fob to your lock, follow these steps.

PASSAGE MODE & AUTO-LOCK

Step1

Auto-lock will automatically lock the lock when it has been opened after 5 second by default. This can be adjusted with Passage Mode and Auto-lock timer. Outlined below is how to adjust these settings related to auto-lock.

Step2

Select Passage Mode

Step3

Passage Mode disables auto-lock during a set schedule.

FAQ

Q: I entered a code or fingerprint incorrectly too many times and my lock will not accept any new inputs.

A: The lock will lock out for 5 minutes.

Q: How can I manually lock the lock?

A: Press and hold # to lock the lock.

Q: The batteries died before I could replace them.

A: Use the provided physical keys to open or plug in the batteries. The lock will be able to be able to enter and change the batteries.

Q: How can I reset the lock to factory default settings?

A: Refer to eKeys or Authorized Admin section on how to do this.

Not working like it should? Contact us with the following information for quicker resolution.

- Which product you do have?
- How long have you had our products for?
- How long have you had our products for?

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.