

Wireless Charger Station Instruction Manual

Please read the following carefully before using this device to ensure safe and proper usage.

Specifications

Input(Base): 5V/3A, 9V/3A, 12V/2.5A

Watch output: 2.5W Max

Earbuds output: 5W Max

Power bank Input(Base): 5V/3A, 9V/3A, 12V/2.5A

Power bank Input(USB-C): 5V/3A, 9V/2A

Power bank Output(USB-C): 5V/3A, 9V/2, 12V/1.5A

Power bank Capacity: 5000mAh/3.7V



Charging Your Device Using Your detachable magnetic power bank

IMPORTANT: Before using your power bank for the first time, fully charge it (when powered on, the four white LEDs remain illuminated).

Connect the supplied USB-C cable (or the cable that came with your device) to the power bank's USB port and to your device or place your phone that supports wireless charging onto the wireless charging area, Then begin charging.

When charging your device with a full power bank, four white LEDs will be illuminated. The white LEDs will shut off one by one as your device receives power. when the power bank is low in power, only one flashing LED will be illuminated until all power has been drained.

The fifth white LED will light up once you enter fast charging mode.

Checking Your Power bank Battery's Charging Status

Momentarily press the button on your power bank and the white LEDs will indicate its charge level. Four LEDs means that the power bank battery is fully charged, while one LED means that it's almost empty. Know before you go!

Recharging your power bank

To recharge your power bank, use the supplied USB cable to connect its USB-C port to a USB wall charging adapter or place it into the base that connect to a power source.

While recharging the power bank, the white LED indicators will light up.If there is one LED flashing, the charging is not completed. Once the power bank is fully charged, all four white LEDs are illuminated.

The fifth white LED will light up once you enter fast charging mode.

NOTE: For best results, do not connect the power bank to a computer's USB port.

We recommend using a wall charging adapter that supports fast charging protocols such as QC or PD.

Wireless Charging

Connect the USB-C cable to the Wireless Charger Station and connect the other end to a power source, then it is ready for wireless charging.
Ensure proper placement of your iWatch and earbuds on the designated charging areas for optimal performance.



Security advice

Attention

- Incorrect usage can cause explosions / danger of chemical burns.
- Damaged batteries can cause chemical burns when they come in contact with human skin.
- Do not disassemble the item.
- Never throw the item or parts of it into fire.
- Never expose the item to high temperature changes Hot/Cold, humidity or liquids.
- Do not use if the items or parts of it are damaged.
- Store in a clean and dry space.
- To maintain battery good health, the item should be recharged every 6 months. Battery will lose capacity when stored without charging.
- If the product gets very hot, please disconnect the item and do not use it.
- Do not put any bare metal objects on the surface of wireless charger when it is operating.

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: (1) Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. (4) Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator & your body.

