




Siren Connected Boat App Guide

Getting Started: Prior To Activation

Existing Siren Marine Customers

If you have previously paired your **ESN (serial number)** with your email please proceed to **Login**.

New Customers

If you have not yet created an account when you purchased a subscription from sirenmarine.com, you will be prompted to do so during registration. You must enter the ESN of your Siren Marine main device into your customer account on sirenmarine.com prior to activation.

Dealer & Installer

Please register with **Siren Marine Support** to obtain your **Dealer Login Credentials**.

Call **401.619.4774** or email **support@sirenmarine.com**.



Table of Contents


Account Registration	4
Profile Set-Up	5
The Home Screen	6
Add a Boat with Siren Device	7
Add a Boat without a Siren Device	9
View Maintenance on Yamaha Outboard Powered Boats.....	11
Record Maintenance on Yamaha Outboard Powered Boats	12
Record Maintenance on Boats without a Yamaha Outboard	13
Create a Float Plan	14
Siren Settings	15
Account Settings.....	16
Add a Secondary User to your Account	17
Find Boat Resources	18
Events.....	19
Adding A Wireless Sensor.....	20
Edit Home Screen	21
Low Power Mode.....	22
Tile Detail Pages	23
Arm Device	24
Arm Aboard.....	25
Disarm Device.....	25
Inbox	26
Creating A Geofence	27

Account Registration

If you already have a log-in, then open the Siren Connected Boat app and log in with your email and password.

If you do not already have a log in, tap “New Account Registration” at the bottom of the screen. Next, select if you’d like to create an account with your email address or if you’d like to sign in with Google or Apple.

Then, follow the prompts on the screen.



Profile Set-Up

Enter your profile details, agree to the three account creation conditions, and tap "Next" to create your account.

You will be sent an authentication email to confirm creation of your account.

The image displays three sequential screenshots of a mobile application's profile setup process.


Screen 1: Profile Setup (Initial)
The screen is titled "Profile" with a subtitle "You still need to enter a few more details." It features three input fields: "First name*", "Last name*", and "Country*" (a dropdown menu). At the bottom, there are three unchecked checkboxes for "I agree to our Terms & Conditions", "I agree to our Privacy Policy", and "I agree I am of legal age or have the consent of a legal guardian". A "Next" button is at the bottom, and a link "If you already have an account Click here" is at the very bottom.

Screen 2: Profile Setup (Filled)
The screen is titled "Profile" with a subtitle "You still need to enter a few more details." The input fields are now filled: "First name*" is "John", "Last name*" is "Doe", and "Country*" is "United States". The three checkboxes at the bottom are now checked. A "Next" button is at the bottom, and a link "If you already have an account Click here" is at the very bottom.

Screen 3: Mail sent
The screen shows the Siren Connected Boat logo and a blue wave graphic. It features an envelope icon in a circle, the text "Mail sent", and a subtitle "A link to reset your password has been sent." Below this, it says "Please check your email: test1234@gmail.com". There is a button labeled "Open Mail App" and a "Re-send" link. At the bottom is a "Back to login" button.

The Home Screen

The first thing you'll see when you open the Siren Marine app is the home screen. Here you can see all of your boat's information in a simple, intuitive dashboard.




Add a Boat with a Siren Device

Tap the three horizontal lines in the upper left corner of the app's home screen.

If you're installing a Siren device on a boat, tap "Add a boat with a Siren Device".

If your boat does not have a Siren device, tap "Add a Boat without a Siren Device".



Add a Boat with a Siren Device

Enter the details about your boat and add any optional information. This information will be used to give you a more personalized experience in the app and give you enhanced features like maintenance reminders and boat brand resources.

Enter in information about yourself and tap “Continue”. When you see the “Successfully Added” screen, tap “Done”.

The image displays three sequential smartphone screens from an application, illustrating the steps to add a boat with a siren device.

Screen 1: Add Boat
The screen is titled "Add Boat" with a back arrow and a progress indicator "2/5". It prompts the user to "Please enter boat information below." and shows a "20% complete" progress bar. The form is divided into "REQUIRED INFO" and "OPTIONAL INFO" sections. Required fields include Boat name*, Boat classification type*, Boat brand*, Power type*, Primary boating activity*, Engine brand*, Number of outboards*, State registration number, Hull ID, and Year. Optional information includes a "Continue" button at the bottom.

Screen 2: About Yourself
The screen is titled "About Yourself" with a back arrow and a progress indicator "4/5". It prompts the user to "Please verify and make any updates below." and shows a "60% complete" progress bar. It features a profile picture of a man. Fields include First name* (John), Last name* (Doe), Email* (john.doe@email.com), Address 1 (123 Street Place), Address 2, City (Anywhere), State (GA), ZIP (10000), and Cell phone number* ((555)555-5555). A "Continue" button is at the bottom.


Screen 3: Successfully Added
The screen displays a large circular icon with a compass rose and the text "SUCCESSFULLY ADDED!". Below this, it says "Your products have been successfully added to your account!" and includes a "4x display" badge. A "Done" button is at the bottom.

Add a Boat without a Siren Device (Yamaha Outboard Powered Boats Only)

Tap the three horizontal lines in the upper left corner of the app's home screen.

Tap "Add a boat without a Siren Device".

Enter Primary ID (PID) of your outboard. You can find your Primary ID (PID) on your warranty registration card or on the mounting bracket of your engine.



Add a Boat without a Siren Device (Yamaha Outboard Powered Boats Only)

Enter the details about your boat and add any optional information. This information will be used to give you a more personalized experience in the app and give you enhanced features like maintenance reminders, product updates, and boat brand resources.

Enter in information about yourself and tap "Continue". When you see the "Successfully Added" screen, tap "Done".

13:13

← Boat Info 2/6

Please enter boat information below.

10% complete



REQUIRED INFO

Boat name*
Life is Good

Boat classification type*
Offshore Center Console

Boat brand*
Boat Brand

Primary boating activity*
Cruising

Set Preferred dealer*
Favorite Dealer

Number of outboards*
5

OPTIONAL INFO

State registration number*
00000000000000

Hull ID
NTLCN401P920

Continue

13:13

← About Yourself 5/6

Please verify and make any updates below.

60% complete



First name*
John

Last name*
Doe

Email*
john.doe@email.com

Address 1
123 Street Place

Address 2

City
Anywhere

State
GA

ZIP
10000

Cell phone number*
(555)555-5555

Continue

13:13



SUCCESSFULLY ADDED!

Your products have been successfully added to your account!

Add to my



Done

View Maintenance on Yamaha Outboard Powered Boats

To view future and past maintenance activities, tap the “Maintenance” tab on the bottom navigation bar.

Here you will find your next scheduled maintenance service date. This date is based on the current engine hours of your Yamaha Outboard(s) and the last recorded maintenance activity.

Note: Owners of Yamaha Outboards with a connection to the NMEA or Yamaha Command Link Plus network and a Siren subscription will see their engine hours auto-populate. All other Yamaha Outboard owners can enter their current engine hours manually.




Record Maintenance on Yamaha Outboard Powered Boats

To record maintenance on any Yamaha Outboard, tap the “Maintenance” tab on the bottom navigation bar, tap the outboard that had maintenance performed, and tap “Record” on the next screen.

For multi-engine boats, if maintenance was performed on more than one outboard you will be able to add it at this time.

Enter the Service details including service type, date performed, the service provider, and attach any receipts you would like to add.

Note: Owners of Yamaha Outboards who service their motor at an authorized Yamaha Outboard dealer may see maintenance activities auto-populate in their account. Be sure to ask your Yamaha Outboard Dealer to record your service after each visit.




Record Maintenance on Boats without a Yamaha Outboard

To record maintenance on a boat without a Yamaha Outboard, tap the "Maintenance" tab on bottom navigation bar.

Enter the engine and service details performed and tap "Save".



Use this area to document all maintenance activities and set reminders for your next annual maintenance.



Your boat info will auto-populate from your account.

Enter in all trip information and select "Continue". Enter in all captain and passenger information and tap "Finish".

Remember to share this information with a friend or relative back on shore.





Siren Settings

Enter the Siren settings menu by tapping the “Siren” tab on the bottom navigation bar and then tapping the three dots icon on the top right of the screen.

Next, tap the “Siren Settings” menu option from the bottom pop-up window.

The “Siren Settings” menu gives you the ability to control preferences, alert options, and the information you see on your Siren app home screen.







Account Settings

To view account details, tap “Account” on the bottom navigation bar.

Here you will be able to view support materials, change login and communication preferences, and view product information on the boats in your account.

Tap “Siren 3 Pro” or “Siren 3” to view or change Siren account information, add Siren sensors, and update Siren system software.








Add a Secondary User to your Account

To add a secondary user to your account, tap “Account” from the bottom navigation bar.

Select “Your Products”, then tap “Siren 3 Pro” or “Siren 3” and “Add Secondary User” from the Siren Info screen.

Add the profile details for your secondary user along with permission preferences and tap “Send Invitation”.


Use this feature to invite anyone who might need access to your boat when you’re away – friends, neighbors, dock masters, etc.



Find Boat Resources

For owners of select boat brands, tap the “Account” option from the bottom navigation bar.

The “Boat Resources” section will appear for select brands, if available. Items that can be shown are owner’s manuals, videos, warranty information, and boat club details.




Events

The events page can be accessed by tapping the “Siren” tab from the bottom navigation bar and the tapping the clipboard icon in the top left.

The events page lists all alerts from every wired and wireless sensor that is being monitored by your Siren Marine unit.

Every event will display a timestamp and the date event occurred.




Adding A Wireless Sensor

To add a wireless sensor, tap the "Siren" tab on the bottom navigation bar, Then tap the three dot icon on the top and tap "Add Wireless Sensor".

The app will access the camera on your mobile device to scan the QR code on the back of the sensor.

Once scanned, name and select the sensor type then tap "Add".

Once added, the wireless sensor will automatically appear on your Siren page and in your monitoring screen options.





Edit Home Screen

You can edit your monitoring screen to add, remove, or edit input names. These settings only apply to hardwired sensors. Wireless sensors will also populate on this screen when paired.

Edit your monitoring screen by tapping “Siren Settings” from the “Siren” tab, then tap “Monitoring”.

You can change or edit the names of your wired and wireless sensors by tapping the pencil icon on the top right of the page.





Low Power Mode *(Siren 3 Pro Only)*

Low Power Mode reduces the amount of power your main Siren device uses when your battery voltage is low. You can select from ON, OFF or Auto. When selecting AUTO, you will be required to enter a battery voltage threshold that when met, the device will enter low power mode.

*Siren Marine main devices ship new with low power mode set to ON

When low power mode is enabled, wireless sensor communication and GPS check-in times will be limited



Tile Detail Pages

Each tile on the Siren page can be tapped on to see more detail. On the tile detail page, you can set parameters for the associated sensor and view historical graphs (where applicable) of data from that sensor.

Customizable
Parameters

Historical
Graphs




Arm Device

Arm and Disarm your system by tapping the Arm/Disarm Toggle on the bottom of the app homepage or the “Siren” tab.

Set your system to “Arm” while you are away to receive notifications for security breaches, geofence alerts, and other pre-selected alerts.


(Optional) Manual Arm/Disarm Switch

The gray wire included with Wiring Cable 1 is designated for a manual Arm and Disarm toggle switch (switch not supplied). Mount this Arm/Disarm toggle switch in a hidden area or at the helm. This gives you the option to manually arm and disarm the system as an alternative to using your Siren Connected Boat app. The Siren 3 Series is able to distinguish the current arm/disarm state so that no matter what position the switch is in, toggling the switch will change the arm state. Changing the arm/disarm status in the app will override the manual toggle switch’s designation.




Arm Aboard

Edit what sensors are being included in your Arm settings by tapping the “Siren” tab from the bottom navigation bar, then tapping the three dot menu at the top right. Then, tap “Siren Settings” and “Arm Aboard”.




Disarm Device

Set your system to “**Disarm**” to disable alerts on all sensors with the exception of battery, bilge, and high water. Siren Marine considers battery, bilge, and high-water alerts to be critical and cannot be disabled.





Inbox

Inbox messages are filtered into 3 different folder. Yamaha, News & Updates, and Siren. You can edit your messages by tapping “Edit” and tapping the messages you want to delete or mark as read.



Creating A Geofence

You can create new geofences or edit an existing geofences by tapping the “Siren” tab on the bottom navigation bar, then tapping the geofence icon on the top right corner of the map.





sirenmarine®
CONNECTED BOAT®

855.75.SIREN (855.757.4736)
support@sirenmarine.com
sirenmarine.com