


GPS Sport Watch

User Manual



1. PRODUCT INTRODUCTION&BUTTON DEFINITIONS



Button ① definition :

Power button

Short press: Short press once on the watch face interface to turn off the screen.

Short press once on the application list interface to return to the watch face interface. Short press once again to turn off the screen.

Long press for 2s: power on/off, restart, SOS (long press to display menu selection).

Press and hold for 12 seconds: force restart the device.

Button ② definition :

Return key/shortcut key:

Short press:

- A. Other pages return to the previous level/customized shortcut functions.
- B. Short press while the screen is idle to light up the screen.
- C. Pause/continue during exercise.
- D. Short press when there is an incoming call to mute.

Press and hold for 2 seconds: Open the voice assistant/custom shortcut function. Supplement: Customers can choose one of the return key/shortcut key. If the shortcut function is not set, short press to return to the previous level, and long press the voice assistant. If the shortcut function is set, follow the setting items to achieve it.

Definition of button③(sports button):

Short press:

- A. Enter the sports mode list
- B. Short press to light up the screen when the screen is off
- C. Long press for 2S during sports; stop and end the sports

Note:

Water sports refer to water sports such as swimming, diving, rafting, rowing, sailing, etc. In this mode, to prevent accidental touches by water drops, the touch function will be turned off by default during sports, and button operation will be preferred. You can also control it by unlocking the touch function.

Key definition in water sports mode:

Button①: Short press to unlock the touch function. After unlocking, if the interface has been flipped down, you can flip the page up through "button①".


Button②: Short press to pause the current sports mode. Short press again to continue the current sports and lock the touch screen.

Button③: Short press to flip the page down, long press to end the sports mode. (If the sports duration is too short, no data will be recorded. When the pop-up window prompts whether to end, short press "button③" to continue the sports. Short press "button②" to exit the sports.)

2.TOUCH SCREEN CONTROL DEFINITIONS


⌚ On the watch face interface, press and hold the watch face for 2-3 seconds to switch watch faces. Swipe left or right to switch watch faces, and click to select a watch face.

- ↓ Swipe down: Swipe down on the watch face interface to open the status bar
- ↑ Swipe up: Swipe up on the watch face interface to access the card shortcut function
- ← Swipe left: Swipe left on the watch face interface to enter the main menu interface
- Swipe right: Swipe right on the watch face interface to enter the notification information interface.



3.CHARGING



1. When the watch prompts that the battery is low, please charge it in time. The charging time is 2-3 hours.
2. The watch is magnetically charged. Align the charging contacts of the charging cable to the charging port of the watch to charge until the watch screen displays the charging prompt.
3. When charging, in order to ensure stable charging, the watch will turn off the screen to charge. Click the button to wake up the watch. When the battery of the watch is too low, it takes 3-5 minutes to wake up the watch. This is normal. Please wait for 5 minutes before checking the charging status of the watch.
4. Please use a charger with a rated output voltage of 5V and a rated output current of 0.5A-2A or a computer USB port to charge the watch.
5. When the watch is not used for a long time, please fully charge it and turn it off for storage. Do not store it for a long time in a low-power state. To avoid damaging the battery due to long-term low-power storage.



4.GPS USAGE

1. In order to get a better experience, please connect and bind the APP when using the GPS function for the first time. Within about 3 minutes after binding, the "GloryFitPro" app will send GPS ephemeris orbit and other data to the watch via Bluetooth in the background. After the ephemeris is successfully sent, the GPS positioning time can be greatly shortened. If the sending is not successful, the watch will pop up the "AGPS has expired" reminder when you open the sports with GPS function for the first time. AGPS expiration will cause the positioning time to be too long, affecting the positioning experience. You can try to unbind and bind the watch APP again. And wait for 2 minutes before trying to use the GPS function. If APGS is sent successfully, the "AGPS has expired" reminder will not pop up when you open the GPS function for the first time.
2. At 09:00 every morning, the "GloryFitPro" app will re-acquire the latest GPS ephemeris data of the day. The watch obtains the latest GPS ephemeris data when Bluetooth is connected.
3. The GPS positioning time is too long and whether the GPS track drifts are greatly affected by environmental factors. Choosing an open place or away from high-rise buildings will help GPS to quickly locate and reduce the deviation of the track.
4. Save the data after the exercise, and the APP will synchronize the exercise data. The exercise trajectory and exercise data can be queried in detail on the APP.

5.GPS USAGE INTERFACE



AGPS has expired


No Location

Get Location

Sports with location

6.APP CONNECTION

Scan the watch QR code or go to major application markets to download and install the "GloryFitPro" APP. When you open the APP for the first time, a permission pop-up window will pop up. Please click "Allow" to ensure that the APP can obtain the corresponding permissions.



During the connection process, a pop-up window will pop up to confirm the pairing connection with the watch and mobile phone. Please click to confirm the pairing. After the connection is successful, the call icon and data connection icon in the watch status bar will turn green. In gray, it is not connected.



BT Call and APP
Disconnected



APP Connected
BT Call Disconnected



APP Connected
BT Call Connected

7.UNBINDING APP

IOS: Find "Unbind" in the "Device" interface of the APP and click on it to enter the "Settings-Bluetooth" interface of the mobile phone system. Click on the ! on the right of the device and select "Forget this device" to unbind it from the mobile phone system. Make sure it is no longer connected to the mobile phone, otherwise it will not be able to connect again next time.

Android: Find "Unbind" in the "Device" interface of the APP and click on it to disconnect from the mobile phone

8.NOTES

- 1, Prohibit charging in the case of water damage.
- 2, This device is not a medical device, the data and information provided are for reference only.
- 3, Hot water shower or sauna etc. can not be worn to prevent water vapor intrusion. If the watch is damaged by water ingress due to use not according to the instructions, we will not provide free warranty.

- 4,Do not place the device in direct sunlight, such as car dashboard or window sill.
- 5,Do not place the device close to heat sources or naked flame sources, such as induction cookers, microwave ovens, ovens, water heaters, stoves, candles, or other places where high temperatures may be generated.
- 6, Please do not allow children or pets to swallow or bite the equipment or its accessories, so as not to cause injury to them or lead to equipment failure.
- 7, This equipment is not a toy, children should use the equipment under adult supervision.
- 8,This device is equipped with a non-removable built-in battery, please do not replace the battery by yourself.
- 9, If the watch has been in contact with water, after leaving the water source, please dry the water stains on the watch surface in a timely manner. If there is too much residual water stains in the sound chamber of the speaker and it is not discharged in time, the sound effect may be affected. Please find the sound hole of the speaker and shake out the residual water in the sound cavity in time.

FCC Caution :

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class

B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not

installed and used in accordance with the instructions, may cause harmful interference


to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device

can be used in portable exposure condition without restriction.

1. 产品介绍及按键定义



按键①定义:

开机键

短按: 表盘界面短按一次熄屏, 应用列表界面短按一次返回表盘界面, 再次短按熄屏。

长按2s: 开机/关机、重启、SOS (长按出现菜单选择)。

长按12s: 强制重启设备。

按键②定义:

返回键/快捷键:

短按:

A. 其他页面返回上一级/自定义快捷功能。

B. 息屏下短按点亮屏幕。

C. 运动中暂停/继续。

D. 来电时短按, 静音。

长按2秒: 打开语音助手/自定义快捷功能。

补充: 返回键/快捷键二选一, 客户可自行设置选择, 未设置快捷功能的情况下, 短按返回上一级, 长按语音助手, 如设置快捷功能后, 按照设置项实现。

按键③定义（运动键）：

短按：

- A. 进入运动模式列表。
- B. 息屏下短按点亮屏幕。
- C. 在运动中长按2S；停止并结束运动

注意：

水上运动指如游泳、潜水、跳水、漂流、赛艇、帆船等水上运动，在此模式下为防止水滴误触，运动中会默认关闭触摸功能，优先采用按键操作，也可通过解锁触摸功能来实现操控。

水上运动模式下按键定义：

按键①：短按一下解锁触摸功能。解锁后，如界面已下翻，可通过“按键①”上翻页面。

按键②：短按一下暂停当前运动模式。再次短按继续当前运动且锁定触屏。

按键③：短按一下为下翻页面，长按结束运动模式。（如遇运动时长过短，不会记录数据，提示是否结束的弹窗时，短按“按键③”继续运动。短按“按键②”退出运动。）


2. 触屏操控定义

↓ 下划：表盘界面下划打开状态栏

↑ 上划：表盘界面上划卡片快捷功能

← 左划：表盘界面左划进入到主菜单界面


→ 右划：表盘界面右划进入到通知信息界面



⌚ 表盘界面长按表盘2-3秒可切换表盘，左右划动选择表盘，
单击选定表盘。

3. 充电

1. 当手表提示电量低时, 请及时充电, 充电时长2-3小时。
2. 手表是磁吸式充电, 将充电线的充电触点对准手表充电口进行充电, 直到手表屏幕显示充电提示。
3. 充电时, 为了保证充电稳定, 手表会熄屏充电, 点击按键可以唤醒手表, 当手表电量过低时, 需要充电3-5分钟才会唤醒手表, 这属于正常情况, 请等待5分钟后再查看手表充电情况。
4. 请使用额定输出电压5V、额定输出电流0.5A-2A以内的充电器或者电脑USB接口为手表充电。
5. 手表长时间不使用时, 请充满电后关机存放。切勿在亏电状态下长时间存放。以免长时期亏电存放损坏电池。



4. GPS使用

1. 为了获得更好的体验, 第一次使用GPS功能时, 请先连接绑定APP。在绑定后约3分钟内, “GloryFitPro” app会在后台会通过蓝牙方式下发GPS星历轨道等数据到手表上, 下发星历成功后可以大幅度缩短GPS定位时长。如未下发成功, 首次打开带GPS功能的运动, 手表将会弹出“AGPS已过期”提醒。AGPS过期会导致定位时间过长, 影响定位体验。可以尝试重新解绑并再次绑定手表APP。并等待2分钟后再尝试使用GPS功能。如APGS下发成功, 首次打开GPS功能, 将不会弹出“AGPS已过期”提醒。
2. 每天早晨09: 00时“GloryFitPro” app会重新获取当天最新的GPS星历数据。手表在蓝牙有连接状态下, 获取到最新GPS星历数据。
3. GPS定位时间过长和GPS轨迹是否有漂移, 受环境影响因素较大, 选择在空旷地方或远离高层楼群有助于GPS能快速定位和减少轨迹的偏移。
4. 运动结束后保存数据, APP将会同步运动数据。运动轨迹和运动数据可以在APP端查询详细。

5. GPS使用界面



AGPS已过期提示



GPS未定位




GPS已定位



已定位运动中

6. APP连接

扫描手表二维码或进入各大应用市场下载并安装“GloryFitPro”APP。首次打开APP，会弹出权限弹窗提醒。请点击“允许”，确保APP能获取到对应的权限。



扫描
手表上的二维码

连接过程中会有弹出确认与手表、手机配对连接等弹窗提示，请点击确认配对。
连接成功后手表状态栏的通话图标与数据连接图标变成绿色。灰色状态下为未连接。



蓝牙未连接
APP未连接



已连接APP
未连接通话蓝牙



已连接APP
已连接通话蓝牙

7. APP解绑

IOS: 在APP“设备”界面找到“解绑”点击解绑后进入手机系统“设置-蓝牙”界面，点击设备右边的感叹号，然后选择“忽略此设备”，可从手机系统中解绑，确保不再和手机连接，否则下次无法再次连接。

Android: 在APP“设备”界面找到“解绑”点击解绑即可解除与手机的连接。

8. 注意事项

1. 禁止在有水渍的情况下充电。
2. 本设备非医疗设备，所提供的数据及信息仅供参考。
3. 热水淋浴或桑拿等不能佩戴，防止蒸气入侵。如因不按指示使用导致手表进水损坏，本公司不作免费保修。
4. 请勿将设备放置在阳光直射的地方，如汽车仪表盘或窗台处。
5. 请勿将设备靠近热源或裸露的火源，如电磁炉、微波炉、烤箱、热水器、炉火、蜡烛或其它可能产生高温的地方。
6. 请勿让儿童或宠物吞咬设备或其配件，以免对其造成伤害或导致设备故障。
7. 本设备非玩具，儿童应在成人的监护下使用设备。
8. 本设备配有不可拆卸的内置电池，请勿自行更换电池。
9. 如手表接触过水后，离开水源后，请及时擦干手表表面水渍，如扬声器音腔内残余水渍过多，未及时排出，可能会影响声音效果。请找到喇叭出音孔，及时甩出音腔内残余水渍。