



What's in the box

Microphone, Lens, microSD card slot *16-256GB Class 10 supported (sold separately), Speaker, Reset Button, Power Input, Screw package *1

LED Light Guide

	Solid Red	Camera initializing
	Flashing Blue	Camera is ready for setup
	Blue and Red Alternating	Connecting to internet
	Solid Blue	Camera is online

Set up the Camera

Step 1
Connect the camera to power with the included power cable and power

Step 2
Scan the QR Code to download CareCam Pro APP
Download the "CareCam Pro" APP from the App Store (iOS devices) or Google Play (Android devices).

Step 3.
Connect your phone to a WiFi network and have Bluetooth enabled

Step 4
Open the APP, enter your email and password to log in. If you do not have an account, please complete the account registration first, and then you can enter the APP.

Step 5
Click the "+" in the upper right corner of the APP to add a camera.

Step 6
Please click on the discovered Bluetooth device.

Step 7
Complete device binding according to APP guidance.

Step 8
Device added successfully. You can name the device.

2 3 4 5 6 7 8

Mounting the camera

The camera can be placed on a table or a shelf, or can be mounted on a wall or ceiling. Choose a location and height that meets your viewing requirements and is within reach of a power outlet and is not too far away from the router.

Note: Please ensure that the camera maintains a minimum distance of 0.7ft/0.2m from any objects or walls to prevent infrared reflection, which could affect the performance of night vision.

Install on a wall

1 Mark the screw position on the wall with the drill template and drill 2 pilot holes

2 Drill the 2 screws in and leave a space of 1.5mm. Attach the camera base onto the 2 screws to secure the camera

Record on a microSD card

Insert a microSD card and format it in camera setting menu, which allows camera to record locally even if camera is disconnected from the internet.

Frequently Asked Questions

I cannot connect the camera to the Internet

Check the following steps:

- Ensure Wi-Fi password or SSID is correct
- Reset the camera and try again
- Try placing the camera as closely to the router as possible
- Ensure camera is powered on and the indicator is flashing in Blue before starting to connect
- Ensure Bluetooth is turned on your phone and Bluetooth permission is allowed for APP
- If the above steps don't help, contact our professional technical support via phone, email or live chat

What can I do if the camera keeps getting offline?

How to record on microSD card?

- Ensure the microSD card is installed in the correct direction
- Format the microSD card in APP to enable recording
- After the card is formatted, choose to record all-day or by incident only in the 'Manage Storage' menu
- If the camera does not detect the microSD card, try formatting the card to FAT32 using a PC

What can I do if the camera stopped working?

What can I do if I receive too many notifications?

Storage Option

In APP, subscribe to a cloud storage plan to back up your footage in encrypted data center, to ensure that you still have critical footages even if camera is stolen or broken.

FCC COMPLIANCE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1- this device may not cause harmful interference.
- 2- this device must accept any interference received, including interference that may cause undesired operation.

The manufacturer is not responsible for any radio or tv interference caused by unauthorized modifications or change to this equipment. Such modifications or change could void the user's authority to operate the equipment.

IMPORTANT PRODUCT SAFETY INFORMATION

Read all instructions and safety information before use. SAFETY INFORMATION FAILURE TO FOLLOW THESE SAFETY INSTRUCTIONS COULD RESULT IN FIRE, ELECTRIC SHOCK, OR OTHER INJURY OR DAMAGE

Alaga K10 Indoor Cam and its accessories are for indoor use only. Do not expose your device or adapter to liquids. If your device or adapter gets wet, carefully unplug all cables without getting your hands wet and wait for the device and adapter to dry completely before plugging them in again. Do not attempt to dry your device or adapter with an external heat source, such as a microwave oven or a hair dryer. If the device or adapter appears damaged, discontinue use immediately. Use only the adapter provided by the manufacturer. To avoid risk of electric shock, do not touch your device or any wires connected to your device during a lightning storm.

THIS DEVICE IS NOT A TOY. Children can get strangled in cords. Keep cords out of the reach of children (more than 3ft away).

NOTICE

This product is designed and manufactured with high quality materials and components, which can be recycled and reused.

This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment. For information on disposal and recycling of this product, contact your local municipality, disposal service, or the shop where you bought this product.

9 10 11 12 13 14 15 16