


USER MANUAL



SmartTag Compass Bluetooth Finder





- Pocket Sized
- MFI Certified

Double sided accordion fold

Accordion



Emerson Compass Bluetooth Finder User Manual	Quick instructions	Quick Instructions	Main Functions	Instructions For Device Button	Instructions For Device Button	FAQ
 <small>Works with Apple Find My</small> <small>Made for iPhone iPad Apple Watch</small>	<p>❶ Turn On The Device The device will beep after install the battery, this indicates that the device has been successfully activated.</p> <p>❷ Pair The Device</p> <ul style="list-style-type: none">• Open the Find My app.• Hold the device close to your iPhone, tap the Items tab, tap + and then Add Other Item.• Tap Connect.• Type a name for your device, select an emoji.• Tap Agree to acknowledge that this item will be linked to your Apple ID.• Tap Finish. <p>❸ Remove The Device</p> <ul style="list-style-type: none">• Open the Find My app, tap the Items tab, then tap your item.• Tap Remove Item and then tap Remove to Complete the operation.	<p>Note: After removing the device in the app, the device will beep, it will not turn off and will be in the pairing mode. If there is no re-pairing within 10 minutes, the device will enter the sleep state, and it is difficult to pair at this time. If you need to pair the device, you need to click the device button twice quick, and then the device will beep, at this point, the device enters the pairing state and can be re-paired with the app</p> <p>❶ Locate Your Item If your missing item isn't nearby, the Find My app can still help you track it down using the FindMy network— hundreds of millions of iPhone, iPad, and Mac devices around the world. Nearby devices securely send the location of your missing device to iCloud, then you can see where it is in the Find My app. It's all anonymous and encrypted to protect everyone's privacy.</p>	<p>❷ Play Sound Open the Find My app, tap the Items tab, then tap your item. Click Play Sound, and the device will beep, so you can find the item easily.</p> <p>❶ Power On After installing the battery, the device will be turned on status.</p> <p>❷ Device Status Confirmation Double-click the device button, the device will beep, indicating that the device is working. If the device does not ring, the device is off. Long press the button for five seconds to turn it on.</p> <p>❸ The device enters the pairing state again After removing the device in the app, the device will beep, it will not turn off and will be in the pairing mode. If there is no</p>	<p>re-pairing within 10 minutes, the device will enter the sleep state, and it is difficult to pair at this time. If you need to pair the device, you need to click the device button twice quick, and then the device will beep, at this point, the device enters the pairing state and can be re-paired with the app.</p> <p>❷ Factory Reset First, remove the item from Find My app then, after the device is powered on, double-click the device button. The device will beep. Long press the device button for five seconds, device beep , continue to press three seconds until the device beeps again. Release the button to complete factory reset. The device can now be paired.</p>	<p>❸ Power Off When the device is on, press the device button 5 times in 2 seconds. The device will beep, the device will be powered off.</p>  <p>❶ When Can The Device Be Located? When an item is separated from its owner for a period of time, it can be found by other Apple devices that are part of the Find My network, and the owner can start to get the location of the device.</p>	<p>❷ How To Confirm Whether The Device Has Been Turned On? Double-click the device button, the device will beep, indicating that the device is working. If the device does not ring, the device is off. Long press the button for five seconds to turn it on.</p> <p>❸ How Is The Device Designed To Discourage Unwanted Tracking? If any Find My network accessory separated from its owner is seen moving with you over time, you'll be <i>Notified in one of Two Ways</i>:</p> <p>❶ If you have an iPhone, iPad, or iPod touch, Find My will send a notification to your Apple device. This feature is available on iOS or iPadOS 14.5 or later.</p>

FAQ	FAQ	FAQ	FAQ	FCC Regulatory Compliance	FCC Regulatory Compliance	Warranty Registration	
<p>❸ If you don't have an iOS device or a smartphone, a Find My network accessory that isn't with its owner for a period of time will emit a sound when it's moved. These features were created specially to discourage people from trying to track you without your knowledge.</p> <p>❸ How Is My Privacy Protected? Only you can see where your item is. Your location data and history are never stored on the item itself. Devices that relay the location of your item also stay anonymous, and that location data is encrypted every step of the way. So not even Apple knows the location of your device or the identity of the device that helps find it.</p>	<p>❷ How To Replace The Battery:</p> <ol style="list-style-type: none">❶ Open the device from the notch side.❷ Replace the battery with a new one. (Positive pole upward).❸ Assemble the device and you can start to use it.  <p>❸ What Is The Find My Network? And How Does It Work? The Apple Find My network provides an easy, secure way to locate compatible personal items on a map using the Find My app on your iPhone, iPad, iPod</p>	<p>touch, Mac, or the Find Items app on Apple Watch. Simply pair your compatible product with the Apple Find My app to view it right along side your Apple devices. If your item ever goes missing, you can put it in Lost Mode to display a message and contact information to anyone who might find it. The Find My network is encrypted and anonymous, so no one else, not even Apple, can view its location. When pairing a device with Find my app, the phone will link to the Apple server. Pairing may fail because of network problems. The following actions are recommended</p> <p>❶ Change The Phone's Network, such as switching between WiFi and mobile network.</p> <p>❷ Factory Reset For The Device: When the device is powered on, double-click the device</p>	<p>button. The device will beep, Long press the device button for five seconds, device beep and continue to press three seconds until the device beeps again. Release the button to complete factory reset.</p> <p>❷ Enable Lost Mode</p> <ul style="list-style-type: none">• Open the Find My app, tap the Items tab, then tap your item.• Under Lost Mode, tap Enable.• Read the instructions, tap Continue and enter a phone number or email address.• Confirm the information, customize the lost message, and tap Activate to complete the setup.	<p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation.</p> <p>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to</p>	<p>try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none">- Reorient or relocate the receiving antenna.- Increase the separation between the equipment and receiver.- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.- Consult the dealer or an experienced radio/TV technician for help <p>NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.</p> 	 <p>Please register your product, if you do not register, Your product will not be covered in the warranty</p> <p>Support</p> <p>Manufacturer: IAI Smart Inc E-mail: support@emersonsmart.com Website: www.emersonsmart.com</p> <p>This product has been manufactured and sold under the responsibility of IAI Smart Inc., Emerson logo is licensed by IAI Smart Inc. Further information at emersonsmart.com. All other products, service marks, Companies, trademarks, trade or product names and logos references herein are the Property of their Respective owners.</p>	