



INSTRUCTION FOR DC MOTOR CEILING FAN

REMOTE CONTROL



INNOVATION•ENERGY-SAVING•FUTURE

WIRING SCHEMATIC DIAGRAM FOR RECEIVER




POWER PARAMETER LIST

Voltage	Fan(max)	Lamp(max)
110V-240V		

With the memory function, the controller can save the status(light and direction)while supply power off and resume to the original after reload the power supply.

FUNCTIONINSTRUCTION OF Emitter



- ① LED indicated light
- ② Fan/lighting off
- ③ Lighting on/off
- ④ Fan forward rotation
- ⑤ Fan reversal
- ⑥ natural wind
- ⑦ Fan off
- ⑧ Fan gear button
- ⑨ Timed 1/2/4/8 hour
- ⑩ Timed for 1 minute
- ⑪ Color temperature switching
- ⑫ Two 1.5V AAA batteries

1. Connecting mode is a mode used to connect the remote to the receiver. Turn ON the power supply and within 5 seconds press and hold the power button "⑩" in the direction of the receiver. It will load after two "beep" sounds. This means the connection is successful and will work normally(PS: Connecting mode is not accepted after turning ON the power supply over 3 seconds,please turn off the power supply and try it again)

2. When the remote cannot control the receiver, please check that the battery is positioned correctly in the battery slot and ensure they have a charge.

3. When the remote cannot control the receiver, please check if there are any remote control devices nearby, and check if they are working, which could be disrupting the connection with the remote.

4. The low voltage of the battery will affect the sensitivity of the remote and the signal reception (the indicated light getting dimmer is a warning when the battery is low). Replace the battery when this accords.

5. Please remove the batteries if the remote is not used long.

6. The maximum load of lighting see the above "POWER PARAMETERLIST"
PS: please connect the ground wire correctly, otherwise it may cause the light micro-light or flash.

7. When installing the fan, the fan ceiling cover don't press the antenna(or other wire), it is easy to breakdown the wire and short-circuited.

8. Please do not use any transmission or dimmer.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.