

Product List



FCC ID: 2BN8K-BCT-9306

Coaster pager		Touch keyboard	
Pager frequency	433.92Mhz	Keyboard Power Supply	DC12V/2A
Pager dimension	80x12mm / 3.15x0.47in	Keyboard frequency	433.92MHZ
Pager weight	50g	Transmit distance	300 meters in open field
Shell material	ABS Plastic	Keyboard weight	265g
Color	Wine red	Low power indicator	LO
Prompt mode	Ring, vibration, flash	Keyboard dimension	190x150x26mm / 7.5x6x1.02in
Label OEM	Customized	Color	Black
Display	3 digit, LED	Keyboard Type	Touch operation
Pager battery	Built-in 3.7V lithium polymer battery	Transmit Power	240mW
	Low battery indicator	Manufacturer	Wirelesslinkx
Standby Time	20 hours	Model	BCT-9306

Instructions

1. Charging: Before using, please connect the charging base to power, and put the pagers stacked on the charger for 20 minutes to charge. Before doing any setting, the pagers have to be charged on the charging base. After taking the pager off the base, within 5 seconds the setting can be done. If the setting failed, put the pager back to the charger and take it off again to repeat the setting.

Pager programming can only be accessed in 5 seconds after the charger base is connected to power. After connected to power, when the display shows 0, within 5 seconds, press back button once, and then press CALL button once till the screen shows "F1". If it passes 5 seconds and can not access to F1, please disconnect the power and connect the power, and repeat operation above.

2. Switch Off Pager: Connect the charging base to power, and put the pagers on the charging base. Input 999 on the keyboard and call the pagers. And all pagers will be switched off. Pagers need to be paired with keyboard first.

3. Keyboard ID Setting: First connect the charging base to power. After the display shows 0, within 5 seconds, press back button once, and then press CALL button once till the screen shows "F1". If the screen doesn't show F1, please disconnect the power and connect the power, After the display shows 0, and press BACK button and press CALL button. When the screen shows F1, press the call button to enter, the screen shows "0". This is keyboard ID number. Press the number buttons to change the displayed number. And press the call button to save and it will automatically return to F1. Press BACK button to exit. If keyboard ID is changed, all pagers need to be paired with the keyboard again.

4. Pager Number Setting: All the pagers must be charged on the base first. First connect the charging base to power. After the display shows 0, within 5 seconds, press back button once, and then press CALL button once till the screen shows "F1". If the screen doesn't show F1, please disconnect the power and connect the power, and repeat operation above. When the screen shows F1, press number 2 on the keyboard, and the screen shows "F2". Press the call button to enter. And the screen shows "0". Press the number buttons to change the displayed number. This is pager number. Take off one charging pager now, and press the call button within 5 seconds. If the pager flashes and beeps, pairing is successful. If failed, you will need to put the pager back on top of the charging stack again and repeat the operation above.

5. Pager Beep / Shake Time Setting: All the pagers must be charged on the base first. First connect the charging base to power.

After the display shows 0, within 5 seconds, press back button once, and then press CALL button once till the screen shows "F1". If the screen doesn't show F1, please disconnect the power and connect the power, and repeat operation above. When the screen shows F1, press number 3 on the keyboard, and the screen shows "F3". Press the call button to enter. And the screen shows "0". Press the number buttons to change the displayed number. This is pager beeping time. Number 1 means pagers will beep or shake for 1 second. 250 seconds is the maximum beeping / shaking time. Take off one charging pager now, and press the call button within 5 seconds. If the pager flashes and beeps, pairing is successful. If failed, you will need to put the pager back on top of the charging stack again and repeat the operation above.

6. Pager Beeping Speed Setting: All the pagers must be charged on the base first. First connect the charging base to power.

After the display shows 0, within 5 seconds, press back button once, and then press CALL button once till the screen shows "F1". If the screen doesn't show F1, please disconnect the power and connect the power, and repeat operation above. When the screen shows F1, press number 4 on the keyboard, and the screen shows "F4". Press the call button to enter. And the screen shows "0". Press the number buttons to change the displayed number. 0 means no beep; number 1 means slow beep, number 2 means normal speed beep and number 3 means fast beep when called. Take off one charging pager now, and press the call button within 5 seconds. If the pager flashes and beeps, pairing is successful. If failed, you will need to put the pager back on top of the charging stack again and repeat the operation above.

7. Pager Shake Setting: All the pagers must be charged on the base first. First connect the charging base to power.

After the display shows 0, within 5 seconds, press back button once, and then press CALL button once till the screen shows "F1". If the screen doesn't show F1, please disconnect the power and connect the power, and repeat operation above. When the screen shows F1, press number 5 on the keyboard, and the screen shows "F5". Press the call button to enter. And the screen shows "0". Press the number buttons to change the displayed number. 0 means no shake, and other numbers mean pager will shake when called. Take off one charging pager now, and press the call button within 5 seconds. If the pager flashes and beeps, pairing is successful. If failed, you will need to put the pager back on top of the charging stack again and repeat the operation above.

8. Pager Flash Speed Setting: All the pagers must be charged on the base first. First connect the charging base to power.

After the display shows 0, within 5 seconds, press back button once, and then press CALL button once till the screen shows "F1". If the screen doesn't show F1, please disconnect the power and connect the power, and repeat operation above. When the screen shows F1, press number 6 on the keyboard, and the screen shows "F6". Press the call button to enter. And the screen shows "0". Press the number buttons to change the displayed number. 0 means no flash; number 1 means normal speed flash, number 2 means fast flash and number 3 means slowly flash when called. Take off one charging pager now, and press the call button within 5 seconds. If the pager flashes and beeps, pairing is successful. If failed, you will need to put the pager back on top of the charging stack again and repeat the operation above.

Note: 2 and more keyboards can call one pager. Need to change the keyboards' ID to the same and pair with the pagers again.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.