

INSTRUCTION

Button Description

1. 4 Red Battery indicator lights
2. 3White Timer indicator lights
3. Power light
4. Power button
5. "+"button
6. "-"button
7. Type-c charging port

How to connect and use the speakers:

1. Press and hold the Power Button for 5 seconds to turn on or turn off the speaker and blue light slow flashing
2. Enable the Bluetooth mode on your phone, tablet or other Bluetooth compatible device and set it to search.
3. Select "DR-6688" and pair it. When you connected successful, you can hear "connected".
4. Short press the "power"button 1 time to pause/play music
5. Timing function. Double-click the "Power"button. Double-click once, one white light turns on, and the timing is 2 hours;double-click again, two white lights turn on, and the timing is 4 hours;double-click a third time, three white lights turn on, and the timing is 6 hours Double-click once more to cancel the timing, and the setting is cyclic.
6. Short press the "+"or "-" to play Next/Previous Track
7. Press and hold the "+"or "-" for 3seconds to Increase/ Decrease the volume
8. Press 2 clicks "-" to turn on/off the LED breathing light

SPECIFICATION:

BT Version:BT V5.4 **BT Range:**33ft

Charging Time:3 hour

Charging Port:Type-C

Speaker Output Power:10W **Horn parameters:**10W/4Ω

Frequency range:20Hz-20KHz

Wireless transmission frequency:2400-2483.5MHz

(Note:Battery life &charging time may vary based on usage &types of devices used.

LED Indicator Status

Power on:The blue light blinks slowly

Successful connection:blue light blinks 5S

Solar charging:The blue light turns to red and stays

onUSB charging power display:4 red lights, 1 red light is 25%, 2 red lights are 50%, 3 red lights are 75%, and

4 red lights are 100%.

Timing:One white light turns on, and the timing is 2 hours;Two white lights turn on, and the timing is 4 hours;Three white lights turn on, and the timing is 6 hours.

TWS connection:

TWS connection is only applicable to two "DR-6688" speakers.

1. Make sure that the phone is not linked to any speaker.
2. Make sure that both speakers are turned on.
3. Double-click the "+"button on a speaker to pair the two speakers together. At

this time, there will be a successful pairing sound.

4. Finally, you search for the device name "DR-6688" on your phone and connect. Hearing the "connected"

sound indicates that the connection is successful. At this time, you can use both speakers to play at the same time and get a full stereo effect

5. If you want to cancel the TWS connection, select any speaker and double-click the "+" button to cancel the pairing. Tip: Use the same Bluetooth name and pair in Bluetooth mode

TROUBLE SHOOTING

1. NO POWER

Recharge your speaker using the Type-C cable. If the problem persists, try another Type-C cable.

2. NO RESPONSE FROM THE UNIT

Ensure your Bluetooth device supports an A2DP, HSP, or HFP profile. Check if both devices are paired and

connected to each other. Restart the device and try to reconnect

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction