

armali

Massage Chair


Operation Manual



Armali Massage Chair
WhatsApp Business Account



Scan this code to start a WhatsApp chat with Armali
Massage Chair company



E-mail: service@armalimassagechair.com
Website: www.armalimassagechair.com

1 Move the chair with one person



1. Gently push down headrest side
2. Push forward using the two wheels underneath the chair

Table of content

Safety Precautions ----- 2 - 5

Precautions before use ----- 6

Functions and methods of use ----- 7 - 11

How to move chair - one/two people -- 12

2 Move the chair with two people



1. Please grasp the bottom of the side panel (not the base) with your hand and lift it
2. Due to its heavy weight, the chair must be moved by two or more people. Please handle with care to avoid straining your back



Security considerations

- Please read this [Safety Precautions] carefully before use and use this product correctly.
- The precautions here suggest safe and correct ways to use the product to prevent possible harm or damage to the product, the user, and others.
- The precautions are distinguished by two warning methods of [Warning] and [Caution] according to the size and severity of harm or damage that may be caused by improper operation. Content-related safety is very important, please be sure to follow.

⚠ Warn

Misuse may cause serious injury to the user.

⚠ Be careful

Incorrect operation may cause user injury and material damage.

※ Property damage refers to damages related to houses, property, livestock, pets, etc.

□ As the picture shows □



This logo is for warning or attention. (The left picture is generally used after warning or attention.)



This symbol ⊗ is to inform the prohibited content, and the figure is a description of the specific prohibited content.
(Disassembly is prohibited on the left)



This logo is mandatory or necessary.

- After reading, please keep it in a place where the user can see it at any time.

⚠ Warn



● Smoke, abnormal sound (abnormal state), please immediately disconnect the power to confirm the safety, please contact the dealer for repair. It is strictly forbidden to repair yourself to avoid danger.



● Water inside the host.
● The debris falls into the host.
● Heavy falls, falls or the casing is damaged.

⚠ Be careful



must be observed

● If you feel abnormal during use, stop using it immediately and consult a doctor.
● This product should be placed on a flat ground to avoid injury.
● Before using this product, please confirm that the power switch is working properly to avoid injury.

Voice Command Function

1 Activate voice command

After pressing “” button, voice command function will be on automatically.

2 Wake up the chair

Use wake up word “**HI,Massage Chair**” to wake up the chair first. Once the chair responds “**HI, I am here**”, you will have a few seconds to command the chair.

(If the chair says “Let me know if you need anything”, meaning the session has expired, please wake up the chair again)

3 Voice commands

After waking up the chair, please use the commands below:

Wake up word:Hi Massage Chair			
1	power on	19	turn on leg airbags
2	power off	20	start massage mode one
3	increase intensity	21	start massage mode two
4	decrease intensity	22	start massage mode three
5	increase massage time	23	start massage mode four
6	decrease massage time	24	start massage mode five
7	Heat on	25	start massage mode six
8	Heat off	26	start massage mode seven
9	increase airbag intensity	27	start massage mode eight
10	decrease airbag intensity	28	start massage mode nine
11	Foot roller on	29	start massage mode ten
12	Foot roller off	30	Zero gravity one
13	Chair up	31	Zero gravity two
14	recline chair	32	Zero gravity three
15	airbags on	33	zero gravity off
16	airbags off	34	Audio volume up
17	Turn on arm airbags	35	Audio volume down
18	turn on shoulder airbags		

IMPORTANT Reminder:

Due to the sensitivity of the voice function, when using the chair, the chair might respond.

randomly if you are watching TV or talk with someone. This is NOT a defective issue.
Please turn off the power supply of the entire massage chair.thank you.



Method of use

Mode 3: Neck

Perfect for anyone who needs relief in the neck and shoulder areas. This program uses a combination of kneading, tapping, and lifting motions to target muscle relaxation and recovery, especially for those who work long hours at a desk or engage in physical activities.

Mode 4: Thai

A full-body stretch program designed to promote circulation and muscle relaxation. This mode features two types of stretching: overall body stretch and segmented stretch. It's ideal for post-workout recovery or anyone who spends long hours sitting. (Not recommended for pregnant women or elderly individuals.)

Mode 5: Back

This program focuses on massaging the lower back and hips, using concentrated, gentle pressure and a slow-fast rhythm to effectively relax and relieve tension in these areas.

Mode 6: Strong

A full-body massage with a rhythmic, flowing motion, enhanced by airbag compression for a gentle "wave-like" sensation. This program is designed to help you relax and de-stress, especially when paired with calming background music.

Mode 7: Elder

This program is specifically designed with a gentle and slow rhythm, using soft airbag compression for a soothing experience. It's perfect for first-time users or individuals who prefer a light, easy massage.

Mode 8: Queen

A more invigorating mode with quick kneading and segmented neck traction. It's designed to offer a deeper and more tailored massage experience, perfect for those seeking a more energizing and rejuvenating massage.

Mode 9: Swing


This special program offers continuous rocking motions combined with airbag compression, creating a gentle, cradling effect. It's a great option for anyone looking for a more dynamic and soothing massage experience.

Mode 10: Motion

Designed to relax muscles after physical activity, this program combines fast and slow massage techniques to relieve muscle tension and improve circulation. The program includes two angle adjustments for enhanced blood flow, especially beneficial for the lower body.

Manual

More manual modes allow user to adjust different massage methods



Security considerations



Be careful



prohibited



must be observed

The following persons are not allowed to use:

Thrombosis (blood disease, severe aneurysm, acute venous aneurysm), various skin diseases or skin infections (including subcutaneous tissue inflammation), etc.

Please consult your doctor before using the massage chair:

- Patients who are vulnerable to electromagnetic effects have implantable medical devices in the body.
- Malignant tumor patients
- Heart disease patients.
- A woman in a pregnancy or physiological cycle.
- Diabetes, peripheral circulation disturbance patients.
- People with perception deficit.
- There was an injured person at the massage site.
- Patients with a body temperature of more than 38 ° C, such as acute inflammation (typhoid fever, hypertension).
- Severe illness and weak body.
- Fracture, acute bone pain.
- Patients with muscle sprain and muscle inflammation.
- In addition, if you have a bad physique, feel uncomfortable or need to be quiet, please use it carefully.
- The product surface heat, heat insensitive people should be paid for.

The massage procedure of this product is a cycle of 20 minutes, please avoid continuous massage in the same part. For continued use, please interval of more than 30 minutes, in order to avoid over-stimulation of the muscles or the nervous system.

Warn




Wet hands are prohibited



moisture is prohibited



must be observed



Disassembly is prohibited



prohibited

When the body is wet, please do not use it to avoid electric shock accidents or machine failures.

This product can not be soaked in water or other liquids, nor can it be used in wet environments such as bathrooms. And custody to avoid electric shock accidents or mechanical failures.

Operate when you make sure there are no people or pets around you.

It is absolutely prohibited to remove or repair this product, power cord, hand controller and other components to avoid electrical, fire accidents or machine failures. When the power cord is broken, it is prohibited to remove and replace it privately, which must be repaired or replaced by the manufacturer or qualified professionals.

Do not use damaged power cords.

Do not forcibly bend, pull, twist, twist, or damage the power cord. Do not hang heavy objects on the power cord. Using damaged power cord may cause electric shock, short circuit or fire accident.

⚠ Warn

The massage chair will automatically change its angle during the automatic procedure. It is forbidden to come close to any gaps and gaps to avoid injury.

Do not use power sources other than 220-240V AC. The power cord must not be used on the product to avoid electric shock, short circuit or fire.

Do not let children ride and play on this product to avoid injury or machine failure.



Forbid

When adjusting the chair back and seat and adjusting the leg lift, first make sure that there are no other people, pets or objects in the back and under the leg massager. During the adjustment process, do not put any parts of the body, including hands and feet. Into the gap between the backrest and seat, backrest and armrest, armrest and shoulder, seat and armrest cover to prevent injury.

Do not use this product naked to avoid skin damage.

Be sure to use this product for the purposes described in this manual. Do not sit directly on the leg or armrest parts to avoid injury or accident.

It cannot be used when the main body cover is disassembled or damaged to avoid injury or accident.



⚠ Be careful



must be observed

When not in use or when there is a power outage, please turn off the power switch immediately and pull out the power plug to avoid any leakage, electric shock or fire accident when the power is on.



Wet hands are prohibited

Do not touch the power socket, plug or power cord with wet hands to avoid electric shock.



prohibited

When cleaning, be sure to turn off the power switch and pull the power plug from the power socket to avoid fire or electric shock. When pulling out the power plug, do not pull the power cord forcibly, but pull it with the flat head to avoid accidents.



prohibited

Do not use this product immediately after meals or after drinking to avoid discomfort. Do not hang heavy objects on the power cord or the manual control line. The manual control cannot be impacted or dropped by external force to avoid malfunction, failure, electric shock or fire accident.

Do not use this product near fire sources or heaters, and do not use it on floors that have floor heating or other heating.

Do not smoke during use to avoid fire.

Phone/tablet controller



Android User:



Settings



Bluetooth
On



1 Go to Settings

2 Turn on Bluetooth

3 Add new device

“Massage Chair Touch”



Auto: 10 present massage programs(15mins per session)



Mode 1:Master

This is the default program that activates automatically when the chair is turned on, unless another program is selected. It features a segmented neck traction with kneading and acupressure techniques, designed to stimulate circulation and relieve soreness.

Mode 2: Sleep

Ideal for naps or short rest periods, this program focuses on gentle comfort with added rocking motion to help you fall asleep.

Recommended use: Wrap the heating pad around your chest and abdomen for added warmth. Close your eyes, relax, and let the chair run its course. After the massage ends, the chair will rock gently three times to ease you into sleep, then return to a zero-gravity position to help you fully unwind.




Hand controller key map



Power On/Off

Chair up/Down



Be careful

Forbid

- Do not pull hard or use a knife or a hard, sharp object to scratch the fabric to avoid injury or accidents.
- Do not forcibly bend or pull the power cord or manual control cord to avoid machine failure or fire accident.
- The hand controller can not be impacted or dropped by external force, so as to avoid misoperation or machine failure.
- When the power cord, power plug is damaged or the power socket is loose, do not use this product to avoid electric shock, short circuit or fire accidents.
- When the legs are raised and lowered, please do not put your fingers into any cracks to avoid injury.
- Do not forcibly apply external force to the parts in each action to avoid personal injury or machine failure.
- Do not use while sleeping, unintentional use may cause injury and physical discomfort. Prohibited.
- Do not drag in the direction of the roller on wooden floors, carpets or easily scratched ground.
- After moving, it should be placed gently to avoid scratching the ground.

Be careful

This product can only be used in general home places, please do not use it in other places.

Do not cover or use this product with a blanket to prevent fire accidents due to excessive temperature inside the machine.

Please make sure that the power plug and the power socket are well coordinated, and no garbage is attached. No wiring board is allowed. In order to avoid electric shock, short circuit or fire accident.

Do not stand, step on or stack heavy objects on the body or leg parts to avoid personal injury or machine failure.

It is forbidden to use this product near fire sources or flammable objects to avoid deformation of the product, machine failure or fire accidents.

Do not use this product in environments with high concentrations of floating chemicals such as oil and gas to avoid product deformation, machine failure or fire accidents.

Do not wipe or spray this product with organic solvents, alcohol, or insecticides to prevent the machine from cracking, electric shock, or fire.

During use, do not let children or people with intellectual disabilities approach to avoid accidents.

People with paralysis cannot use this product to avoid physical discomfort or injury.



Precautions before use


1 Check around before use

Make sure there are no people, pets and other objects around the machine.



2 Make sure there are no foreign objects in the gap.

Before massage, make sure that no foreign objects are caught in the calf or foot.



3 Turn on the power.



Before massage, make sure that no foreign objects are caught in the calf or foot.



Warn


- Please check whether the power cord and power plug are damaged before use.
- Before seating, please confirm that there are no foreign objects between the various parts of the machine. Be sure to insert the power plug to the end. Otherwise, electric shock or overheating may result and cause a fire.
- Please use Alternating current. Do not use this product abroad or connect the transformer without authorization. Failure to do so may cause electric shock, machine failure, or overheating, which may cause a fire.
- Do not insert or pull out the power plug with wet hands.

Insert the power plug into the power outlet and press the power switch at the bottom of the unit to the "I" button.



Function and name

Main accessories name



FCC Statement

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has evaluated to meet general RF exposure requirement. The device can be used be in portable exposure without restriction.