


T09


成品尺寸: 60*80mm
材质: 105g铜版纸
装订方式: 风琴11折页

T09 WIRELESS EARPHONES



USER MANUAL

Packing List




Package Contents:

- A. Earphone x 2 (L&R)
- B. Charging Case x 1
- C. USB Charge Cable x 1
- D. User Manual x 1

Warm Tips:

- *Please clean the charging contacts and ear tip mesh with alcohol pads regularly to remove dust or earwax that may affect the charging or volume.
- *Please take good care of your earphones, lost earphones will not be covered by the warranty.
- *If there are any questions in the manual that are not answered, please check the product description on Amazon or contact our store customer service team.

Product Overview




Power On

Auto Power On:
Take out the earphones from the charging case, they will power on automatically with a beep: pairing.




Manual Power On:
When the device is not connected, press the left or right earphone for 3-5 seconds. The indicator blinks red and blue alternately and prompts "power on".




Power Off

Auto Power Off:
Put the earphones into the charging case, they will power off automatically.




Manual Power Off:
When the device is not connected, press the left or right earphone for 6 seconds and the indicator flashes red and blue alternately, then the indicator goes off and prompts "power off".




Pairing

Stereo Mode:
1. Open the charging case and take the earphones out of the case, the two earphones will automatically turn on and connect to each other. The master earphone's indicator blinks red and blue alternately to wait to be paired.
2. Turn on your phone's Bluetooth, search for "T09" and select it. The earphones connect with your phone successfully and prompts "connected".




Single Earbud Mode:
1. Take an earphone (left/right) out of the charging case.
2. Turn on your phone's Bluetooth and select "T09". The earphones connect with your phone successfully and prompts "connected".




Phone Calls Control

Answer/ End Calls:
Double tap the touch button of Right or Left earphone.




Reject Calls:
Long press 2s the touch button of Right or Left earphone.




Music

Play/Pause:
Once tap the touch button of Right or Left earphone. (when the music is paused)




Reset Earbuds

Reset earphones:
1. In the state of power on without any device connected, quickly tap the Left or Right earphone 5 times, then earphones will power off with a voice prompt "Power off".
2. Turn on your phone's Bluetooth and select "T09". The earphones connect with your phone successfully and prompts "connected".
3. Put the earphones back into the charging case.
4. Wait for 10s to open the charging case and turn on the bluetooth of your phone. Click "T09" to connect, earphones will work properly.



Charging


Digital Charging Display:



Activate Siri/Bixby



Earphones Charging:
Put the earphones into the charging case and close the case. The earphone light will remain red for 10 seconds and then go out.



Resetting the Case:
1. Take an earphone (left/right) out of the charging case, quickly tap the Left or Right earphone 5 times, then earphones will power off with a voice prompt "Power off".
2. Turn on your phone's Bluetooth and select "T09". The earphones connect with your phone successfully and prompts "connected".
3. Put the earphones back into the charging case.
4. Wait for 10s to open the charging case and turn on the bluetooth of your phone. Click "T09" to connect, earphones will work properly.



Specification

Model:	T09
Bluetooth Version:	V5.3
Charging Case Battery Capacity:	500mAh
Earphone Charging Time:	About 1.5H
Charging Case Charging Time:	About 3H
Music Playing Time:	About 8H
Standby Time:	About 40H
Charging Port:	Type-C
Operation Way:	Touch
Earphones Battery Model:	500909/3.7V/35mAh
Maximum Transmission Range:	≤12M

Q&A

Bluetooth

How to connect with my Phone?



To take earbuds out of the charging case, activate the Bluetooth setting on your phone, click "T09" to connect.

Occurrence and troubleshooting?

Cause: The Bluetooth connection is unstable, please reconnect it.



Press L&R earbuds together

Put them back into the charging case

封面

Earbuds can pair with phone, but can't pair with Pad.
Cause: These earbuds connected with previous device automatically, please forget the previous device's Bluetooth record then pair with new device.



Previous device




New device



Sound

There is no sound from one earbud? The volume from one earbud is lower than the other side?
Cause 1: One earbud connection failure, please make sure both earbuds are powered on and connected to your device.



I bought two pairs of T09 earbuds, when I use them at the same time, they would get messy or not work.
Cause: There's interference between the two pairs of earbuds.


Step 1: Please connect one pair of them to your device first, and then wait a few minutes before you connect another pair to another device.
If interference has occurred, please reset both pairs of earbuds, and try step 1.



The Earbuds' sound is very low.
Cause: Android phones don't synchronize audio. Please turn on "sync volume with phone" in your phone.



Sound Cut in/out or disconnected.
Cause 1: There is electromagnetic interference around earbuds, please keep away from them.




Cause 2: The grilles or the ear tips are dirty, please use alcohol to gently clean the metal mesh filter under the ear tips.
Step 1: Please connect one pair of them to your device first, and then wait a few minutes before you connect another pair to another device.

If interference has occurred, please reset both pairs of earbuds, and try step 1.



Charge

The earbuds won't charge or turn on?
Cause 1: The charging case is low battery, please make sure the charging case is not out of battery and use the Type-C cable to charge it for more than 3 hours.



These earbuds have static noise or a constant buzzing sound.
Cause: The signal and connection between the earbuds and your device are affected by electronic interference emitted by devices like microwave ovens, WiFi routers, signal lights, or devices in airports/metro stations, etc.



Cause 2: The distance between earbuds and phone are too far, please keep them within 33 feet.
Cause 3: The earbuds are too far from the charging port, please keep them within 33 feet.



Safety Instruction

Pay close attention to the surrounding traffic when using it on foot. It may cause traffic accidents.

- Reduce the volume to a minimum before use. Sudden loud noises can damage your hearing.
- To protect your ears, do not turn the volume up too high.
- Stop using this product if it falls into flammable or liquid (such as water). Continued use may result in fire, malfunction or electric shock.
- Opening the inside may result in malfunction or electric shock.
- Do not touch the inside. Also, we cannot guarantee performance if the interior has been manually modified.
- Do not charge with wet hands or touch the charging port. This may result in electric shock.
- If you feel uncomfortable while using this product, stop using it immediately.
- If you are using a medical device such as a pacemaker, consult your doctor before using it.
- Do not allow small children to use it.

Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference.
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This device and its antenna(s) must be co-located or operation in conjunction with any other antenna or transmitter.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Charge


Cause 3: The earbuds are low battery or high temperature, please charge it.



After eliminating the above causes, please re-pair these earbuds with phone.



Cause 2: Check if the charging interface is loose.




Charge

Cause 2: The pin is dirty, please check the pin connection, they may be dirty or broken. Clean the pins in the case and the dots in the earbuds with a cotton swab, better dipped with alcohol.



Cause 3: Try using a different power source.



Asking for more help

If none of the above solutions work or you receive your package with missing parts or other problems not mentioned, please follow the steps below to contact our support and ask for assistance:

1. Go to the Amazon website and log in to your account.
2. Click on the "Orders" icon located on the top right corner of the screen.
3. Locate the order that you need help with and click on the "Contact Seller" button.
4. Choose the reason for your inquiry from the drop-down menu and provide a brief description of your issue.
5. Click on the "Send" button to submit your message to us.
6. Alternatively, you can also go to the seller's storefront on Amazon and click on the "Ask a Question" button located on the top right corner of the screen. This will allow you to send a message directly to us.

***It is recommended to be as clear and concise as possible when describing your problem to us, as this will help us understand your problem and provide you with the best solution.**