


Programming




When plugged in, turning on or off the fan functions or using the remote to power off requires pressing the power button on the remote or any button on the main unit to wake the system; It will automatically resume its previous settings before shutdown.



In cooling and heating modes, set the desired temperature; In fan mode, adjust the fan speed; In temperature control mode, select the target temperature and airflow level. In temperature display mode, when setting the cooling or heating triggers, press both the up and down buttons to adjust temperature levels. You can switch modes at any time.



After adjusting the speed button, press it again to toggle between the current speed level (1-10) and 0.




In temperature display mode, press and hold the temperature display button for at least 3 seconds; The buzzer will beep three times, and the screen will show "LC" (indicating continuous display). After 2 seconds, it will automatically display the actual temperature. Press and hold the button again for 3 seconds, and the buzzer will beep once, showing "UL" (indicating screen off mode). After 2 seconds, the screen will turn off. Press any button to wake the fan control.



In cooling trigger temperature setting mode, press the button again to toggle between the cooling trigger temperature and "OF."



In heating trigger temperature setting mode, press the button again to switch between the heating trigger temperature and "OF."



Instantly enter the humidifying fan mode setting and toggle between "Hold Position" and "Auto Oscillation."

Warning:

Remote control buttons not responding:

1. Check if the remote control battery has power.
2. Re-pairing process: Reconnect the main unit to power, then within 30 seconds, press and hold the power button on the remote for at least 5 seconds until the main unit emits three beeps ("beep beep beep"), indicating a successful connection.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.