


Find My Smart Tag

USER MANUAL

Require system iOS 14.5 and
iphone 6s above



Works with
Apple Find My

Main Functions

Locate your item

The Apple Find My network provides an easy, secure way to locate compatible personal items on a map using the Find My app on your iPhone, iPad, or Mac. Simply pair your compatible product with the Apple Find My app to view it right alongside your Apple devices. If your item ever goes missing, you can put it in Lost Mode to display a message and contact information to anyone who might find it. The Find My network is encrypted and anonymous, so no one else, not even Apple or the maker of your personal item, can view its location.

Quick instruction

1.1 Power On/off

This product is designed without a switch button. For the first time, just put the battery into the back cover and turn it on automatically. It should beep for a long time, indicating that it is powered on.

1.2 Check For Updates

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS.

2.1 Add Your A Tag

Start The App, Open Find My app on your supported iPhone. Turn on the bluetooth and network of your phone.

2.2 Connect your A Tag

Put the battery into the back cover, then "Add Other Item", Once your A Tag is located, tap "connect", Enter a name and choose an emoji for your A Tag and tap "Continue". Find My will ask for confirmation to your Apple ID, Tap "Agree" and "Finish", then your A Tag will be set up and ready to be used.

3.1 Find A Tag When it's Nearby

Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch. Tap your item from the list, Tap "Play Sound" to make your A Tag beep, Tap "Stop Sound" to stop the beeps once you find it.

3.2 Find A Tag Location

Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch. Tap your A Tag from the list. Your A Tag location will appear on the Map with a time stamp of when the item was located. To navigate to the A Tag's location, tap "Directions" to open Apple Maps.

4.1 Notifications

Enable "Notify When Left Behind".

Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch. Tap on your item from the list, Under "Notifications", enable the "Notify When Left Behind" toggle. You will receive a notification when you leave your A Tag behind and it's no longer in range of your device.

4.2 Enable "Notify When Found"

Under "Notifications", enable the "Notify When Found" toggle

When your A Tag is seen by another Find My network device, you will receive a notification of its location. Note: "Notify When Found" can only be activated when your A Tag is out of range.

5.1 When Your A Tag Is Lost / Enabling "Lost Mode".

Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch. Tap on your item from the list, Under "Lost Mode" tap "Enable". A screen detailing Lost Mode will pop up, tap "Continue", Enter your phone number or email address and tap "Next" You may enter a message that will be shared with the person that finds your item.

Tap "Activate" to enable "Lost Mode" Note: When "Lost Mode" is enabled, "Notify When Found" is automatically enabled.

Note: when "lost Mode" is enabled, your A Tag is locked and cannot be paired to a new device

6.1 Resetting A Tag

Remove The A Tag From Find My App

Open Find My app and select the "Items" tab, Tap on your item from the list, Please ensure "Lost Mode" is disabled. Scroll to the bottom of the screen and tap "Remove item", A summary will open, tap "Remove" to confirm.

6.2 Factory Reset Your A Tag

After successfully deleting the A Tag from Find My App, unscrew the back cover to remove the battery.

The A Tag is now reset and ready to pair with the new Apple ID/OS device.

7.1 Unwanted tracking

If any Find My network accessory separated from its owner is seen moving with you over time, you'll be notified, Find My will send a notification to your Apple device. This feature is available on iOS or iPadOS 14.5 or later, This features were created specifically to discourage people from trying to track you without your knowledge.

FAQ

1. How the items are located?

When an item is separated from its owner for a period of time, it can be found by other Apple devices in Find My network and the owner can start to get the location of the device.

2. How to confirm whether the device is powered on?

After getting the Find My, after removing the back cover and loading the battery, the equipment will beep, indicating that the device has been started. If there is no response, please try to reset the device. If there is still no response, please try to replace the battery or contact our after-sales service team for handling.

3. How is the device designed to discourage unwanted tracking?

If any Find My network accessory separated from its owner keeps going with you over time, you'll be notified in one of two ways:

1. If you have an iPhone, iPad, iPod touch, Find My will send a notification to your Apple device. This feature is available on iOS or iPadOS 14.5 or later.

2. If you don't have an iOS device or a smartphone, a Find My network accessory that is not with its owner for a period of time will emit a sound when it's moved. These features were created specifically to discourage people from trying to track you without your knowledge.

4. Why I can't find device with Bluetooth connection?


Try to reset the device by removing the battery until the beep sound, or you can try to replace the battery, or you must disconnect the device from other Apple ID firstly, and then try to connect again.

Battery

A Tag contains a button battery. The battery may need to be replaced during the life of the product. Replace only with batteries of the same type (EVE CR22032) and rating, observing correct polarity.

Battery replacement:

1. Disassemble the product into two parts through the gap between the upper cover and the lower cover
2. Remove the battery.
3. Insert the EVE CR22032 battery into the device with the positive (+) side facing up.
4. Connect the upper cover and the lower cover, and press tightly.



- a) The statement "Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate"
- b) The statement "Even used batteries may cause severe injury or death"
- c) The statement "Call a local poison control center for treatment information."
- d) A statement indicating the compatible battery type (EVE CR22032).
- e) A statement indicating the nominal battery voltage.
- f) The statement "Non-rechargeable batteries are not to be recharged."
- g) The statement "Do not force discharge, recharge, disassemble, heat above (manufacturer's specified temperature rating) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns"
- h) The statement "Ensure the batteries are installed correctly according to polarity (+ and -)"
- i) The statement "Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries."
- j) The statement "Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations"
- k) The statement "Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children"

Safety and handling

Important safety information to handle A Tag with care. It contains sensitive electronic components, including batteries, and can be damaged, impair functionality, or cause injury if dropped, burned, punctured, crushed, disassembled, or exposed to excessive heat or liquid or to environments with high concentrations of industrial chemicals. Don't use a damaged A Tag.

A Tag 1 Year Limited Warranty

The warranty obligation is limited to the following terms: there are no defects in materials and workmanship for one year from the date of initial purchase ("warranty period"). If there is a defect and the tag receives a valid claim within the warranty period, A Tag will choose:

1. Repair the product freely.
2. Exchange the product with another new product.

3. The freight rose from goods return will be shared by A Tag and Customer together. (customer will have to bear the freight to the factory while A Tag will bear the freight to the customer). For any maintenance and repairs out of service range, the customer will have to bear the freight.

Environmentally friendly disposal

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and the treatment of toxic substances.

FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

Use of the Works with Apple badge means that a product has been designed to work in specification with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specification and requirements.

Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc. registered in the U.S. and other countries. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.