






1



2




3



Removing Keycaps

1. Turn off Create – Disconnect the USB-C cable and ensure that the power switches are in the OFF position.
2. Position the keycap puller – Take the keycap puller and gently hook it under opposing sides of the keycap. Ensure the puller is securely attached to the keycap.
3. Gently pull up – Slowly and carefully pull upward to remove the keycap. Avoid using excessive force to prevent damage to the switches underneath. Larger keycaps may require more pressure as they have stabilizers.
4. Repeat for all keycaps – Continue this process for all keycaps you wish to remove. Place the removed keycaps in a safe location for reassembly.

Switches may sometimes release together with the keycap, if this occurs simply **⚠** separate the two by firmly grasping both and gently rocking the keycap back and forth while pulling them apart.







If any keycaps or switches are difficult to remove or install, be patient and avoid using excessive force.

Installing Keycaps



1. Turn off Create – Disconnect the USB-C cable and ensure that the power switches are in the OFF position.
2. Match the location – The back of each keycap is labeled with a coordinate. You can reference the location the keycap should be placed based on the map provided below.
3. Align the keycap – Line up the stem of the keycap with the switch stem.
4. Press the keycap down – Gently press the keycap onto the switch until it fits securely in place. You should feel a slight snap when the keycap is correctly positioned.
5. Repeat for all keycaps – Continue the process for all keycaps. For larger keys with stabilizers, ensure that the stabilizers are properly aligned before pressing down.




Removing Switches

1. Turn off Create – Disconnect the USB-C cable and ensure that the power switches are in the off position.
2. Remove Keycaps – See above.
3. Insert the switch puller – Use the switch puller to grip the switch. Position the prongs of the puller in the cutouts above and below the switch.
4. Gently pull the switch out – Once the puller is securely in place, carefully pull the switch straight up and out of the socket. This should not require an excessive amount of force.


1



3








4




Installing Switches

1. Turn off Create – Disconnect the USB-C cable and ensure that the power switches are in the off position.
2. Inspect the socket – Ensure there is no dust or debris before inserting a new switch.
3. Inspect the switch – Ensure all pins on the switch are straight to prevent damage to switch and/or socket. (If using third-party sourced CPG-1232 switches please ensure that the pins are 0.45x0.42mm.)
4. Align the metal pins on the bottom of the switch with the holes of the socket. You may need to ensure that the sockets align with the cutouts on the body by pushing the PCB into position.
5. Press gently into the socket – Push the switch straight down into the socket until it clicks into place. Ensure the switch is seated firmly and evenly.
6. Repeat for all switches.
7. Check for stability – Test each switch by gently pressing it to confirm it's properly installed.





Naya Default – Base Layer



LA1	= Esc	LA3	= Caps Lock	LA5	= Layer 2 (Hold)	RC1	= O and)	RC3	= ; and :
LB1	= Grave and Tilde	LB3	= Caps Lock	LB5	= Ctrl	RB1	= - and _	RB3	= ' and "
LC1	= 1 and !	LC3	= A	LC5	= Win Key	RA1	= = and +	RA3	= \ and
LD1	= 2 and @	LD3	= S	LD5	= Alt	RG2	= Y	RG4	= N
LE1	= 3 and #	LE3	= D	LE5	= Space	RF2	= U	RF4	= M
LF1	= 4 and \$	LF3	= F	LH2	= Space	RE2	= I	RE4	= , and <
LG1	= 5 and %	LG3	= G	LH3	= Enter/Return	RD2	= O	RD4	= . and >
LH1	= Backspace	LA4	= Shift	LH4	= Layer 1 (Hold)	RC2	= P	RC4	= / and ?
LA2	= Tab	LB4	= Shift	RH4	= Layer 1 (Hold)	RB2	= [and {	RB4	= Shift Right
LB2	= Tab	LC4	= Z	RH3	= Backspace	RA2	=] and }	RA4	= Shift Right
LC2	= Q	LD4	= X	RH2	= Space	RG3	= H	RE5	= Space
LD2	= W	LE4	= C	RH1	= Enter/Return	RF3	= J	RD5	= Alt Right
LE2	= E	LF4	= V	RG1	= 6 and ^	RE3	= K	RC5	= Win Key Right
LF2	= R	LG4	= B	RF1	= 7 and &	RD3	= L	RB5	= Ctrl Right
LG2	= T			RE1	= 8 and *			RA5	= Layer 2 (Hold)
				RD1	= 9 and (

Naya Default – Layer 1



LA1 = Transparent
 LB1 = Transparent
 LC1 = F1
 LD1 = F2
 LE1 = F3
 LF1 = F4
 LG1 = F5
 LH1 = Transparent
 LA2 = Transparent
 LB2 = Transparent
 LC2 = Page Down
 LD2 = Home
 LE2 = Up
 LF2 = End
 LG2 = Page Up

LA3 = Transparent
 LB3 = Transparent
 LC3 = Transparent
 LD3 = Left
 LE3 = Down
 LF3 = Right
 LG3 = Insert
 LH3 = Transparent
 LA4 = Transparent
 LB4 = Transparent
 LC4 = Transparent
 LD4 = Transparent
 LE4 = Transparent
 LF4 = Transparent
 LG4 = Delete

LA5 = Transparent
 LB5 = Transparent
 LC5 = Transparent
 LD5 = Transparent
 LE5 = Transparent
 LF5 = Transparent
 LG5 = Transparent
 LH2 = Transparent
 LH3 = Transparent
 LH4 = Transparent
 RH1 = Transparent
 RG1 = F6
 RF1 = F7
 RE1 = F8
 RD1 = F9

RC1 = F10
 RB1 = F11
 RA1 = F12
 RG2 = Numpad *
 RF2 = Numpad 7
 RE2 = Numpad 8
 RD2 = Numpad 9
 RC2 = Numpad +
 RB2 = Numpad (
 RA2 = Numpad)
 RG3 = Numpad /
 RF3 = Numpad 4
 RE3 = Numpad 5
 RD3 = Numpad 6

RC3 = Numpad -
 RB3 = Num Lock
 RA3 = Transparent
 RG4 = Numpad ,
 RF4 = Numpad 1
 RE4 = Numpad 2
 RD4 = Numpad 3
 RC4 = / and ?
 RB4 = Transparent
 RA4 = Transparent
 RE5 = Numpad 0
 RD5 = Numpad .
 RC5 = Win Key Right
 RB5 = Transparent
 RA5 = Transparent