




QUICK REFERENCE GUIDE

Mini walkie-talkie



Product Layout



Basic Operations

Charge the Battery

⚠ CAUTION

- Please use a FCC certified power adapter or portable power bank to charge the terminal, ensuring that the output voltage of the power adapter or portable power bank is not greater than 5V
- The terminal may experience a low battery alarm when used for the first time. Please charge the terminal before initial use.

Use the USB Type-C Cable to connect the radio to the power adapter, power bank, or PC. The running light of the battery indicator lights up to indicate that the terminal is charging. The terminal battery is fully charged by the battery indicators are all light up.

Turn On or Off the Radio

Long press the On-Off key.

Adjust the volume

- Press the **【O】** Key to switch the Volume/Channel Up and Volume/Channel Down Keys to volume control mode.
- Press the Volume/Channel Up key to increase the volume, or the Volume/Channel Down Key to decrease the volume.

Select a Channel

- Press the **【O】** Key to switch the Volume/Channel Up and Volume/Channel Down Keys to channel selector mode.
- Press the Volume/Channel Up key or the Volume/Channel Down Key to switch the channel.

Make a Call

⚠ Note: This device must be connected to a dedicated Type-C earphone to use!

To ensure optimal voice quality on the receiving radio, keep the microphone about 3cm to 10 cm away from the mouth during speaking.

- Select a channel.
- Press and hold the PTT key.

Lock key/unlock

Long press the **【O】** key to lock it; Press and hold the **【O】** key again to unlock. After 30 seconds of no operation, this terminal will automatically lock the key.


Wireless Replication

This function can copy the usage frequency of one terminal to another terminal. The specific operation is as follows:

- Host selects channel 2 and shuts down. Press and hold the **【O】** and **【PTT】** keys, turn on the radio, release all keys, the LED screen display 'CL', and the host will enter wireless replication mode.
- Sub terminal selects channel 2 and shuts down. Press and hold the **【O】** and **【PTT】** keys, turn on the radio, release all keys, the LED screen display 'CL', and the sub terminal will enter wireless replication mode.
- Press the PTT key on the host to start wireless replication. There will be a replication progress prompt on both the host and sub terminal. Once replication is complete, the LED screen will display 'CL' and return to wireless replication mode to wait for the next operation.
- Turn Off and restart the radio, exit wireless replication, and enter intercom mode.

Wear the Earpiece

You can rotate the earbud to fit to your left or right ear.





WARNINGS: Replacement or substitution of transistors, regular diodes or other parts of a unique nature, with parts other than those recommended by CRONY may cause a violation of the technical regulations of part 95 of the FCC rules, or violation of type acceptance requirements of part 2 of the rules. Your radio is set up to transmit a regulated signal on an assigned frequency. Any adjustment to your radio must be made by qualified technicians.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference, and
- 2) this device must accept any interference received, including interference that may cause undesired operation.



FCC & RSS WARNINGS:
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

SAR tests are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. Before a new model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC. Tests for each product are performed in positions and locations as required by the FCC.

For body worn operation, this device has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. in order to comply with the

FCC RF exposure requirements, the antenna installation must comply with following:

Users must be fully aware of the hazards of the exposure and able to exercise control over their RF exposure to qualify for the higher exposure limits.

This product sends out radio frequency (RF) signals when the Push-to-Talk (PTT) Button is pressed.

The device is authorized to operate at a duty factor not to exceed 50%.

Note

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

----Reorient or relocate the receiving antenna.

----Increase the separation between the equipment and receiver.

----Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

----Consult the dealer or an experienced radio/TV technician for help.

Appendix B. - Technical Specifications

| | |
|-----------------|--|
| Frequency Range | FRS(462.5500-462.7250MHz, 467.5625-467.7125MHz) |
| Memory Channel | 22 |
| Battery Voltage | DC 3.7V |
| Power | 462.5500-462.7250MHz:22.03dBm 467.5625-467.7125MHz:23.14dBm |

Company Name: Quanzhou Xingdian Cross-border E-commerce Co.,Ltd.

No. 12, Xifeng, Fushan Village, Hangban Town, Taishang Investment Zone, Quanzhou City, Fujian Province, China