


WIRELESS MICROPHONE FREQUENCY ADJUSTMENT METHOD

It is only necessary to change the frequency of the microphone when it is interfered by products of the same model. For example: you and your friend each have one of this speaker and use it at the same time. Maybe your voice will come out from his speaker. Then you can adjust the frequency of your microphone and change the channel to avoid interference.

Make sure the speaker and microphone are powered on before performing the following functions:



- ① Screen display
- ② Power switch
- ③ Increase channel
- ④ Decrease channel
- ⑤ Battery tray
- ⑥ DC input 5V

* Gain change

The set button ③ ④ are the button to change the input gain for the microphone, press to change the gain from 1 to 9

* Instructions to change the frequency for hand microphone

Step 1: Press and hold the set button ③ or ④ for about 3 seconds until the screen display ① shows the word "SET", then release

Step 2: press the set button ③ ④ to change the frequency channel

Step 3: After selecting the frequency, wait 3 seconds, the microphone and the speaker will automatically connect

* Instructions for reconnecting the microphone hand

Step 1: Turn on the micro hand

Step 2: Press the Power switch button ② about 7 seconds (Note: hold the power switch button for 2 seconds, the screen will turn off, at this time do not release your hand and continue to hold it for another 5 seconds until the screen lights up, then release your hand)

Step 3: wait for about 3 seconds, the microphone and speaker will automatically connect together

Insert the battery correctly before use.

Press and hold the switch button, the microphone is turned on, and the display shows the status.

The microphone is divided into two U-band wireless microphones with A and B frequency (A\B logo on the bottom)

Please replace the battery when the microphone sound is weak or not displayed.

FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.