


105g铜版纸/单面单色印刷/折叠尺寸: 55*80mm



Power Bank Layout

Magnetic Wireless Power Bank

Magnets align perfectly every time for faster wireless charging. Snap the power bank (10,000 mAh) onto your device for extended power, lasting more than a day while playing games. It also serves as a wireless charging station at home.

Advantages

What are the advantages compared to a regular wireless and power bank?

1. Portable: Magnetic snap-on design for phones, for easy holding.
2. Fast Charging: Our power bank is designed to work quickly.
3. One Click: Simple and hands-free, ideal for games and videos.
4. Compact Size: Lightweight, perfect for emergencies.
5. Pocket Power: No need to worry about running out of power.

Suitable for

1. iPhone 12 / 13 / 14 / 15 / 16 series or phones with magnetic protective cases.

2. Other smartphone models phones supporting wireless charging.

Charging the Power Bank

Connect the USB cable to a computer or USB wall charger (not included). Connect the USB-C plug to the USB-C port of the Power Bank. Once charging is complete, all 4 LED indicators will be steady white.

Note: DO NOT charge and discharge the Power Bank at the same time.

Charging Mobile Devices

1. Wireless Charging

Place the device on the back of the Power Bank. Press the on/off button once. If the device supports wireless charging, the LED will light up green. Press the on/off button twice to turn off wireless charging.

2. Charging with USB-C Cable

Alternatively, connect the USB-C cable to the USB-C port. Connect the other end of the cable to the mobile device to be charged.

Compatible with official Apple iPhone cases with MagSafe.

Security Information

1. Keep the Power Bank away from moisture and corrosive materials.

2. Do not touch the device with wet hands.

3. Store in a relatively dry and ventilated environment, away from fire and heat.

4. Keep out of reach of children and animals.

5. Do not disassemble, modify, or repair the device without permission.

6. Avoid placing magnetic objects such as bankcards/passbooks/phone cases near the device.

7. If not used frequently, charge the Power Bank at least once every two months and charge for at least 1 hour before storage.

Avoid serious drops, collisions, friction, or other impacts. If the Power Bank is damaged, stop using it. Dispose of batteries according to local regulations; used batteries should be taken to a local recycling center.

Specification

Battery Capacity: 10,000 mAh / 3.85V / 38.5Wh

5W / 7.5W / 10W / 15W (Max)

Material: Aluminum Alloy + PC

Magnetic Level: Strong

Input USB-C: 5V~3A, 9V~2A, 12V~1.5A

Output USB-C: 5V~3A, 9V~2.2A, 12V~1.67A (Max)

Device Dimensions: 102.5 * 66 * 14 mm

Weight: 100g

Note: Automatically turns off after 30s under no-load status.

Green light: Wireless charging active.

White light: Battery capacity indicator.

CONTAINS:

1. Magnetic Wireless Power Bank*1

2. USB-C Cable*1

3. User Manual*1

Please note: Does not include an adapter.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio communications, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

FCC RF exposure statement:

This device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

