


TX16-2 Manual



OUTDOOR SENSOR

1. Outdoor temperature
2. Channel display
3. Outdoor humidity
4. Wireless signal indicator (Flashes when data is being sent to the display unit)
5. Wall mount hole
6. Channel selector, select external sensor channel
7. Compartment 2xAAA batteries

FIRST OPERATION

1. Open the battery compartment cover.
2. Set the desired channel with the switch. If you are using only one transmitter, please leave the selection at "1".
3. Insert 2 new "AAA" 1.5V batteries observing correct polarity.
4. Close the battery compartment cover and set the unit in the desired location.

Note: Although the outdoor sensor is weatherproof, it should not be placed in places exposed to direct sunlight, rain or snow


Positioning the Wireless outdoor Transmitter:

Once the Forecast Station shows the outdoor temperature, place it and the transmitter in the desired locations and wait approximately 1-hour before permanently mounting the transmitter to ensure that there is proper reception. The transmitter should be mounted vertically, in a shaded, protected area, at least 1.3 m from the ground to avoid damage and ensure accurate readings. The transmitter is water resistant, not waterproof and should not be placed anywhere it will become submerged in water or subject to standing water or snow.

WALL MOUNT:

1. Choose a shaded location with an overhang for the transmitter, that is within the confirmed wireless reception range of the Forecast Station for accuracy.
2. Install one mounting screw (not included) into a wall leaving approximately 1/2 of an inch (12.7mm) extended.
3. Place the hanging hole (on the back of the transmitter) onto the mounting screw and gently slide the transmitter down onto the mounting screw to secure it into place.

Right way



Hang on the wall



Hang on the wall

Wrong way



Don't lie flat on outside



FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.