



Helicopter components




Remote control component name



Battery installation usage

- 1)Use only AAA batteries.
- 2)Do not mix different battery types.
- 3)Do not mix older and newer batteries.
- 4)Remove the batteries when the remote controller is not in use.
- 5)Do not recharge non-rechargeable batteries.
- 6)Insert the batteries with the correct polarity.
- 7)USE 3x 1.5V AAA BATTERIES(Not Included).

Helicopter charging



1. First make sure the helicopter is turned off.
2. The light on the circuit board of the helicopter will turn red when charging.
3. Plug the USB cable to the helicopter.(and connect to a computer USB power supply.)
4. The light on the circuit board of the helicopter will turn off when the helicopter is fully charged.
5. The charging time is about 60 minutes, and the flight time is about 12 minutes.

Flight environment

- In for flight safety, please make sure that there are no pedestrians and other obstacles around the flight environment.
- In the wind generated by various electrical appliances and the wind from the outside world to interfere with the helicopter to make it unsafe and unstable.

Flight Operations

- Notice: must turn on helicopter at first, then turn remote controller, or it can't match succeed.
- Place the helicopter on a level surface, turn on the helicopter power at first, indicator light flashes slowly.
- Then turn on remote controller, it will be search correct frequency auto, the helicopter indicator light flashes quickly, it indicates a successful match
- After a successful match, you can control the airplane to take off with the one-touch takeoff button; or you can press the ascent button to take off.(No operate the helicopter within 5 seconds, the helicopter will stop take off)

Warning

- If the helicopter stops flying after hitting an obstacle, restart the helicopter

How To Connected Helicopter & Remote Contolle

1	The remote control signal transmission window must face the aircraft to transmit signals to the aircraft	
2	Turn on the helicopter power switch in the direction of the arrow, and then place the aircraft in a stable place (Do not to hold it in your hands)	
3	Press power on after3 seconds, power LED flashing	


Remote control flight mode

Throttle L ever Pushed Up/aircraft Raised Throttle Rod Downward/aircraft Down	
Push the lever to the left/turn the aircraft to the left	
Push the joystick to the right/turn the aircraft to the right	

Flight left and right fine adjustment

When the aircraft automatically turns left, press this key continuously to correct the aircraft so that it does not rotate continuously.	
--	--

When the aircraft automatically turns right, press this key continuously to correct the aircraft so that it does not rotate continuously.



Federal Communications Commission Notice

This device complies with part 15 of the FCC Rules. Operator is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.