EXT-004





Setting Instruction

Plug the power supply cord into a 3- conductor outlet Plug the appliance into the outlet of the timer.

- Rotary switch preset "OFF", shut the power off for the provided six outlets.
 - Remote control is disable in this mold.
- Rotary switch preset "ON", the provided six outlets constantly switch power on
 - Remote control is allowed to switch on / off the six outputs at anytime
- Rotary switch preset "Dusk/Dawn", the provided six outlets would automatically switch on at dusk, and switch off at dark.
 - In this mold, remote control can switch off the power immediately. Remote control is disable in daytime.
- Rotary switch preset 2, 4,6,8,10 hrs, switch the appliance "ON" for indicated hours after the photocell detecting dusk.
 - In this mold, remote control can switch off the outputs immediately.

 Remote Control is disable in daytime or while the count down timer is pass due.

Installation Instruction

The timer must be mounted in a vertical position with the receptacle facing downward and with the receptacle not reaching ground level.

Transmission

- Working voltage: 3V~12V
- Working current: max≤40mA(12V), min≤9mA(3V)
- Modulation mode: ASK/OOK
- Working frequency: 315MHz
- Frequency error: +150kHz (max)
- Transmission: 25mW(315MHz at 12V)

Receiving

- Working voltage: 5.0V ~ +0.5V
- Modulation method: ASK/OOK
- Frequency range: 250MHz-450MHz

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the authoriy to operate equipment.