
Quick Installation Guide

D892

VoIP phone







#### Wireless handset

This phone can also be operated with the D8M wireless handset. It is available separately, Snom PN 00004557.


Unplug the corded handset and place the D8M in the cradle for charging and automatic pairing with the phone. For more information, see the D8M Quick Installation Guide that came with the handset

Note: When the phone has been paired with a wireless handset, the handset must be deregistered from the phone before you can use the phone with the corded handset

- Remove the D8M from the cradle.
- Press Settings.
- Press Connection
- Press **Select** to select **DECT**.

Press Deregister. The display shows the message Unregister under Cordless Receiver.

Plug in the corded handset



Snom Technology GmbH Aroser Allee 66 13407 Berlin, Deutschland office.de@snom.com

Snom Technology GmbH Via Milano 1 20020 Lainate, Italia

office.it@snom.com

Snom Technology GmbH 130, avenue Joseph Kessel 78960 Voisins-le-Bretonneux, Franceoffice.fr@snom.com

Snom Technology GmbH The Courtyard High Street

Ascot, Berkshire SL5 7HP, UK office.uk@snom.com

VTech Communications Inc. Snom Americas Suite 555 Tigard, OR 97223

9020 Washington Square Road, Phone support: (339) 227 6160

VTech Technologies Canada Ltd. Suite 222

13888 Wireless Way Richmond, B.C. V6V 0A3, Canada Phone support: (339) 227 6160

Manufacturer: VTech Telecommunications Ltd. 23/F., Tai Ping Industrial Centre, Block 1, 57 Ting Kok Road, Tai Po

HONG KONG

# **ENGLISH**

## Copyright, Trademarks, Legal Disclaimers

trademarks owned by Snom Technology GmbH

© 2024 Snom Technology GmbH. All Rights Reserved. Snom, the names of Snom products, and Snom logos are

All product specifications are subject to change without notification. Snom Technology GmbH reserves the right to revise and change this document at any time, without being obliged to announce such revisions or changes beforehand or after the fact.

Although due care has been taken in the compilation and presentation of the information in this document, the data upon which it is based may have changed in the meantime. Snom therefore disclaims all warranties and liability for the accurateness, completeness, and currentness of the information nublished except in the case of intention or gross negligence on the part of Snom or where liability arises due to binding legal provisions.

#### Important Information

Follow the instructions in the manual and other applicable documentation of the device. Save this guide and do not give the device to third parties without it.


### Safety Instructions

- This device is designed for professional use.
- Warning: The product included (ITE) in this manual is to be connected only to PoE networks without routing to the outside plant.
- · The socket outlet for the power adaptor must be near the equipment and easily accessible.
- · Mount the device only at heights not exceeding 2m
- If the phone is not supplied with power via the Ethernet cable, use only the power adapter listed in the user instructions. Other power supplies may damage or destroy the phone, affect its behavior, or induce noise.
- · Avoid placing the cables where people may trip over them or where they may be exposed to mechanical pressure as this may damage them.
- This device is for indoor use only! NOT FOR OUT-DOOR LISE!
- . Do not install the device in rooms with high humidity (for example, in bathrooms, laundry rooms, damp basements). Do not immerse the device in water and do not spill or pour liquids of any kind onto or into the device.
- Do not install the device in surroundings at risk for explosions (paint shops, for example). Do not use the device if you smell gas or other potentially explosive fumes.
- · Do not use the device during thunderstorms. Lightning striking the power grid may cause electric shocks.
- Warning: The handset contains a magnet, and its earpiece may attract small dangerous objects such as needles or pins. Please ensure before each use that no such objects are present.
- SELV (Safety Extra Low Voltage) Compliance. Safety status of Input/Output connections comply with SELV requirements. Warning: To avoid electric shock, do not connect safety extra-low voltage (SELV) circuits to telephone-network voltage (TNV) circuits. LAN ports contain SELV circuits, and PSTN ports contain TNV circuits. Some LAN and PSTN ports both use RJ-45 (8P8C) connectors. Use caution when connecting cables.
- · Caution: To maintain compliance with radio frequency exposure requirements, the phone shall be installed and used so that parts of user's body other than hands keep a distance of 20 cm or more.

# Standards conformance

This device complies with Directive 2014/53/EU and the essential health, safety, and environmental requirements of all relevant European I IK directives. This device complies with the Radio Equipment Regulations 2017 and the essential health, safety, and environmental standards of the UK.

This device is FCC certified and meets US health, safety. and environmental standards.



Accept call ✓. confirm

End call, cancel → (x) (4)

#### FCC ID: EW780-S112-00

This product meets the applicable Innovation, Science and Economic Development Canada technical specifications. IC: 1135B-80S11200

You can download the declaration of conformity at www. snom.com/conformity.

Unauthorized opening, changing, or modifying the device will cause the warranty to lapse and may also result in the loss of CE and IC conformity and the FCC certification. In case of malfunction contact authorized service personnel, vour seller, or Snom.

# FCC part 15

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions. may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Privacy of communications may not be ensured when using this telephone.

# RF Radiation Exposure

To ensure safety of users, the ECC/ISEDC has established criteria for the amount of radio frequency energy that can be safely absorbed by a user or bystander according to the intended usage of the product. This product has been tested and found to comply with the FCC/ISEDC criteria. The handset may be safely held against the ear of the user. The telephone base shall be installed and used such that parts of the user's body other than the hands are maintained at a distance of approximately 20 cm (8 inches) or more.

# Consumer Information

- a. This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On the bottom of this equipment is a label that contains, among other information, a product identifier in the format US:AAAEQ##TXXXX. If requested, this number must be provided to the telephone company.
- An applicable certification jacks Universal Service Order Codes (USOC) for the equipment is provided (i.e. RJ45C) in the packaging with each piece of approved terminal equipment.
- c. A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant LAN cable (RJ45) and modular plug is provided with this product. An RJ45 jack should normally be used for connecting to the SIP equipment through the LAN cable. See installation instructions for details.
- d. If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice isn't practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.
- e. The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.
- f. Should you experience trouble with this equipment,

Snom Technology GmbH 1 (339) 227-6160 (select option 2)

for repair or warranty information. If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.

g. Please follow instructions for repairing if any (e.g. battery replacement section); otherwise do not alternate

or repair any parts of device except specified.

- h. Connection to party line service is subject to state tariffs. Contact the state public utility commission. public service commission or corporation commission for information.
- NOTICE: If your home has specially wired alarm equipment connected to the telephone line ensure the installation of this device does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.
- This equipment is hearing aid compatible

NOTICE: According to telephone company reports, AC electrical surges, typically resulting from lightning strikes, are very destructive to telephone equipment connected to AC power sources. To minimize damage from these types of surges, a surge arrestor is recommended.

### **Industry Canada**

This Class B digital apparatus complies with Canadian requirements: CAN ICES-3 (B)/NMB-3(B).

Operation of 5150-5350 MHz is restricted to indoor use only.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Privacy of communications may not be ensured when using this telephone.

The term "IC:" before the certification/registration number only signifies that the Industry Canada technical specifications were met. This product meets the applicable Innovation, Science and Economic Development Canada technical specifications.

#### **RF Radiation Exposure**

This VoIP phone also complies with Industry Canada RSS-102 with respect to Health Canada's Safety Code 6 for human exposure to radiofrequency electromagnetic

To maintain compliance with the radio frequency exposure requirement, the phone shall be installed and used so that parts of user's body other than hands keep a distance of

- Safety: IEC 62368-1
- Bluetooth 5.0
- Radio frequency band: 2.402-2.480 GHz (US, EMEA) Wireless LAN (WLAN, Wi-Fi): 802.11b/g/n/a/ac
- Radio frequency (RF) bands:
- EMEA: 2.412-2.472 GHz. 5.180-5.7 GHz US: 2.412-2.462 GHz. 5.150-5.850 GHz
- DECT frequency bands: 1.88–1.9 Ghz (Europe), 1.921536-1.928448 Ghz (U.S.A.)
- NFC: Standard ISO/IEC 14443, type A NFC tag
- EU/UK regulatory information:

| Frequency band           | Power   |
|--------------------------|---|
| 1881.792-1897.344<br>MHz | FP: 20.8 dBm (EIRP)   |
| 13.56 MHz                | 25.22 dBuA/m @ 3m   |
| Wi-Fi 2412 - 2472 MHz    | 18,32 dBm (EIRP)  |
| 5150 - 5250 MHz          | 20.03 dBm (EIRP)  |
| 5250 - 5350 MHz          | 16.47 dBm (EIRP)  |
| 5470 - 5725 MHz          | 16.19 dBm (EIRP)  |
| 2402 - 2480 MHz          | 5 dBm (EIRP)  |
| 2402 - 2480 MHz          | 2 dBm (EIRP)  |
| 432 - 528 kHz            | 24.46 dBuA/m @ 3m   |
|                          | 1881.792-1897.344<br>MHz<br>13.56 MHz<br>2412 - 2472 MHz<br>5150 - 5250 MHz<br>5250 - 5350 MHz<br>5470 - 5725 MHz<br>2402 - 2480 MHz<br>2402 - 2480 MHz |

# /\O

 Built-in rechargable Li-Polymer battery, 850mAh, 3.7V Connectors:

- ° 2 x RJ45 (Ethernet): 1 x LAN, 1 x PC
- 2 x 4P4C (optional corded handset, optional headset)
- 1 x RJ12 (for EHS); 2 x USB 2.0 ports, type A 1 x 5V DC power jack
- Ethernet: 2 x IEEE 802.3 / 1 Gigabit Ethernet switch

Power over Ethernet (PoE): IEEE 802.3af, Class 3 If PoE not available: Power adapter not included in delivery, available separately:

# /\Oi

Mass Power, model NBS18C050300D5, Snom PN 00004715, or NBS12E050200UV, Snom PN00004570 EU/UK: shipped with EU and UK clips U.S./Canada: shipped with U.S. clip

# Disposal of the device



This device is subject to European Directive 2012/19/EU and may not be disposed of with general household garbage. If you

do not know where to dispose the device at the end of its lifespan, contact your municipality, local waste management provider, or vendor

#### For countries outside the European Union

Disposal of electrical and electronic products in countries outside the European Union should be done in line with local regulations. Please contact local authorities for further information

#### Cleaning

To clean the device, use an anti-static cloth. Please avoid cleaning liquids as they might damage the surface or internal electronics of the device

Setting up and connecting the phone: See figures

# Initializing and registering the phone

NOTE: You will need the registration information received from your Internet service provider or your network administrator - normally the phone or extension number, the password, and the registrar

After you have set up the phone and connected it to the network, it will begin to initialize. Normally the initialization is completely automatic, using DHCP.

If your network does not support DHCP, you must obtain the IP address, netmask, IP gateway, and DNS server from your Internet service provider or your network administrator and enter them manually when you are asked to do so on the display.

Type the phone's URL shown on its display into the address bar of a browser on a PC connected to the same network as the phone to open the phone's Phone Manager.

- 1. Enter username and password and click Authenticate. 2. Click Preferences in the vertical menu on the left side.
- 3. Select the language and click Apply. The default is
- English. 4. Select the time zone and click Apply.
- 5. Select the tone scheme (dial tone) and click Apply. 6. Click **Identities** in the vertical menu on the left side and select **Profile**.
- 7. Enter the account number, the registrar, and the password received from your Internet service provider or administrator and click Apply.
- 8. The display shows the "Welcome to the Snom D892 deskphone" message.

For further information, please see our web page https://service.snom.com.

# FRANCAIS

Copyright, Marques Déposées, Non Responsabilitée

 $\hbox{@ 2024 Snom Technology GmbH. Tous droits réservés.}$ 

Snom, les noms des produits et les logos Snom sont des marques déposées par Snom Technology GmbH.

Toutes les spécifications du produit sont suiet à modifications sans préavis. Snom Technology GmbH se réserve le droit de modifier et de changer ce document à n'importe quel moment, sans devoir annoncer de telles modifications ou changements avant ou après leur mise en place.

Bien que le plus grand soin ait été apporté à la compilation et à la présentation des informations contenues dans ce document, les données sur lesquelles elles sont basées peuvent entre-temps avoir été modifiées. Snom doit donc décliner toute garantie et toute responsabilité guand à l'exactitude et à l'exhaustivité des informations publiées excepté en cas de négligence flagrante de la part de Snom ainsi que des les cas ou la responsabilité de Snom est engagée de par la loi.

# Informations importantes

Veuillez lire les informations concernant la sécurité et la mise au rebut de l'appareil ainsi que celles concernant son installation et son utilisation avant d'utiliser buanmderl'appareil. Communiquez également ces informations aux autres utilisateurs. Gardez ce manuel et ne cédez pas l'appareil à une tierce partie sans le manuel.

# Sécurité

Suivez les instructions présentes dans ce manuel et dans les autres documents concernant l'annareil

- Cet appareil est destiné à une utilisation professionnelle.
- Evitez de placer les câbles de l'appareil dans un endroit ou il est possible de trébucher dessus. Evitez également de les placer là ou ils pourraient être exposé à un écrasement car ils pourraient en être endommagé. Si les câbles ou la fiche sont endommagés, débranchez l'appareil et contactez du personnel d'entretien qualifié.
- La boite de sortie pour le bloc d'alimentation doit être à proximité de l'équipement et facilement accessible. Montez l'appareil uniquement à des hauteurs ne dépas-
- Cet appareil est destiné à une utilisation en intérieur uniquement! Ne l'installez pas au dehors!
- N'installez pas l'appareil dans des pièces très humides (par exemple, dans une salle de bain ou un sous-sol humide). N'immergez pas l'appareil dans l'eau et ne versez pas de liquides d'aucune sorte sur ou dans l'appareil.

(Bitte Blatt umdrehen, weiter auf der Rückseite)

vDRAFT 1₀0