



CG-201 USER MANUAL

Preparing for Use

Before you can use your cordless telephone, you must charge the HANDSET for 12 hours. Failure to do so will require recharging of the battery pack more often.

1. Place the HANDSET on the BASE UNIT for 12 hours.
2. After 12 hours, remove the HANDSET from the BASE UNIT.
3. RAISE THE BASE UNIT ANTENNA FOR THE BEST RECEPTION.

Before you can use your cordless telephone, you must charge the HANDSET for 12 hours. Failure to do so will require more frequent charging of the battery pack. See page 24 for more information on the battery pack.

Receiving Calls

1. When the phone rings, lift the HANDSET and press the TALK button. The BASE UNIT IN USE indicator will light up.
2. Start your conversation.
3. To end your conversation, either press the TALK button or place the HANDSET on the BASE UNIT. If the HANDSET is placed on the BASE UNIT charge cradle, the automatic STANDBY feature is then activated.

NOTE: The Call Timer will start to count once you press the TALK button.

Placing Calls

1. Press the TALK button, Call Timer starts to count. The BASE UNIT IN USE indicator will light up.
2. Listen for a dial tone.
3. Dial the phone number.
4. When finished with your call, press the TALK button again.

Redial Feature

1. If you get a busy tone, press the TALK button to hang up.
2. Press the TALK button again.
3. Listen for a dial tone.
4. Press the REDIAL button. This will automatically redial the last telephone number you called.
5. When finished with your call, press the TALK button again.


Caller ID System

This telephone automatically displays incoming caller's name and telephone number together with the date and time of the call. It records up to 80 calls and stores the data in memory.

IMPORTANT: You must subscribe to the Caller ID service from your local telephone company to utilize this feature.

Viewing Caller Information During Incoming Calls


1. When there is an incoming call, the name and the telephone number of the caller will automatically appear after the second ring. Press the ► button to view the name which has more than 11 digits.



OR Caller's telephone number will appear if the caller's name is not available.


OR "OUT OF AREA" will appear if the origin of the incoming call does not support Caller ID system.

e. g.



OR "UNKNOWN" will appear if the origin of the incoming call has no name and does not support Caller ID system.

e. g.



OR "PRIVATE" and/or "P-----" will appear if the caller's name and/or telephone number is blocked.

OR "DATE ERROR" will appear if wrong data was received from the telephone line.

OR The name stored in the Directory will appear for an incoming call with matching telephone numbers.

"MSG" (Message Waiting)

The MSG WAITING LED indicator will blink in green when there is a message for you from your telephone company if you have subscribed to Voice Mail message service and if you have requested Visual Message Indication from your local telephone company. "MSG" will appear on the LCD Screen in STANDBY mode.

(To remove the message waiting indicator, see page 10 for details.)

CHERISH TELECOM CO., LTD.

FCC ID: FNXCG-201

JOB #: 439AK0

EXHIBIT #: 18C

Call Waiting

When you have subscribed to Call Waiting service from your local telephone company, this telephone can indicate the name and number of the second caller while you are having a conversation.

1. When you are having a conversation, this telephone will automatically display the name and number of the second caller.
2. Press the FLASH button to answer the second caller. The first caller's name and number will be displayed.

e. g.

CHERICH
800-2-10-8950
00 MIN 18 SEC

2nd Caller

e. g.

ALEX BROWIN
604-555-1212
00 MIN 20 SEC

1st Caller

3. When you have finished, press the FLASH button to continue your conversation with your first caller.

"C-F" (Forwarded Call)

Appears on the upper left hand side, when the incoming call has been assigned to your telephone number.

"L-D-C" (Long Distance)

Appears on the upper left hand side, when the incoming call is a long distance call and the service is provided by your local telephone company.

Caller List

Records call information for up to 80 incoming calls such as caller's name and telephone number together with the date and time of the call. After recording a new incoming call, the display will look as shown below:

RING : HI
10:00am 11/18 NEW 18 TOTAL 20

No. of new calls.
Maximum calls = 80

1. Press the CALL button
2. Press the ▼ button to view the latest record, or
Press the ▲ button to view the first record, press the ► button if the name is more than 11 digits.

e. g.

ALEX BROWIN
604-555-1212
10:00am 11/18 NEW#20

►
←
→
◀

BROWING
604-555-1212
10:00am 11/18 NEW#20

3. Press the DIR. button to go back to STANDBY mode.

(If no activate buttons are pressed for 20 seconds or you have viewed the last record in the Caller's List, the LCD Screen will automatically return to STANDBY mode.)

CHERISH TELECOM CO., LTD.

FCC ID: FNXCG-201

JOB #: 439AK0

EXHIBIT #: 18D

Placing a Call from the Caller List

1. Press the CALL button.
2. Press the ▼ button to select from the latest record, or
Press the ▲ button to select from the first record.
3. Press the TALK button.
4. To end your conversation, either press the TALK button or place the HANDSET on the BASE UNIT.

NOTE: You can edit the number before dialing, but you cannot save any changes in the Caller List.

NOTE :The name of the caller and time called cannot be edited.


Saving the Name and Number in the Caller List into the Directory

1. Press the CALL button
2. Press the ▲ or ▼ button to find the caller.
3. Press the SAVE button.

NOTE: It is not advisable to save a telephone number without the corresponding name in the Directory. This will lead to improper displays of name information.


Deleting All Records in the Caller List

1. Press and hold down the DELETE button at STANDBY mode.
2. The LCD screen will automatically return to STANDBY mode.



Selective Deleting in the Caller List

1. Press the CALL button.
2. Press the ▲ or ▼ button to find the caller at STANDBY mode.
3. Press and hold down the DELETE button, then the LCD screen will display the next item in the directory.
4. Press the DIR. button to return to STANDBY mode.



CHERISH TELECOM CO., LTD.

FCC ID: FNXCG-201

JOB #: 439AK0

EXHIBIT #: 18E

Name and Telephone Number Directory

This directory lets you scroll through the list to find the person you need for one touch dialing. You can store up to 40 names and telephone numbers in the memory.

Viewing the Directory

1. Press the DIR. button.

| | |
|------------------------|----------------------|
| DIRECTORY | No. of memory stored |
| 10:00am 11/18 TOTAL 12 | |

2. Press the ▲ or ▼ button to find the one you need, press the ► button if the name or telephone number is more than 11 digits.

e.g.

| | | |
|--|---|--|
| ALEX BROWIN 604-555-1212 #1 TOTAL 12 | ► | BROWING 604-555-1212 #1 TOTAL 12 |
|--|---|--|

NOTE: To exit the Directory List at anytime, press the DIR. button.

Speed Viewing the Directory

1. Press the DIR. button.

2. Enter the first letter of a name.

(See page 22 for details of entering a letter.)

3. Press the ▼ button to find all names with the same first letter.

Saving in the Directory

1. Press the DIR. button at STANDBY mode.

2. Press the EDIT button.

3. Use the TELEPHONE KEYPAD button (0~9) to enter the name,

(See page 22 for details) you can store up to 15 characters.

4. Press the ▼ button once.

5. Enter the telephone number using the TELEPHONE KEYPAD button (0~9). You can store up to 16 digits.

6. Press and hold down the SAVE button.

7. Press the DIR. button to go back to STANDBY mode.

(If no activate buttons are pressed for 20 seconds, the LCD Screen will automatically return to STANDBY mode.)

NOTE: It will not save a duplicate telephone number or a name without the corresponding telephone number in the Directory.

Preferred Calls

You can assign a Preferred Call which will generate a special ringer sound at the start of the second ring to any welcome caller in the DIRECTORY. When you are saving the name and number into the DIRECTORY, add "#" mark at the beginning of the name by pressing the # button.

Blocked Calls

You can assign a Blocked Call which will disable the ringer sound from the second ring, to any caller in the DIRECTORY.

When you are saving the name and number into the DIRECTORY, add "*" mark at the beginning of the name by pressing the * button.

CHERISH TELECOM CO., LTD.
FCC ID: FNXCG-201
JOB #: 439AK0
EXHIBIT #: 18F

Editing Name and Number in the Directory

1. Press the DIR. button.
2. Press the ▲ or ▼ button to find the one you want to edit.

| |
|--------------|
| ALEX BROWIN |
| 604-555-1212 |
| #1 TOTAL 12 |

3. Press the EDIT button to edit the name.

e.g.

| |
|--------------|
| ALEX BROWIN |
| 604-555-1212 |
| #1 TOTAL 12 |

█ cursor is blinking

4. Press the ◀ or ▶ button to move the cursor to the letter or number you want to change.
To erase, press the DELETE button.
To add, use the TELEPHONE KEYPAD buttons (0~9).
5. Press the ▲ or ▼ button to edit the number.
6. Press the ◀ or ▶ button to move the cursor to the number you want to change.
To erase, press the DELETE button.
To add, use the TELEPHONE KEYPAD buttons (0~9).

e.g.

| |
|--------------|
| ALEX BROWIN |
| 604-555-1212 |
| #1 TOTAL 12 |

- cursor is blinking

7. Press and hold down.

IMPORTANT: It is not advisable to save a telephone number without the corresponding name in the Directory. This will lead to importer displays of name information.

NOTE: When no activate button are pressed for 20 seconds, the LCD Screen will automatically return to STANDBY mode.

Editing the Number in the Directory before Dialing

1. Press the DIR. button.
2. Press the ▲ and ▼ button to find the caller.
3. Press the EDIT button.
4. Press the ▼ button.

| |
|--------------|
| ALEX BROWIN |
| 604-555-1212 |
| #1 TOTAL 12 |

█ cursor is blinking

5. Press the ◀ or ▶ button to move the cursor to the number you want to change.
To erase, press the DELETE button. To add, use the TELEPHONE KEYPAD buttons.
6. Press the EDIT button.
7. Press the TALK button.
8. To end your conversation, either press the TALK button or place the HANDSET on the BASE UNIT.

NOTE: If you want to save the edited number in the Directory, follow steps 1 through 5 and then press the SAVE button.

Placing Calls from the Directory

1. Press the DIR. button.
2. Press the ▲ or ▼ button to find the one you want to call.
3. Press the TALK button.
4. To end ou conversation, either press the TALK button or place the HANDSET on the BASE UNIT.

Deleting All Records in the Directory

1. Press the DIR. button.
2. Press and hold down the DELETE button at STANDBY mode.
3. Press the DIR. button to return to STANDBY mode.

ALL DELETE
10:00am 11:18 TOTAL 0

Selective Deleting in the Directory

1. Press the DIR. button.
2. Press the ▲ or ▼ button to find the one you want to delete.
3. Press and hold down the DELETE button, then the LCD screen will display the next item in the directory.
4. Press the DIR. button to return to STANDBY mode.

DELETE
#1 TOTAL 12

Function Operation

This unit contains the following spacial functions:

| | | |
|------------------|---------------|----------------|
| A. LANGUAGE | D. AREA CODE | G. PBX ON/OFF |
| B. SILENT ON/OFF | E. CONTRAST | H. PAUSE TIME |
| C. TIME SET | F. PBX NUMBER | I. MSG WAITING |

To access, press the FUNC. button at STANDBY mode. then press the TELEPHONE KEYPAD (1~9) or the ▲ or ▼ buttons.

ENGLISH
#1 TOTAL 9

SILENT OFF
#2 TOTAL 9

TIME SET
10:00am 11/18 #3 TOTAL 9

KEYPAD Button #1

KEYPAD Button #2

KEYPAD Button #3

AREA CODE
#4 TOTAL 9

CONTRAST 4
#5 TOTAL 9

PBX NO. 9
#6 TOTAL 9

KEYPAD Button #4

KEYPAD Button #5

KEYPAD Button #6

PBX MODE OFF
#7 TOTAL 9

PAUSE TIME 2
#8 TOTAL 9

MSG WAITING OFF
#9 TOTAL 9

KEYPAD Button #7

KEYPAD Button #8

KEYPAD Button #9

CHERISH TELECOM CO., LTD.
FCC ID: FNXCG-201
JOB #: 439AK0
EXHIBIT #: 184

A. Language

This telephone offers English, Spanish and French languages for your convenience.

1. Press the FUNC. button.
2. Press the TELEPHONE KEYPAD #1 button.
3. Press the EDIT button.
4. Press the ▲ or ▼ button to select the type of language you desire.
English is the preset language.
5. Press and hold down the SAVE button.
6. Press the FUNC. button to go back to STANDBY mode.

B. Silent On/Off

This telephone will generate the first ring sound even in the Blocked Call mode to indicate that you have an incoming call. To keep silent in BLOCKED CALL mode you can turn off the first ring sound.

1. Press the FUNC. button.
2. Press the TELEPHONE KEYPAD #2 button.
3. Press the EDIT button.
4. Press the ▲ or ▼ button. Silent Off is the preset mode.
5. Press and hold down the SAVE button.
6. Press the FUNC. button to go back to STANDBY mode.

C. Time Set

Set the date and time.

1. Press the FUNC. button.
2. Press the TELEPHONE KEYPAD #3 button.
3. Press the EDIT button.
4. Use the TELEPHONE KEYPAD button to enter the month, date, hour and minute. The cursor moves automatically after entering each item. Press the TELEPHONE KEYPAD #1 for AM setting, or press the TELEPHONE KEYPAD #2 for PM setting.
5. Press the FUNC. button to go back to STANDBY mode.

NOTE: The date and time will automatically set, if you have subscribed to the Caller ID service from your local telephone company.

D. Area Code

1. Press the FUNC. button.
2. Press the TELEPHONE KEYPAD #4 button.
3. Press the EDIT button.
4. Use the TELEPHONE KEYPAD button to enter the AREA code.
5. Press and hold down the SAVE button.
6. Press the FUNC. button to go back to STANDBY mode.

CHERISH TELECOM CO., LTD.
FCC ID: FNXCG-201
JOB #: 439AK0
EXHIBIT #: 18I

E. Contrast

This unit enables you to select 8 brightness levels for the Large LCD display.

1. Press the FUNC. button.
2. Press the TELEPHONE KEYPAD #5 button.
3. Press the EDIT button.
4. Press the ▲ or ▼ button to adjust the brightness of the display.
Level 4 is the preset brightness.
5. Press and hold down the SAVE button.
6. Press the FUNC button to go back to STANDBY mode.

F. PBX Number

This unit enables you to preset the PBX number (such as an 8 or 9) while you are using a switchboard system.

1. Press the FUNC. button
2. Press the TELEPHONE KEYPAD #6 button
3. Press the EDIT button.
4. Press the ▲ or ▼ button. (9 is the preset PBX number.)
5. Press and hold down the SAVE button.
6. Press the FUNC. button to go back to STANDBY mode.

G. PBX Mode

This unit enables you to turn ON/OFF the PBX system depending on the telephone system you are using.

1. Press the FUNC. button.
2. Press the TELEPHONE KEYPAD #7 button.
3. Press the EDIT button.
4. Press the ▲ or ▼ button.

PBX MODE OFF - Set for direct line access. The preset PBX mode is OFF.

PBX MODE ON - When connected to a switchboard system.

5. Press and hold down the SAVE button.
6. Press the FUNC. button to go back to STANDBY mode.

NOTE; When placing a call in PBX mode ON, this telephone will automatically add the PBX number and a pause time before the dialed telephone numbers.

H. Pause Time

This unit enables you to adjust the pause time for dialing on switchboard system or long distance calls.

1. Press the FUNC. button.
2. Press the TELEPHONE KEYPAD #8 button.
3. Press the EDIT button.
4. Press the ▲ or ▼ button to adjust the pausing time. 2 seconds is the preset pause time.
5. Press and hold down the SAVE button.
6. Press the FUNC. button to go back to STANDBY mode.

CHERISH TELECOM CO., LTD.
FCC ID: FNXCG-201
JOB #: 439AK0
EXHIBIT #: 185

I. MSG Waiting (Message Waiting)

To turn off the Message Waiting LCD indicator.

1. Press the FUNC. button.
2. Press the TELEPHONE KEYPAD #9 button.
3. Press the EDIT button.
4. Press the ▲ or ▼ button.
5. Press and hold down the SAVE button.
6. Press the FUNC. button to go back to STANDBY mode.

IMPORTANT: Message Waiting LCD indicator will automatically turn on, if you have subscribed to Voice Mail message service and if you have Visual Message Indication from your local telephone company.

