

## 7" Multimedia Tablet



### Quick Start Guide

#### 4 - Turn Device ON/OFF/Standby Mode

**ON:** Press and hold the Power button until the loading screen appears. Once the lock screen appears, unlock the Tablet by swiping your finger from the left 'Unlock' icon to the right 'Unlock' icon (illustrated below). Should the display 'Timeout' (or go black) before you are able to unlock the device, press the Power button for one second to turn the display back on.



**OFF:** Press and hold the Power button until the Tablet options appear. The options will prompt you to tap 'OK' to power the Tablet off or 'Cancel' to return back to the Home screen.

**STANDBY:** To enter Standby mode, simple tap and release the Power button. To wake up from Standby, tap and release the Power button.

NOTE: Leaving the device in Standby mode when not in use will result in a small battery drain. Switch the Tablet off completely to conserve power between charges.

#### 8 - Settings: Date, Time, & Screen Timeout

**Manual Time Setting**  
A. Open the App Tray > Select 'Settings' > Scroll down to and tap 'Date & Time' > Select 'Set Time' > Set the hour and minute by tapping the arrow keys; then tap 'Set.'



**Manual Date Setting**  
A. Open the App Tray > Select 'Settings' > Scroll down to and tap 'Date & Time' > Select 'Set Date' > Set the month, date, and year by tapping the arrow keys; then select 'Set.'

**Screen Timeout**  
A. Open the App Tray > Select 'Settings' > 'Display' > 'Sleep.' B. A dialogue box will appear with several options to choose from. Tap the length of time (in seconds or minutes) before the Tablet goes black (to conserve battery life).



**Screen Timeout**  
A. Open the App Tray > Select 'Settings' > 'Display' > 'Sleep.' B. A dialogue box will appear with several options to choose from. Tap the length of time (in seconds or minutes) before the Tablet goes black (to conserve battery life).

#### 12 - Online Video Streaming

Your Tablet is capable of streaming videos directly from the Internet or via 3rd party streaming applications. To properly run certain applications Adobe® Flash® Player may be required. Popular streaming video applications are available through the Skytex App Store for download onto your Tablet. Prior to streaming films, download the application of your choice.



Note: To view video on your HDTV or monitor, connect using an optional HDMI cable and select the appropriate TV input.

#### 1 - Introduction

Thank you for purchasing the new 7" SKYTEX SP722 Android 4.0 tablet with capacitive multi-touch display. It is designed to keep you entertained and engaged for hours at a time. With 8GB\* of internal storage and MicroSD card slot for up to an additional 32GB, you can house a library of games, movies, music and eBooks. In addition, 5GB of free cloud storage is provided through the Cloudlink toolbox which includes other productivity Apps as well. View video files from your HDTV in high definition with HDMI®.

When connected to the internet, download many of your favorite Android Apps from the Skytex App Store. The Apps are optimized specifically for your screen size bringing you the best experience possible. In addition, the 1Mobile Market offers hundreds of thousands of Apps including gaming, productivity, children's education and more.

Visit us as [www.skytex.com/support](http://www.skytex.com/support) to register your product and receive additional information and updated FAQ's. It's recommended that you review the online user manual for more detailed instruction about your Tablet.

\*Approximately 1.5GB of internal storage is used for the OS, system files and pre-installed Apps.

**FCC Warning:**  
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) this device may not cause harmful interference, and  
(2) this device must accept any interference received, including interference that may cause undesired operation.


Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**FCC RF warning statement:** The device has been evaluated to meet general RF exposure requirement. The device can be used in portable expos


#### 2 - Device Controls and Ports



1. Volume –
2. Volume +
3. Power
4. Microphone
5. 3.5mm Audio Jack
6. Mini-HDMI 1.4 port
7. Mini-USB OTG port
8. DC IN
9. Webcam
10. Micro SD card reader
11. Speaker
12. Back Key
13. Home Key
14. Open Apps Key


#### 3 - Charging Your Device

Connect the AC adapter to your Tablet via the DC input on the bottom (illustrated below). The Tablet may also be charged via USB by connecting your Tablet to a PC with the included USB cable.




Note: When charging the tablet while powered OFF, the battery indicator will only appear momentarily. Although the battery indicator disappears, the tablet will continue to charge. A full charge takes approximately 3 hours.

#### 7 - Browse the Web




Your SKYPAD Tablet is equipped with a full HTML Web Browser that enables you to view webpages.  
A. To access the Web Browser select the icon from the App Tray.  
B. To enter a URL, tap the URL field at the top of the browser and enter the desired link using the QWERTY keyboard.  
C. Tap 'Go' to load the page.



Bookmark a Favorite Page  
A. Scroll to the top of the desired webpage.  
B. Tap the star on the URL field > Tap 'OK.'

#### 6 - Install Apps from Skytex App Store and 1Mobile Market




A. Tap the or to browse by category or Search for popular apps to download on to your Tablet. Select the desired App and download it. (You must be connected to the internet)

B. NOTE: Once your download has completed you will be prompted to install the app. Tap 'Install' and when completed the app will appear in the App Tray.

C. Tap 'Connect' to complete the connection.

Tip: Check the "Show Password" box to verify password was entered correctly.




Note: Google Play is not supported at this time.


#### 10 - Transfer Your Music/Photos/Videos

A. Connect your Tablet to your PC via the USB cable.  
B. A USB symbol will appear in the Notifications Bar/Bottom Bar.  
C. Select the USB icon that appears in the Notifications Bar/Bottom Bar.  
D. Tap 'USB Connected' > 'Turn on USB Storage.'

Drag-and-drop your music, video, and photo files between your Tablet and PC.



Note: Your Tablet will be recognized as an external drive. Once completed, tap 'Turn off USB Storage' and remove Tablet from your PC.



#### 11 - Playing Your Music/Videos/Photos



Play Music  
A. Go to App Tray then tap the 'Music' app.  
B. Select the desired song and adjust volume settings to your liking.  
C. To exit out of the app, tap 'Home' or 'Back.'  
D. To stop music playback, go back to the Music app and tap 'Pause.'




Watch Videos  
A. Go to the App Tray and select 'Super-HD Player'  
B. Select the movie file to view.  
C. Once the video begins, you may select playback controls that appear on the display.

View Photos  
A. Go to App Tray and select 'Super-HD Player'  
B. Tap on photo files you would like to view.

#### 14 - Setting up Your Email

A. From your App Tray, tap the 'Email' icon to enter the Email client.  
B. Enter an email address and a password.  
C. After you have entered your information, press 'Next' to move to the next step.  
D. The email app will test the incoming and outgoing mail servers. Once completed, you will be prompted to enter an account name and your name.  
E. The account name is used to identify the name of the account on the Tablet.  
F. Your name will be displayed on all outgoing messages sent from the email app on your Tablet.



Certain email providers will require you to enter more details about the type of account you are using. You will have three choices: POP3, IMAP, and Exchange. If unsure of your account type, please contact your email provider for more information

#### 15 - FAQ's

##### • How do I reset my Tablet?

If your Tablet won't turn on try resetting the device. To reset, first make sure the power source is unplugged. Press and hold the Power button for 10 seconds and then plug the power source back in. Press the Power button for another 2-3 seconds.

To erase all data on the Tablet go to Settings > Backup & reset > Factory Data Reset.

##### • Where can I download Android Apps from?

We've pre-installed the Skytex App Store and 1Mobile Market, giving you immediate access to well over 200,000 of the best Android apps available. Additionally, there are several 3rd party Android App stores that offer free and paid Apps that you'll find at the Skytex App Store for download. Google Play is not officially supported at this time.

##### • Why am I unable to connect to my Wi-Fi Network?

Make sure that the correct password is entered when connecting to your wireless network. To ensure a correct password is being entered enable the "Show Password" option and double check for a case sensitive password. If you are still having problems you may need to contact your Wireless provider.

##### • Why do I get a parsing error when I attempt to download apps from the 1Mobile Market?

We recommend force closing the application and clearing the cache data. To do this go to Menu > Settings > Apps (select 1Mobile Market) > Clear Data

If you continue to receive the parsing error, try downloading the application from the 1Mobile Market's website at [www.1mobile.com](http://www.1mobile.com).