



MOTOROLA

EN

MOTOROLA XT611

LIFE.  POWERED.



CONGRATULATIONS

MOTOROLA XT611

Your MOTOROLA **XT611** phone delivers more for your work and play!

- **Search:** Touch Search  to search across your apps, contacts, web, and maps—or just enter the address for a place or a web page.
- **Apps:** Open  **Market** to download games for fun, social networking apps to keep in touch (like Facebook™ or Twitter), or find something else you like with “**APPS**” on page 9.
- **Touchscreen:** Browse the web and pinch-to-zoom on the touch display in “**WEB**” on page 32.
- **Camera:** Capture photos and videos with the 5MP auto-focus camera in “**PHOTOS & VIDEOS**” on page 37.

Note: Some apps and features might not be available in all countries.

Caution: Before assembling, charging, or using your phone for the first time, please read the important safety, regulatory and legal information provided at the end of the guide.


MORE

- **Support:** Phone updates, PC software, online help and more at www.motorola.com/support.
- **Accessories:** Find accessories for your phone at www.motorola.com/products.

Dec.29th, 2011

YOUR PHONE

the important keys & connectors



CONTENTS

LET'S GO	5
HOME SCREEN & APPS	8
PERSONALIZE	12
CALLS	15
CONTACTS	19
MESSAGING	22
TEXT ENTRY	26
SCHEDULE	29
WEB	32
LOCATION	34
PHOTOS & VIDEOS	37
MUSIC	40
BLUETOOTH™, WI-FI, & CABLE CONNECTIONS	43
SECURITY	49
TROUBLESHOOTING	51
SAFETY, REGULATORY & LEGAL	52

LET'S GO

let's get you up and running

ASSEMBLE & CHARGE

1 Cover off



2 SIM in



3 microSD in (may already be inserted)



4 Battery in



5 Cover on



6 Charge up



Caution: Please read "**BATTERY USE & SAFETY**" on page 53.

SET UP & GO

Note: This phone supports apps and services that use a lot of data, so make sure your data plan meets your needs. Contact your service provider for details.

When you turn on your new phone, you can create or enter a Google™ account so that you can download apps, use Gmail™, and much more:

- 1 Press and hold Power/Lock key  to turn on your phone.
- 2 Touch the Android™ image to begin setup.
- 3 Touch a button to **Create** a Google account, **Sign in** with one you have, or **Skip**.
You can log into your account from a computer at accounts.google.com.
- 4 Enter details to create or sign into your account. When your phone confirms the account, it shows account sync options.
 - To change whether your phone shows the Google account's contacts, Gmail™, and calendar, touch the Google account name.
 - To add another account, touch **Add account**. For details, see "**EMAIL**" on page 23.
 - To exit setup touch Home .

**Power/
Lock Key**



If your phone cannot connect, you can touch Menu  > **Wireless & networks** > **Wi-Fi settings** to change mobile network settings.

FLIP CLOSED

You can access some of the features on your phone, such as answering an incoming call, playing music or viewing a message, with the flip closed.

To lock the screen when the flip is closed, touch Menu  > **Settings** > **Display** > **Close flip to lock screen**.

SLEEP & WAKE UP

Your screen sleeps when you hold it to your ear during a call, or when it is inactive. To change the sleep delay, touch Menu  > **Settings** > **Display** > **Screen timeout**.

KEYS

Use your phone's keys to navigate and open options at any time.

Press the volume keys to change the ringer volume (in the home screen), or the earpiece volume (during a call).

From any screen, press the camera key on the right side of the phone to open the camera.

Touch Home  to return to the home screen. Touch and hold Home  to see your recent apps.


HOME SCREEN & APPS

a few essentials

Use your home screen for quick access to apps, search, and more. Download social networking apps to keep in touch!

QUICK START: HOME SCREEN

You'll see the home screen when you turn on the phone or touch Home  from a menu:



Status Indicators

Notifications

Flick down for details.

Widgets

Touch to open. Touch & hold to move or delete.

Drag or flick to open panels (or scroll in lists).

Shortcuts

Open the app menu.

- To open shortcuts or widgets, **touch** them. Touch Home  to return to the home screen.

When you open shortcuts or widgets, touch Menu  for options.

- To move or delete shortcuts or widgets, **touch and hold** them until you feel a vibration, then drag it to another spot, another panel, or  at the top.

In lists like **Contacts**, touch and hold list items for options.

- To add shortcuts, widgets, or wallpaper, touch and hold an empty spot until you see the menu. You can also add a folder to organize your shortcuts.
- To show more panels, **drag** or **flick** right or left. Touch and hold Home  to show recent apps.

In lists like **Contacts**, drag or flick to scroll.

To change your ringtone, display brightness, and more, touch Menu  > **Settings** > **Sound** or **Display**. For details, see “**PERSONALIZE**” on page 12.

APPS

To show your **apps menu**, touch .

- To scroll through the menu, flick up or down.
- To open an app, touch an icon.
- To close the app menu, touch Back .

Tip: To show the last eight apps you opened, touch Home  from the home screen.

To **download** new apps from Android Market™, touch  >  **Market**. Touch Search  to find an app, or touch **My Apps** to show or reinstall the apps you downloaded. To download apps from websites, you need to change your security settings: Touch Menu  > **Settings** > **Applications** > **Unknown sources**.

Tip: Choose your apps and updates carefully, from trusted sites like  **Market**, as some may impact your phone's performance—see “**CHOOSE CAREFULLY**” on page 9.


Note: When installing an app, make sure you read the alerts that tell you what information the app will access. If you don't want the app to have access to this information, cancel the installation.

To **move or uninstall** your apps, touch Menu  > **Settings** > **Applications** > **Manage applications**. Touch an app in the list to show details and options.

On your computer, you can browse and manage apps for all your devices powered by Android™ at market.android.com.

PHONE STATUS & NOTIFICATIONS

In the status bar at the top of your screen, the right side shows phone status. The left side shows new messages or events (for details, flick the bar down).



	network strength		battery strength
	new voicemail		new text message
	Bluetooth™ on		Bluetooth connected
	Wi-Fi connected		airplane mode
	USB connected		alarm set
	silent ringer		silent ringer, vibrate on
	mute call		speakerphone


PERSONALIZE

add your personal touch

Customize your phone's sounds and appearance to make it unique to you!


QUICK START: PERSONALIZE

From the home screen, touch Menu  > **Settings** > **Sound** or **Display**.



Choose separate volume settings for incoming calls, media, alarms, and notifications.

Call & Message Notifications



Turn on or off menu animations.

To...

Choose a **ringtone** or **vibration** for calls and messages

Touch Menu  > **Settings** > **Sound**, then choose **Phone ringtone**, **Notification ringtone**, or **Vibrate**.

Change the **volume**

Touch Menu  > **Settings** > **Sound** > **Volume**.

Turn **dialpad** sounds on or off.

Touch Menu  > **Settings** > **Sound** > **Audible touch tones**.

Turn menu **selection** sounds on or off

Touch Menu  > **Settings** > **Sound** > **Audible selection**.

Change your **wallpaper**

Touch and hold an empty spot on the home screen, then touch **Wallpapers**.

Change **shortcuts** and **widgets** on your home screen

Touch and hold them. For details, see "**HOME SCREEN & APPS**" on page 8.

Close flip to **lock screen**

Touch Menu  > **Settings** > **Display** > **Close flip to lock screen**.