

# Technical Description RE 429NT+ UHF

The basic functions of the main stages of the RE 429NT+ UHF are described below. The main board together with the sub-board constitute a functional unit. The complete board assembly is combined on a printed circuit board assembly jig and passes along the complete assembly process through to the adjustment and check of the data content. The pair of printed circuit boards are tuned together by means of the common learning process and can be treated as a self-contained functional unit.

## Contents:

	Technical Description RE 429NT+ UHF .....	1
1	MAIN BOARD RE429NT+ .....	2
	1.1 Power source and DC supply .....	2
	1.2 Antenna / Amplifier / Filter .....	2
	1.3 Crystall oscillator .....	3
	1.4 First mixer / Filter .....	3
	1.5 $\mu$ P Microprocessor / $\mu$ P-Clock / Reference voltage .....	3
	1.6 EEPROM .....	4
	1.7 Correlator .....	4
	1.8 AF-Amplifier .....	4
	1.9 Visual and audio indicators .....	4
	1.10 LCD Liquid Crystal Display .....	5
	1.11 Vibrator .....	6
	1.12 Key functions .....	6
2	SUBPRINT RE429NT+ .....	6
	2.1 DC-Voltage .....	7
	2.2 DC/DC-Converter .....	7
	2.3 ZF- IC .....	7
	2.4 Squelch .....	8
	2.5 Speech memory .....	8
3	PRINT INTERFACES OF RE429NT+ .....	9
	3.1 Connection from Main board - Subprint .....	9
4	CONNECTION FROM RECEIVER TO PERIPHERAL UNIT .....	10

## **1 MAIN BOARD RE429NT+**

The main board is designed as a 4 layer printed circuit board and is mounted with SMD components. The functional units and stages described below are contained on this board.

One important functional group comprises the HF input stage, oscillator and mixer up to the first IF signal processor. Another functional group combines the  $\mu$ P with clock generator, EEPROM, correlator, reference voltage and the push-button boards. The AF output amplifier with loudspeaker, indicator LEDs, vibrator and LCD are mounted on the reverse side of the main board.

### **1.1 Power source and DC supply**

The accumulator (nom. voltage= 1.26 V) or a battery serve as the power source.

The main board requires the following supply voltages:

$V_{BAT}$ = 1.26V /DC for the AF amplifier, vibrator, lamps, voltage monitor and supply of various transistor stages

$V_{DD}$ = 3 V/DC for the  $\mu$ P, correlator and EEPROM

$V+ = 1V$ /regulated for the HF-transistors.

Both the supply voltages  $V_{DD} = 3$  V and  $V+ = 1V$  are generated in the receiver using the DC/DC converter and the IF-IC (both on the sub-board).

If the accumulator voltage falls below 1.2V the battery alarm is activated via the  $\mu$ P (periodic beeping). From this moment on, the equipment is able to function for approximately five more hours. If the voltage drops below 1V DC for a short period, the equipment switches to the startup condition.

NiMH accumulators should be preferably used for the power source. It should be noted that when using a battery, the receiver recognizes it as a battery and therefore it cannot be charged.

### **1.2 Antenna / Amplifier / Filter**

The signal is picked up via (C1, C17) from the loop antenna L1. The antenna is tuned to resonance using capacitors C2, C4 and C16. The signal is then amplified by transistor T1 which operates in the common base mode. The desired frequency band is selected using a SAW filter which is with the L3, C12 and C13 for T1 and with the C41, C42 and L40 for T3 adapted.

### 1.3 Crystall oscillator

The oscillator uses the Colpitts configuration. The crystal frequency is trebled in the collector circuit for operation in the UHF band. The oscillator output is coupled to the mixer via coupling capacitor C44.

The oscillator frequency is 21.4 MHz lower than the received signal.

### 1.4 First mixer / Filter

The dual gate MOSFET T51 mixes the amplified input signal from the antenna with the local oscillator signal to generate the first IF signal at a frequency of 21.4 MHz. The resonant circuit formed by L51/C51 forms the load for this stage.

The IF-signal is then filtered by the crystal filter F51 after the mixer stage. The necessary impedance matching for the crystal filter is achieved using components R54, L51 and C51, together with R55, L52 and C55 as well as the input capacitance of IC201.

The IF-signal appears at the connector ST1 on the sub-board for further processing.

### 1.5 $\mu$ P Microprocessor / $\mu$ P-Clock / Reference voltage

The microprocessor 75336 (IC61) is used for processing the tone sequence and control of the equipment. This device contains mask programmed software.

The main function of the  $\mu$ P is the measurement of the AF frequency. Control routines are started by interrupts and run during time periods such that a valid call recognition is not affected.

The microprocessor requires two clock frequencies in addition to the supply voltages. Q63 supplies it with a 1.229 MHz operating clock and Q62 provides a 32.768 kHz clock for the Ecomode, LCD and an internal clock.

The voltage reference diode ZRA25 (IC42) provides the 2.5 V voltage rail which is used by the  $\mu$ P for monitoring the operating voltage.

To save power, the reference voltage is switched via pin 57 of the  $\mu$ P and is therefore only available at predetermined times.

## 1.6 EEPROM

In addition to the internal ROM of the  $\mu$ P, the equipment uses the 4 kBit EEPROM BR93LC66F (IC63) for data storage of the operating mode, call addresses etc. The data are loaded into the pager using a PC together with the PSW429NT+ software and the PGM 300/429 programmer.

## 1.7 Correlator

The FX102LS correlator (IC151) converts the AF signal to a digital pulse train with a fourfold increase in pulse frequency. It operates using a 614.4 kHz clock which is correlated with the input signal.

The  $\mu$ P decides whether or not it recognizes a valid call tone using the digital pulse train and a continuous output clock from the correlator at 102.4 kHz. Using the 614.4 kHz clock for the correlator reference guarantees that the input signal in the range 800 Hz -3 kHz is processed without error.

The correlator has an internal delay of 6 ms, but its use offers an improvement in sensitivity of 10 dB.

To save power, the correlator can be switched off via transistor T81

## 1.8 AF-Amplifier

The AF amplifier NJM2076M (UC91) operates from  $V_{BAT} = 1.26V$  and is switched by transistor T95. The volume is set by the voltage divider R92/R93/R94 and R95 which is controlled by the  $\mu$ P. The output power is typically 50 mW (level 3). The AF-amplifier receives signals from the  $\mu$ P (beeper tone signal) or via connector ST1 from the sub-board (AF-signal)

## 1.9 Visual and audio indicators

Visual signalling is achieved using both the red LED D62 and the display of the input address on the LCD display G62.

Audible signalling is made using the loudspeaker LS91. This signal lasts for 5 sec. for each address. Its tone (3 programmable frequencies) and beep pattern are selectable.


## 1.10 LCD Liquid Crystal Display

The LCD displays the different operating modes of the equipment for the user. The LCD is also visible at night using the lamp G61.


Significance of the different symbols:

**View of RE429NT+ Displays:**

**Quattrino (Voice, memo)**



**Quattrino (eco, tone)**



## 1.11 **Vibrator**

In addition to the visual and audible signals, the vibrator M61 also indicates the presence of an incoming call. The vibration pattern is the same for all addresses and is controlled from pin 56 of the µP.

## 1.12 **Key functions**

The following functions are executed by the keys labelled "EXECUTE" (right hand button):

- acknowledge call signalling
- call query
- call clear
- acknowledge battery alarm

Changes in the operating mode of the equipment are executed using the two buttons labelled "SELECT" and "EXECUTE". The "SELECT" push button (left hand button) switches between the different functions.

Only the released and programmed functions from the programming are displayed. A flashing display on the LCD indicates to the user which function has been selected.

The following settings can be selected via the push buttons:

- Acoustic ON      - mini beep      - acoustic OFF
- Monitor operation ON / OFF
- Volume of the speech message
- Field strength alarm ON / OFF

When both buttons are pushed simultaneously this

- switches ON
- or
- switches OFF the pager (after approx. 4 secs.).

Various sub-functions are described in more detail elsewhere in this documentation.

## 2 **SUBPRINT RE429NT+**

The sub-board is a four layer printed circuit board. The following stages are found on the sub-board: IF-amplifier, demodulator, AF-filter, squelch stage, DC/DC converter and speech memory as well as the associated clock generators. The circuit board interface is provided by a 24 pin socket array.

## 2.1 DC-Voltage

The following supply voltages are required by the sub-board:

$V_{BAT}$  = 1.26 V for the DC/DC converter, IF IC, various transistors

$V_{DD}$  = 3V Speech memory

$V_{+}$  = 1V IF-IC, squelch (transistors)

The required voltages  $V_{DD}$  = 3V and  $V_{+}$  = 1V are generated by the DC/DC converter and IF-IC.

## 2.2 DC/DC-Converter

For the generation of the voltage  $V_{DD}$  = 3 V out of the operating voltage  $V_{BAT}$ , the DC-DC / converter TPS60301 (IC 181) is utilised. In addition to the IC, the external components C184, C188, C182 and C186 are necessary.

L181, L182 and L184 serve for the reduction of the interferences from the DC - converter.

If the voltage  $V_{BAT}$  drops below 1 V, the detector (IC182) triggers the reset with the uP.

## 2.3 ZF- IC

In the 2nd mixing stage, the wanted signal on the sub-print is mixed down from 21,4 MHz to 455 kHz. The oscillator frequency of 20,945 MHz is supplied by the quartz Q201. The conversion to 455 kHz is effected by a mixer integrated in the ZF-module TA31145 (IC 100).

Thereafter the signal is filtered twice and amplified. The amplifiers are integrated in the ZF-IC, the filtering is taken care of by the two external ceramic filters F101 and F102, which also define the channel spacing (25 kHz / 12,5 kHz) for the receiver.

In a final step, by means quadrature modulation a mixing down to the base band (NF) is carried out. Quadrature demodulator and the downstream low pass filter are also integrated in the ZF-IC.

The signal mixed into the base band is further conducted through a low pass filter of the third order, which is formed by R131, R132, R133, C132, C133, C134 and an amplifier integrated in the ZF - IC. In this manner, one achieves the required reduction of 20 dB at 6 kHz. R134 and C136 are defined by the modulation type FM or PM. For PM, a further reduction of 6dB/octave takes place in the useful band (de-emphasis).

The signal is conducted onwards for further processing to the correlator NF/FX on the base print. Through the amplifier T171, the NF-signal reaches the voice memory and

the base print. the 3 dB – frequency range of the NF – signal is located at approx. 300 Hz and 3 kHz.

With the outputs of PIN 17 and 18, the ZF-IC controls the transistor T130, which outputs a controlled voltage of 1 V.

For the purpose of saving electric power, the ZF-module can be switched off through the transistor T121.

## 2.4 Squelch

The AF output signal sourced by the IF-IC passes through a high pass filter and is amplified twice. The high pass filter is a second order stage and is formed using components R142, R143, C141, C142 and an amplifier integrated in the IF-IC. The second amplification stage is realized using the external transistor T141.

The noise signal which results, lies in the frequency band from approx. 8-20 kHz is fed to a comparator which is also integrated in the IF-IC. The comparator threshold is set by resistor R146. The output of the comparator is smoothed by R148 and C144 and is then fed to the AD converter input of the  $\mu$ P (pin 58) as an analog voltage with a magnitude corresponding to the received noise level (squelch).

At the  $\mu$ P, the squelch determination is made from the average of two measurements which has an additional low pass filtering effect.

The programming defines at what level of the averaged squelch signal the AF amplifier is switched in. A hysteresis function is implemented (two different values for the on and off switching) which prevents the AF amplifier from being continuously switched on and off due to a varying squelch voltage. In practice this hysteresis corresponds to a level difference of 2-4 dB in the HF signal.

## 2.5 Speech memory

The speech memory is realized using the chip ISD 4002 (IC161). This chip is controlled by the 6 control lines MISO, MOSI, SCLK, SS, RAC and INT.

The record period can be selected between 1x80 secs 2 x 40 secs 3x26.6 secs or 4 x 20 secs. The speech memory can be enabled or disabled for specific addresses via programming. Messages which have been recorded can be replayed as often as required as long as they have not been erased and only recalled.

After each call input, the memory area with the earliest input time is overwritten. The last call always remains with the speech information as long as it will be overwritten.

### 3 PRINT INTERFACES OF RE429NT+

#### 3.1 Connection from Main board - Subprint

The main board and sub-boards are connected together with a 24 pin plug and socket.

Pin	Symbol	Connection	Function
1 V+	Sub	> Main	1 Volt supply
2 ZF	Main	> Sub	ZF-signal
3 GND	Main	= Sub	Ground
4 GND	Main	= Sub	Ground
5 NF/FX	Sub	> Main	NF Signal for Correlator
6 SQ	Sub	> Main	Squelch signal
7 RE	Main	> Sub	Eco mode (Receiver Enable)
8 REC/PL	Main	> Sub	Select record/ play mode
9 NF	Sub	> Main	NF Signal
10 GND	Main	= Sub	Ground
11 GND	Main	= Sub	Ground
12 GND	Main	= Sub	Ground
13 SCLK	Main	> Sub	Speech memory control
14 MISO	Main	< Sub	Speech memory control
15 MOSI	Main	> Sub	Speech memory control
16 <u>SS</u>	Main	> Sub	Speech memory control
17 VDD	Sub	> Main	3 V Supply voltage
18			
19 VDD	Sub	> Main	3 V Supply voltage
20 BAT+	Main	> Sub	1,26 V Accu /Battery voltage
21 RAC	Main	< Sub	Speech memory control
22 BAT+	Main	> Sub	1,26 V Akku /Battery voltage
23 <u>INT</u>	Main	< Sub	Speech memory control
24 RESET	Main	< Sub	Reset for $\mu$ P

## 4 CONNECTION FROM RECEIVER TO PERIPHERAL UNIT

The connection between the **LGxx 300/429 charger** and the **PGM 300/429 programmer** is made via the 6 pole edge connector on the main board. The access to this interface is possible through an opening in the casing.

The following signals appear on the edge connector:

Symbol	Function
HF/AF	Input HF signal/output AF signal
GND	Common ground
GND/S	Fixed ground (precontact)
DATA-OUT	Communication with charger/programmer
DATA-IN	Communication with charger/programmer
BAT+	Charge the accumulator, external supply operation